



NARUMI

Vol.7



TREASURED WHENEVER FOREVER

Since being established in 1946, NARUMI has been devoted to producing fine quality tableware that creates joy and happiness for all diners. In 1965, it succeeded in the mass production of bone china for the first time in Japan. Since then, NARUMI has gone on to make a name for itself as one of the major bone china manufacturers in retail and HoReCa sectors worldwide.

Long-Standing Trust from Professionals

In 1975, NARUMI launched for the first time a bone-china collection specially designed for hotel and restaurant use. Since then, the quality of NARUMI Bone China has become well-known among hoteliers of star-rated hotels and restaurants across the world. Over the past 50 years, NARUMI products have exported to more than 100 countries.

With its own in-house design studio and production facilities, NARUMI is committed to providing the highest level of quality and flexibility in all stages, from design and prototyping to production and quality checks.

Characteristics of NARUMI Bone China

Excellent body

NARUMI uses glaze specifically developed for NARUMI Bone China, which creates unsurpassed luster on the surface of bone china. It also has a long history of hand-crafted moulds that create a beautiful relief.

Chipping resistance

Due to its dense crystal structure, NARUMI Bone China is durable and can withstand considerable shock and heavy usage in the hospitality industry.

Functionality

NARUMI Bone China has an outstanding unity when stacked. NARUMI has a high standard for dimensional control to maintain the shape and size; hence, the bone china takes up less space in cabinets, which makes it easier for large-scale outlets.

Beautiful decoration colors

NARUMI uses screen printing for decorating the bone china. This decoration technique makes it possible to create a wide range of designs, including complex motifs and detailed watercolors. Due to the special glaze used for the bone china, the color paints sink into the china body and create beautiful color patterns.



CULINARY DELIGHT

While the world has experienced dramatic changes over the past few years, the joy of having an excellent meal will not fade away. As people come together to eat, they expect a high standard and a memorable dining experience. In addition to safety and cleanness, diversity and uniqueness are the keys for filling the appetite of diners. NARUMI is committed to creating a joyful and unforgettable dining experience with our quality, creativity and innovation.



CONTENTS

■ NEW IN	
RYDGES	6 - 7
WALTZ	8 - 9
nomadd	10 - 13
aeca	14 - 15
■ CHEF'S	16 - 23
■ SHOW PLATE / A LA CARTE PLATE	24 - 31
■ DÉCOR	
RAMAGE / QUEEN'S GARDEN	34 - 35
GOLD COUTURE	36 - 37
KIKKA	38
MONTMARTRE	39
GLOWING	40 - 41
NEW RIM (WHITE)	42 - 43
ANATOLIA BLUE	44
NOCTURNE	45
MIREI BLUE	46
SHAGREEN BLACK	47
PATTERN VARIATIONS	48 - 49
FLAT RIM (WHITE)	50 - 51
CAVIAR WHITE	52
GOLD DUST / CRYSTAL PLATINUM	53
CANYON	54
GRAIN	55
BAMBOO PEARL	56
PATTERN VARIATIONS	57
■ WHITE DECORATION	
ESPRIT	60 - 63
STRATA	64 - 65
ARIA	66 - 67
TERRACE RELIEF	68 - 69
SENSE	70 - 73
COOL COUPE	74 - 75
■ TASTE OF EAST	
CHINESE (WHITE)	78 - 83
PATTERN VARIATIONS	84 - 85
WAKU	86 - 87
OPERA	88
SQUARE	89
DICE / HAMMER	90
BEAT / OVAL	91
ROYAL COURT	92 - 93
LOTUS	94 - 95
LEAF	96 - 97
NOBLE	98
SILKY	99
■ ACCESSORIES	100 - 111
■ CUSTOM-MADE SOLUTIONS	112 - 116

NEW IN

Selected shapes and glazes that match with the latest culinary trends.







RYDGES

The design inspiration comes from the rhythms seen in natural landscapes, such as mountain ridges, ocean waves and strata. The designer began by imagining what it would be like if the earth were cut out and made into a plate. The rhythmical relief carved on the white bone china can become the best canvas for a chef.





52257-5977
28cm SIGNATURE PLATE
D279 • H22mm



58082-5976
27cm PLATE
D277 • H25mm
<Matte&Shiny>



52257-6004
27cm DEEP PLATE
D277 • H52mm
58082-6004
27cm DEEP PLATE
<Matte&Shiny>



52257-5976
27cm PLATE
D277 • H25mm



52257-6005
24cm PLATE
D242 • H22mm



52257-6006
20cm PLATE
D202 • H20mm



52257-5987
17cm PLATE
D170 • H18mm



52257-3696
15cm BOWL
D150 • H40mm • 320cc



51298-2831
TEA/COFFEE CUP
L124 • S98 • H68mm • 280cc
52257-6030
TEA/COFFEE SAUCER
D165 • H16mm



52257-3676
42cm OBLONG BOWL
L421 • S212 • H42mm



52257-3677
25cm OVAL BOWL
L264 • S202 • H90mm



LEFT : 58082-5976 (MATTE & SHINY)
RIGHT : 52257-5976 (SHINY)



WALTZ

Swaying motions, such as ocean waves and fluttering cloths, are incorporated into the organic curve of the collection. As the form is carefully designed to achieve the best balance of width and depth, the plate can be used widely and freely from its edge to the centre. It comes in different sizes to accommodate various cuisines.





52215-5930
28cm PLATE
D289 • H25mm



52215-6032
27cm PLATE
D275 • H19mm
52215-6033
23cm PLATE
D233 • H25mm
52215-6019
20cm PLATE
D202 • H22mm
52215-6034
16cm PLATE
D165 • H18mm



52215-5948
29cm DEEP PLATE
D291 • H56mm
52215-5940
25cm DEEP PLATE
D253 • H52mm
52215-5980
22cm DEEP PLATE
D224 • H48mm



52215-6035
26cm SOUP PLATE
D260 • H40mm



52215-9978
AMUSE CUP
D117 • H72mm



52215-5949
34cm OVAL BOWL
L341 • S215 • H46mm



52215-3670
SOUP BOWL
D106 • H62mm • 260cc



52215-5982
OVAL TRAY
L230 • S153 • H29mm



52215-3670 Soup Bowl can sit on
52215-5982 Oval Tray



52215-4738
CREAMER JUG 170cc
L107 • S74 • H77mm • 170cc



92626-93392
COVER FOR CHAPPEI
D85 • H23mm
52215-2992
CHAPPEI CUP
D99 • H57mm • 190cc
52215-6020
CHAPPEI SAUCER
D110 • H24mm



52215-3692
RICE BOWL
D112 • H52mm • 250cc



51290-4739
TEA POT W/COVER 900cc
L238 • S163 • H144mm • 900cc



Today, dining venues are not limited to only restaurants. You can enjoy a meal in-room, on the terrace, in the garden and in many more places. The nomadd collection proposes a flexible dining style in which diners can enjoy quality dining anytime and anywhere.





Stackable

As the plates and bowls are the same dimension, they can be stacked neatly and in many different ways. In lounges, you can use a pair of deep dishes to make a two-tier cake stand. At buffets, you can serve individual, covered portions of food in small bowls so that guests can easily pick up food they like without using tongs or other serving equipment.



Portable

The collection offers a Bento box-style solution to meet the growing demand for outdoor dining. Made of bone china characterised by its lightness and durability, it is ideal for transporting food and drinks in picnic baskets.



Adaptable

A simple and modular shape can be adapted for a variety of cuisine styles. With a range of design options and glazes available, the collection can be seasonally updated with different colors and patterns.

8cm
|

12cm
|

14cm
|

18cm
|

21cm
|

Plate/Cover



50131-3707
8cm PLATE
D80 • H15mm



50131-3709
12cm PLATE
D120 • H15mm



50131-3711
14cm PLATE
D140 • H15mm



50131-3713
18cm PLATE
D180 • H15mm



50131-3716
21cm PLATE
D210 • H15mm

Deep Dish



50131-3708
8cm DEEP DISH
D80 • H25mm



50131-3714
18cm DEEP DISH
D180 • H40mm

Bowl



50131-3710
12cm BOWL
D119 • H40mm



50131-3712
14cm BOWL
D140 • H50mm



50131-3715
18cm BOWL
D180 • H60mm

Deep Bowl



50131-3706
8cm DEEP BOWL
D80 • H54mm • 190cc



50131-3704
12cm DEEP BOWL
D120 • H80mm • 760cc



50131-3703
18cm DEEP BOWL
D180 • H100mm • 2,200cc

Option



50131-2991
MUG
L110 • S80 • H80mm • 300cc
※8cm PLATE(50131-3707)
can be used as a mug cover.



50131-9960
LEAF BOWL
L115 • S47 • H35mm
※Insert for 18cm Bowl(50131-3715)



50131-9959
QUARTER BOWL
L113 • S82 • H34mm
※Insert for 18cm Bowl(50131-3715)

COLOR VARIATIONS



58063 Sky Blue



58064 Earth Brown



58068 Heather Gray



58104 Cobalt Blue



58066 REACTIVE COLOR GLAZE

58066 KOKUTAN



58066-3713
18cm PLATE
D180 • H15mm



58066-3714
18cm DEEP DISH
D180 • H40mm



58066-3715
18cm BOWL
D180 • H60mm



58066-3708
8cm DEEP DISH
D80 • H25mm



58066-3716
21cm PLATE
D210 • H15mm

52473 BLUE MARBLE



52473-3707
8cm PLATE
D80 • H15mm



52473-3709
12cm PLATE
D120 • H15mm



52473-3716
21cm PLATE
D210 • H15mm



52473-3706
8cm DEEP BOWL
D80 • H54mm • 190cc



52473-3704
12cm DEEP BOWL
D120 • H80mm • 760cc



aeca

The word "aeca" refers to subtle beauty in ancient Japanese culture. The aeca collection creates a table of whimsical beauty represented by momentary changes of nature. In order to express this unique concept, a range of different color glazes are applied. The modern shape and translucent color glaze give an inspiring twist to conventional table setting.

Reactive color glaze is admired for its variegated coloring, which appears in irregular patches. The glaze that creates the coloration undergoes a chemical reaction, producing a particular pattern and variegation. Due to this finishing technique, variations in glaze and color are to be expected and each piece is subtly one of a kind. For the material, we use fine bone china—which is durable, thin, and light—as well as transparency glazing.



PURE COLOR GLAZE

● 58064 Earth Brown

● 58068 Heather Gray

● 58063 Sky Blue



58064-5636
28cm PLATE
D285 • H26mm

58064-5649
23cm PLATE
D233 • H25mm

58064-5638
21cm PLATE
D215 • H20mm

58064-5617
19cm PLATE
D190 • H20mm

58064-5667
16cm PLATE
D165 • H15mm



58064-5637
23cm SOUP PLATE
D230 • H46mm



58064-3635
16cm BOWL
D155 • H63mm • 770cc

58064-3636
14cm BOWL
D137 • H55mm • 500cc



58064-3657
14cm DEEP BOWL
D140 • H45mm • 340cc



58064-3571
13cm BOWL
D136 • H78mm • 670cc



58064-3637
11cm BOWL
D113 • H57mm • 310cc



58064-2955
8cm BOWL
D79 • H42mm • 100cc



58064-2695
TEA/COFFEE CUP
L113 • S90 • H65mm • 210cc

58064-1946
TEA/COFFEE SAUCER
D146 • H21mm



58064-2757
ESPRESSO CUP
L93 • S72 • H58mm • 120cc

58064-1222
ESPRESSO SAUCER
D124 • H18mm



58064-2696
LATTE CUP
L117 • S91 • H84mm • 280cc


58064-1217
LATTE SAUCER
D158 • H19mm



58064-2684
MUG
L113 • S78 • H100mm • 370cc

REACTIVE COLOR GLAZE

● 58066 KOKUTAN



58066-5636
28cm PLATE
D285 • H26mm

58066-5649
23cm PLATE
D233 • H25mm

58066-5638
21cm PLATE
D215 • H20mm

58066-5617
19cm PLATE
D190 • H20mm

58066-5667
16cm PLATE
D165 • H15mm



58066-5637
23cm SOUP PLATE
D230 • H46mm



58066-5864
31cm OCTAGONAL PLATE
L321 • S279 • H23mm

58066-5867
23cm OCTAGONAL PLATE
L227 • S202 • H17mm

58066-5868
21cm OCTAGONAL PLATE
L209 • S186 • H18mm



58066-5738
36cm OBLONG TRAY
L360 • S210 • H20mm

58066-5710
35cm OBLONG TRAY
L350 • S160 • H18mm

58066-5923
28cm OBLONG TRAY
L280 • S109 • H16mm



CHEF'S | The "chef's" items show NARUMI's commitment to food presentation. Some items have a distinctive shape or delicate relief to make the food stand out; others offer a unique way to serve food, such as pouring sauce and covering/uncovering a bowl. We hope that each piece of our production will resonate with chefs who can turn their inspiration into an exquisite presentation.



52063-5858
28cm PLATE (CASCADE)
D277 · H17mm



51290-5609
27cm AMUSE PLATE
D269 · H17mm



50131-5827
27cm PLATE
D277 · H20mm



51799-5816
28cm WIDE RIM PLATE
D279 · H34mm



52061-5852
28cm PLATE (SHOWER)
D279 · H22mm

58088-5852
<White Matte&Shiny>

58087-5852
<Black Matte&Shiny>



52199-5936
28cm PLATE (RUSTIC)
D280 · H22mm

58088-5936
<White Matte&Shiny>

58087-5936
<Black Matte&Shiny>



52062-5853
28cm PLATE (FOREST)
D280 · H22mm

58082-5853
<White Matte&Shiny>

58081-5853
<Black Matte&Shiny>



52061-5852
28cm PLATE (SHOWER)
D279 · H22mm

52061-6024
25cm PLATE(SHOWER)
D256 · H20mm

52061-6025
23cm PLATE(SHOWER)
D232 · H20mm



51985-5830
27cm PLATE(CRYSTAL)
D275 · H21mm



52060-5859
31cm PLATE(VENUS)
D328 · L310 · S264 · H26mm



58045-OC5220
30cm SERVICE PLATE
D301 · H28mm
<Black Matte&Shiny>



52201-5938
29cm PLATE(SWIRL)
D289 • H13mm
58082-5938
<White Matte&Shiny>
58081-5938
<Black Matte&Shiny>



52200-5937
29cm PLATE(HORIZON)
D289 • H13mm
58082-5937
<White Matte&Shiny>
58081-5937
<Black Matte&Shiny>



51090-5540
30cm FLAT PLATE
D301 • H24mm
51090-5831
26cm FLAT PLATE
D262 • H22mm



51985-5939
30cm OBLONG TRAY
L310 • S154 • H28mm



51985-9929
ROCK TRAY (M)
L140 • S107 • H37mm



51985-9930
ROCK TRAY (S)
L114 • S69 • H24mm



51985-9845
PEPPER SHAKER
(3HOLES)
D35 • H68mm
51985-9844
SALT SHAKER
(1HOLE)
D38 • H89mm
51985-9848
CLOUD DISH
L143 • S74 • H31mm



51800-5850
24cm SQUARE FLAT TRAY
L240 • S238 • H13mm



51800-5828
28cm OBLONG TRAY
D280 • S140 • H13mm



52060-5860
36cm TRAY (VENUS)
D363 • S151 • H21mm



51300-5525
34cm SQUARE 3 DIVIDED TRAY
L337 • S112 • H16mm



51300-5502
30cm SQUARE DIVIDED TRAY
L300 • S150 • H17mm



51300-5524
27cm SQUARE 4 DIVIDED TRAY
L266 • S266 • H17mm



51299-5602
16cm SQUARE DIVIDED TRAY
L160 • S80 • H13mm



51299-5601
8cm SQUARE TRAY
L80 • S80 • H13mm



51299-9798
7cm SMALL STAND (PLAIN)
L70 • S70 • H24mm



51300-9797
7cm SMALL STAND (RELIEF)
L68 • S72 • H24mm



52257-6004
27cm DEEP PLATE
D277 • H52mm

58082-6004
<White Matte&Shiny>



51799-5815
28cm WIDE RIM DEEP PLATE
D277 • H46mm



51800-5813
28cm WIDE RIM DEEP PLATE
D277 • H46mm



52215-5949
34cm OVAL BOWL
L341 • S215 • H46mm



58088-5948
29cm DEEP PLATE
D291 • H56mm

<White Matte&Shiny>

58088-5940
25cm DEEP PLATE
D253 • H52mm
<White Matte&Shiny>



58087-5948
29cm DEEP PLATE
D291 • H56mm

<Black Matte&Shiny>

58087-5940
25cm DEEP PLATE
D253 • H52mm
<Black Matte&Shiny>



58089-5948
29cm DEEP PLATE
D291 • H56mm

<Gray Matte&Shiny>

58089-5940
25cm DEEP PLATE
D253 • H52mm
<Gray Matte&Shiny>



58045-OC5219
27cm DEEP PLATE
D273 • H45mm

<Black Matte&Shiny>

58045-OC3452
23cm DEEP PLATE
D228 • H37mm
<Black Matte&Shiny>



52456-6021
28cm PLATE
D281 • H28mm



52466-6021
28cm PLATE
D281 • H28mm
<Platinum Line>



52456-6022
FOOTED PLATE
D187 • H70mm



52466-6022
FOOTED PLATE
D187 • H70mm
<Platinum Line>



51396-5664
27cm WIDE RIM PLATE
D278 • H24mm

51396-5665
24cm WIDE RIM PLATE
D246 • H22mm



50131-5964
15cm SLANT PLATE
D153 • H27mm
※This Plate sits on the
24cm Wide Rim Plate
(item code 51396-5565).



50131-9880
GARNISH PLATE
L153 • S52 • H20mm



50131-9881
LEAF BOAT
L148 • S64 • H32mm



52215-3670
10cm BOWL
D106 • H62mm • 260cc



52215-5982
OVAL TRAY
L230 • S153 • H29mm



52215-4738
CREAMER JUG 170cc
L107 • S74 • H77mm • 170cc




9795-4652
CREAMER JUG 100cc
L72 • S59 • H63mm • 100cc



51030-4667
CREAMER JUG 290cc
L145 • S78 • H102mm • 290cc



51030-4660
CREAMER JUG 170cc
L126 • S65 • H83mm • 170cc



52100-5873
26cm TRAY
L262 • S91 • H14mm



52100-5872
9.5cm SAUCE DISH (OCTAGONAL)
L95 • S85 • H22mm



52100-5884
8cm SAUCE DISH (ROUND)
D80 • H22mm



50460-98122
COVER FOR 6cm ROUND BOX
D60 • H17mm

50460-98121
6cm ROUND BOX
D60 • H27mm



50460-98122
COVER FOR 6cm ROUND BOX
D60 • H17mm

● 50460-2931
6cm ROUND BOX (DEEP)
D60 • H39mm



● 50460-29302
COVER FOR 10cm ROUND BOX
D104 • H32mm

● 50460-29301
10cm ROUND BOX
D104 • H54mm



50131-99362
COVER FOR SMALL MUFFIN DISH
D82 • H49mm

50131-99361
SMALL MUFFIN DISH
D104 • H18mm



50180-35852
COVER FOR 11cm CUP
D113 • H48mm

50180-26561
11cm CUP
D110 • H64mm



52061-36612
COVER FOR 25cm MUFFIN DISH
D176 • H104mm

9795-32704
25cm MUFFIN DISH
D258 • H33mm



50131-9799
CUBE OBJECT
L122 • S107 • H78mm



51290-4739
TEA POT W/COVER 900cc
L238 • S163 • H144mm • 900cc

SHOW PLATE A LA CARTE PLATE

Show plates play a crucial role in welcoming and making a good first impression on guests. An extensive variety of designs, each inspired by nature, traditions, unique local culture, and more, are available to choose from to suit the concept and atmosphere of the dining space.






58076-5462
27cm PLATE
D272 • H16mm



58077-5462
27cm PLATE
D272 • H16mm



58078-5462
27cm PLATE
D272 • H16mm



58075-1557
27cm PLATE
D269 • H24mm



58074-1557
27cm PLATE
D269 • H24mm




52207-5816
28cm WIDE RIM PLATE
D279 • H34mm



51993-5415
27cm WIDE RIM PLATE
D274 • H24mm



51994-5415
27cm WIDE RIM PLATE
D274 • H24mm



52209-1223
27cm PLATE
D269 • H23mm



51366-5599
24cm SQUARE RIM PLATE
L240 • S240 • H13mm



51365-5599
24cm SQUARE RIM PLATE
L240 • S240 • H13mm



51633-1670
30cm PLATE
D304 • H21 mm



51632-1670
30cm PLATE
D304 • H21 mm



52059-1670
30cm PLATE
D304 • H21 mm



52074-1670
30cm PLATE
D304 • H21 mm



52068-1670
30cm PLATE
D304 • H21 mm



52069-1670
30cm PLATE
D304 • H21 mm



50861-5495 33cm PLATE
50861-1670 30cm PLATE
50861-1557 27cm PLATE



50860-5495 33cm PLATE
50860-1670 30cm PLATE
50860-1557 27cm PLATE



52471-1670
30cm PLATE
D304 • H21mm



51615-5462
27cm PLATE
D272 • H16mm



96072-5462
27cm PLATE
D272 • H16mm



81405-5461
30cm PLATE
D302 • H17mm



51717-5461
30cm PLATE
D302 • H17mm



51693-5461
30cm PLATE
D302 • H17mm



51357-5727 30cm PLATE
51357-5664 27cm PLATE



51522-1670 30cm PLATE
51522-1557 27cm PLATE



51979-5513 29cm PLATE
51979-5514 23cm PLATE



52094-5461
30cm PLATE
D302 • H17mm

SHOW PLATE • A LA CARTE PLATE - UNDER GLAZE



Under-glazing is a decorating technique. As the decoration is applied under the glaze, it develops a beautiful gloss and excellent abrasion resistance.



●52138-1986 29cm FLAT PLATE
●52138-1866 26cm FLAT PLATE



●52139-1986 29cm FLAT PLATE
●52139-1866 26cm FLAT PLATE




●52204-1866
26cm FLAT PLATE
D259 • H14mm



●52208-1986 29cm FLAT PLATE
●52208-1866 26cm FLAT PLATE



●52253-1986
29cm FLAT PLATE
D288 • H17mm



●52243-1986
29cm FLAT PLATE
D288 • H17mm

●MADE IN JAPAN(SHIPMENT FROM JAPAN)



52468-1866
26cm FLAT PLATE
D259 • H14mm



97178-1866
26cm FLAT PLATE
D259 • H14mm



97179-1866
26cm FLAT PLATE
D259 • H14mm



52252-1866 29cm FLAT PLATE
52252-1866 26cm FLAT PLATE



52386-1866
26cm FLAT PLATE
D259 • H14mm



52387-1866
26cm FLAT PLATE
D259 • H14mm



51721-1986
29cm FLAT PLATE
D288 • H17mm



51720-1986
29cm FLAT PLATE
D288 • H17mm



95667-5312 30cm PLATE
95667-5242 27cm PLATE



51584-5462
27cm PLATE
D272 • H16mm



51555-1670
30cm PLATE
D304 • H21 mm

SHOW PLATE • A LA CARTE PLATE



52192-5865
29cm OCTAGONAL PLATE
L293 • S260 • H22mm



52178-5864 31cm OCTAGONAL PLATE
52178-5865 29cm OCTAGONAL PLATE



52193-5865
29cm OCTAGONAL PLATE
L293 • S260 • H22mm



52198-5875
27cm ROUND PLATE
D275 • H22mm



51867-1986
29cm FLAT PLATE
D288 • H17mm



51868-1986
29cm FLAT PLATE
D288 • H17mm



51870-1986
29cm FLAT PLATE
D288 • H17mm



51586-1986
29cm FLAT PLATE
D288 • H17mm



51585-1986
29cm FLAT PLATE
D288 • H17mm



51732-1986
29cm FLAT PLATE
D288 • H17mm



51589-1986
29cm FLAT PLATE
D288 • H17mm



8353-1986 29cm FLAT PLATE (GOLD)
8353-1866 26cm FLAT PLATE (GOLD)
51534-1866 26cm FLAT PLATE (PLATINUM)



96759-1986
29cm FLAT PLATE
D288 • H17mm




96824-1986
29cm FLAT PLATE
D288 • H17mm



51522-1986 29cm FLAT PLATE
51522-1866 26cm FLAT PLATE



96835-1986(GOLD) 29cm FLAT PLATE
96908-1986(PLATINUM) 29cm FLAT PLATE



51996-1866
26cm FLAT PLATE
D259 • H14mm



51995-1866
26cm FLAT PLATE
D259 • H14mm



96000-1866
26cm FLAT PLATE
D259 • H14mm



51897-1986
29cm FLAT PLATE
D288 • H17mm



51719-1986
29cm FLAT PLATE
D288 • H17mm

DÉCOR

A variety of designs for a
luxurious dining experience.







52468-5636
28cm PLATE
D285 • H26mm



52468-5617
19cm PLATE
D190 • H20mm



52468-5667
16cm PLATE
D165 • H15mm



52468-5637
23cm SOUP PLATE
D230 • H46mm



52468-3279
22cm ROUND
VEGETABLE BOWL
D220 • H89mm



52468-1231
38cm OVAL COUPE PLATTER
L384 • S275 • H31mm



52468-1913
11cm RICE BOWL
D118 • H57mm • 330cc



52468-1882
10cm SAUCE DISH DEEP
D105 • H29mm



52468-9549
SPOON(S)
L130 • S46 • H40mm



52468-6022
FOOTED PLATE
D187 • H70mm



52468-2473
TEA/COFFEE CUP
L124 • S98 • H59mm • 200cc
52468-1946
TEA/COFFEE SAUCER
D146 • H21mm



52468-4718
TEA POT W/COVER
1,200cc
L250 • S160 • H163mm • 1,200cc




52468-4392
SUGAR BOWL
W/COVER 250cc
L138 • S104 • H100mm • 250cc



52468-4391
CREAMER JUG
170cc
L104 • S72 • H91mm • 170cc




97178 Queen's Garden Red
97179 Queen's Garden Green



97178-5636
28cm PLATE
D285 • H26mm



97178-5617
19cm PLATE
D190 • H20mm



97178-5667
16cm PLATE
D165 • H15mm




97178-5637
23cm SOUP PLATE
D230 • H46mm



97178-3279
22cm ROUND
VEGETABLE BOWL
D220 • H89mm



97178-1231
38cm OVAL COUPE PLATTER
L384 • S275 • H31mm



97178-5710
35cm OBLONG TRAY
L350 • S160 • H18mm



97178-1913
11cm RICE BOWL
D118 • H57mm • 330cc



97178-1882
10cm SAUCE DISH DEEP
D105 • H29mm



97178-9549
SPOON(S)
L130 • S46 • H40mm



97178-2762
TEA/COFFEE CUP
D111 • S87 • H61mm • 270cc
97178-5706
TEA/COFFEE SAUCER
D157 • H20mm



97178-4740
TEA POT W/COVER
900cc
L254 • S118 • H128mm • 900cc



97178-4742
SUGAR BOWL
W/COVER 250cc
L140 • S78 • H90mm • 250cc



97178-4741
CREAMER JUG
170cc
L110 • S60 • H93mm • 170cc



52436-5864
31cm OCTAGONAL PLATE
L321 • S279 • H23mm



52436-5866
25cm OCTAGONAL PLATE
L244 • S217 • H19mm



52436-5867
23cm OCTAGONAL PLATE
L227 • S202 • H17mm



52436-5869
18cm OCTAGONAL PLATE
L182 • S162 • H16mm



52436-5873
26cm TRAY
L262 • S91 • H14mm



52436-5872
9.5cm SAUCE DISH (OCTAGONAL)
L95 • S85 • H22mm



52436-5884
8cm SAUCE DISH (ROUND)
D80 • H22mm



52436-3639
10cm RICE BOWL
D108 • H56mm • 230cc



52437-36402
COVER FOR SOUP CUP
D124 • H36mm

92626-32681
SOUP CUP
L142 • S121 • H56mm • 340cc

52437-1218
18cm SAUCER
D177 • H22mm



52437-29452
COVER FOR CHAPPEI
D86 • H26mm

52100-29451
CHAPPEI CUP
D98 • H58mm • 200cc

52437-5883
SAUCER (ROUND)
D108 • H18mm



52437-4719
TEA POT W/COVER 900cc
L215 • S138 • H104mm • 900cc



96970-1136
30cm PLATE
D309 • H30mm



96970-1120
27cm PLATE
D276 • H31mm



96970-1121
23cm PLATE
D233 • H24mm



96970-1122
21cm PLATE
D218 • H24mm



96970-1123
17cm PLATE
D177 • H19mm



51179-36562
SOUP CUP COVER (LOTUS KNOB)
D122 • H51mm

51050-35381
12cm ROUND BOWL
D117 • H68mm • 470cc

52437-1218
18cm SAUCER
D177 • H22mm



51556-9549
SPOON (S)
L130 • S46 • H40mm



52437-9468
CHOPSTICKS & SPOON REST
L110 • S55 • H15mm



51179-36592
COVER FOR 30cm PLATE
D217 • H111mm



52422-5820
27cm PLATE
D277 • H25mm



52424-5638
21cm PLATE
D215 • H20mm



52423-5637
23cm SOUP PLATE
D230 • H46mm



52422-1221
32cm OVAL PLATTER
L328 • S234 • H26mm



52424-3571
13cm ROUND BOWL
D136 • H78mm • 670cc



52423-2831
TEA/COFFEE CUP
L124 • S98 • H68mm • 280cc
52424-1128
COMMON SAUCER
D159 • H23mm



52424-2984
MUG
D119 • S92 • H83mm • 330cc



52424-1913
11cm RICE BOWL
D118 • H57mm • 330cc



52424-1882
10cm SAUCE DISH DEEP
D105 • H29mm



52424-9321
SPOON(L)
L138 • S45 • H50mm



51230 Montmartre Noir



51230-5513
29cm PLATE
D291 • H20mm



51230-5462
27cm PLATE
D272 • H16mm



51230-5514
23cm PLATE
D236 • H13mm



51230-5463
21cm PLATE
D214 • H12mm



51230-5472
16cm PLATE
D164 • H12mm



51230-1224
19cm PLATE
D193 • H21mm



51230-5239
25cm SOUP PLATE
D252 • H38mm



51230-5637
23cm SOUP PLATE
D230 • H46mm



51230-1541
10cm RICE BOWL
D106 • H50mm • 240cc



51230-2793
TEA/COFFEE CUP
L124 • S101 • H69mm • 270cc



51230-2794
ESPRESSO CUP
L97 • S75 • H61mm • 110cc
51230-5562
ESPRESSO SAUCER
D127 • H11mm

81635 Montmartre Rouge





52010 Glowing Gold - Pro

51989 Glowing Gold
51446 Glowing Platinum



52010 Glowing Gold - Pro
51552 Glowing Platinum - Pro



51552-1232
31cm PLATE
D309 • H32mm

51552-5636
28cm PLATE
D285 • H26mm

51552-5638
21cm PLATE
D215 • H20mm

51552-5667
16cm PLATE
D165 • H15mm



51552-2831
TEA/COFFEE CUP
L124 • S98 • H68mm • 280cc

51552-1217
16cm SAUCER
D158 • H19mm



51552-2830
ESPRESSO CUP
L83 • S63 • H44mm • 80cc

51552-5639
ESPRESSO SAUCER
D120 • H14mm



51552-4663
TEA POT
W/COVER 1,180cc
L248 • S155 • H124mm • 1,180cc



51552-4636
SUGAR BOWL
W/COVER 430cc
D104 • H104mm • 430cc



51552-4637
CREAMER JUG
310cc
L125 • S84 • H95mm • 310cc



51552 Glowing Platinum - Pro



51552-1757
47cm OVAL RIM PLATTER
L475 • S345 • H46mm

51552-1759
35cm OVAL RIM PLATTER
L357 • S262 • H37mm

51552-1760
30cm OVAL RIM PLATTER
L305 • S220 • H32mm

51552-1761
25cm OVAL RIM PLATTER
L254 • S193 • H30mm



51552-1842
36cm ROUND COUPE
PLATE DEEP
D361 • H51mm



51552-5637
23cm SOUP PLATE
D230 • H46mm



51552-9807
22cm BUTTER TRAY
L225 • S128 • H17mm



51552-1578
16cm SOUP BOWL
D160 • H56mm • 660cc



51552-1763
12cm NOODLE
SOUP BOWL
D117 • H51mm • 260cc



51552-1541
10cm RICE BOWL
D106 • H50mm • 240cc



51552-1765
9cm SHARK'S
FIN BOWL
D97 • H44mm • 170cc



51552-1882
10cm SAUCE
DISH DEEP
D105 • H29mm



51552-3268
SOUP CUP W/COVER (L)
L142 • S121 • H93mm • 340cc

51552-1218
18cm SAUCER
D177 • H22mm



51552-20903
CHAPPEI (M)
51552-95182
COVER
D72 • H12mm
51552-95181
CHINESE TEA CUP(M)
D83 • H50mm • 160cc
51552-9416
CHAPPEI SAUCER
D102 • H24mm



51552-4267S (醬油)
51552-4267R (辣油)
51552-4267V (酢)
SOYA/OIL/VINEGAR
CONTAINER
L90 • S73 • H102mm • 120cc



51552-33362
COVER FOR
23cm MUFFIN DISH
D174 • H84mm
51552-33154
23cm MUFFIN DISH
D230 • H33mm



51552-9549
SPOON (S)
L130 • S46 • H40mm



51552-9468
CHOPSTICKS &
SPOON REST
L110 • S55 • H15mm



8531-1670
30cm PLATE
D304 • H21mm

8531-1557
27cm PLATE
D269 • H24mm

8531-1269
23cm PLATE
D228 • H20mm

8531-1086
21cm PLATE
D212 • H17mm

8531-1558
19cm PLATE
D191 • H17mm

8531-1214
16cm PLATE
D167 • H14mm



8531-1219 43cm OVAL PLATTER
L434 • S315 • H30mm

8531-1220 38cm OVAL PLATTER
L383 • S271 • H26mm

8531-1221 32cm OVAL PLATTER
L328 • S234 • H26mm



8531-3281
24cm OVAL
VEGETABLE BOWL
L238 • S178 • H73mm



8531-3279
22cm ROUND
VEGETABLE BOWL
D220 • H89mm



8531-5282
29cm PASTA PLATE
D288 • H53mm



8531-1646
23cm RIM SOUP PLATE
D227 • H36mm • 350cc



8531-9212
23cm BUTTER TRAY
L224 • S122 • H26mm



8531-5762
17.5cm MEZZA BOWL
(DEEP)
D175 • H53mm



8531-5763
17cm MEZZA BOWL
D168 • H45mm



8531-5764
13cm MEZZA BOWL
D129 • H36mm



8531-1857
13cm FRUIT BOWL
D130 • H44mm



8531-1597
10cm BUTTER DISH
D103 • H21mm



8531-2438
TEA CUP
L125 • S100 • H62mm • 230cc
8531-1217
16cm SAUCER
D158 • H19mm



8531-2423
TEA/COFFEE CUP
L109 • S87 • H74mm • 240cc
8531-1217
16cm SAUCER
D158 • H19mm



8531-2427
ESPRESSO CUP
L88 • S68 • H59mm • 110cc
8531-1222
ESPRESSO SAUCER
D124 • H18mm



8531-2428
BOUILLON CUP
L151 • S120 • H53mm • 340cc
8531-1218
18cm SAUCER
D177 • H22mm



8531-2685
MUG
L123 • S94 •
H114mm • 370cc



8531-4359
COFFEE POT
W/COVER 1,320cc
L251 • S141 •
H215mm • 1,320cc



8531-4416
TEA POT
W/COVER 940cc
L250 • S152 •
H145mm • 940cc



8531-4464
TEA POT
W/COVER 550cc
L200 • S124 •
H127mm • 550cc



8531-4358
SUGAR BOWL
W/COVER 300cc
L133 • S111 •
H109mm • 300cc



8531-4357
CREAMER JUG
220cc
L122 • S87 •
H99mm • 220cc



8531-4414
CREAMER JUG
200cc
L114 • S81mm •
H86 • 200cc



8531-3283
CASSEROLE W/COVER 2,420cc
L248 • S217 • H181mm • 2,420cc
8531-3356
CASSEROLE W/COVER 4,280cc
L275 • S238 • H206mm • 4,280cc



8531-32821
GRAVY BOAT 560cc
L218 • S97 • H115mm • 560cc
8531-32064
GRAVY BOAT TRAY
L233 • S145 • H23mm
8531-59097
GRAVY BOAT W/TRAY
L233 • S145 • H125mm



8531-9318
SALT SHAKER
(3HOLES)
L54 • S41 • H85mm



8531-9319
PEPPER SHAKER
(5HOLES)
L54 • S41 • H85mm

WIDE RIM



8531-5128
32cm DEEP PLATE
D325 • H46mm



8531-5129
30cm PLATE
D309 • H26mm

8531-5130
27cm PLATE
D271 • H22mm

8531-5131
23cm PLATE
D231 • H 22mm

8531-5132
16cm PLATE
D166 • H14mm



8531-5415
27cm WIDE RIM PLATE
D274 • H24mm



50939-1670
30cm PLATE
D304 • H21mm

50939-1557
27cm PLATE
D269 • H24mm

50939-1269
23cm PLATE
D228 • H20mm

50939-1086
21cm PLATE
D212 • H17mm

50939-1214
16cm PLATE
D167 • H14mm



50939-1220 38cm OVAL PLATTER
L383 • S271 • H26mm

50939-1221 32cm OVAL PLATTER
L328 • S234 • H26mm



50939-1646
23cm RIM SOUP PLATE
D227 • H36mm • 350cc



50939-1857
13cm FRUIT BOWL
D130 • H44mm



50939-2423
TEA/COFFEE CUP
L109 • S87 • H74mm • 240cc

50939-1217
16cm SAUCER
D158 • H19mm



50939-2427
ESPRESSO CUP
L88 • S68 • H59mm • 110cc

50939-1222
ESPRESSO SAUCER
D124 • H18mm



50939-2428
BOUILLON CUP
L151 • S120 • H53mm • 340cc

50939-1218
18cm SAUCER
D177 • H22mm



50939-2685
MUG
L123 • S94 • H114mm • 370cc



50939-4416
TEA POT
W/COVER 940cc
L250 • S152 • H145mm • 940cc



50939-4464
TEA POT
W/COVER 550cc
L200 • S124 • H127mm • 550cc



50939-4358
SUGAR BOWL
W/COVER 300cc
L133 • S111 • H109mm • 300cc



50939-4357
CREAMER JUG
220cc
L122 • S87 • H99mm • 220cc



50939-4414
CREAMER JUG
200cc
L114 • S81 • H86mm • 200cc



50939-9318
SALT SHAKER
(3HOLES)
L54 • S41 • H85mm

50939-9319
PEPPER SHAKER
(5HOLES)
L54 • S41 • H85mm



50685 Nocturne Platinum
51035 Nocturne Gold

51527 Nocturne Platinum - Pro
51806 Nocturne Gold - Pro



51527-1670
30cm PLATE
D304 • H21mm

51527-1557
27cm PLATE
D269 • H24mm

51527-1269
23cm PLATE
D228 • H20mm

51527-1086
21cm PLATE
D212 • H17mm

51527-1214
16cm PLATE
D167 • H14mm



51527-1760 30cm OVAL RIM PLATTER
L305 • S220 • H32mm

51527-1042 23cm OVAL RIM PLATTER
L229 • S172 • H27mm



51527-5282
29cm PASTA PLATE
D288 • H53mm



51527-1857
13cm FRUIT BOWL
D130 • H44mm



51527-2423
TEA/COFFEE CUP
L109 • S87 • H74mm • 240cc

51527-1217
16cm SAUCER
D158 • H19mm



51527-2427
ESPRESSO CUP
L88 • S68 • H59mm • 110cc

51527-1222
ESPRESSO SAUCER
D124 • H18mm



51527-2685
MUG
L123 • S94 •
H114mm • 370cc



51527-4416
TEA POT
W/COVER 940cc
L250 • S152 •
H145mm • 940cc



51527-4464
TEA POT
W/COVER 550cc
L200 • S124 •
H127mm • 550cc



51527-4358
SUGAR BOWL
W/COVER 300cc
L133 • S111 •
H109mm • 300cc



51527-4357
CREAMER JUG
220cc
L122 • S87 •
H99mm • 220cc



51527-4414
CREAMER JUG
200cc
L114 • S81 •
H86mm • 200cc



51527-9318
SALT SHAKER
(3HOLES)
L54 • S41 • H85mm

51527-9319
PEPPER SHAKER
(5HOLES)
L54 • S41 • H85mm



51683 Mirei Blue
 51684 Mirei Baby White
 96404 Mirei Blue Mix & Match



51683-1670
 30cm PLATE
 D304 • H21mm



51683-1557
 27cm PLATE
 D269 • H24mm



51683-1269
 23cm PLATE
 D228 • H20mm



51684-1558
 19cm PLATE
 D191 • H17mm



51683-1214
 16cm PLATE
 D167 • H14mm



51683-1220 38cm OVAL PLATTER
 L383 • S271 • H26mm



51683-1646
 23cm RIM SOUP PLATE
 D227 • H36mm • 350cc



51684-1857
 13cm FRUIT BOWL
 D130 • H44mm



51684-9318
 SALT SHAKER
 (3HOLES)
 L54 • S41 • H85mm
 51684-9319
 PEPPER SHAKER
 (5HOLES)
 L54 • S41 • H85mm



51684-2428
 BOUILLON CUP
 L151 • S120 • H53mm • 340cc

51683-1218
 18cm SAUCER
 D177 • H22mm



96404-4359
 COFFEE POT
 W/COVER 1,320cc
 L251 • S141 •
 H215mm • 1,320cc



96404-4416
 TEA POT
 W/COVER 940cc
 L250 • S152 •
 H145mm • 940cc



96404-4358
 SUGAR BOWL
 W/COVER 300cc
 L133 • S111 •
 H109mm • 300cc



51684-4357
 CREAMER JUG 220cc
 L122 • S87 •
 H99mm • 220cc



51684-2423
 TEA/COFFEE CUP
 L109 • S87 • H74mm • 240cc
 51683-1217
 16cm SAUCER
 D158 • H19mm



51684-2427
 ESPRESSO CUP
 L88 • S68 • H59mm • 110cc
 51683-1222
 ESPRESSO SAUCER
 D124 • H18mm



50994-1670
30cm PLATE
D304 • H21mm

50994-1557
27cm PLATE
D269 • H24mm

50994-1269
23cm PLATE
D228 • H20mm

50994-1086
21cm PLATE
D212 • H17mm

50994-1214
16cm PLATE
D167 • H14mm



50994-1220 38cm OVAL PLATTER
L383 • S271 • H26mm

50994-1221 32cm OVAL PLATTER
L328 • S234 • H26mm



50994-1646
23cm RIM SOUP PLATE
D227 • H36mm • 350cc



50994-1857
13cm FRUIT BOWL
D130 • H44mm



50994-2710
TEA/COFFEE CUP
L114 • S88 • H65mm • 270cc

50994-5368
COMMON SAUCER
D159 • H18mm



50994-2713
ESPRESSO CUP
L88 • S68 • H61mm • 140cc

50994-5370
ESPRESSO SAUCER
D125 • H20mm



50994-2712
BOUILLON CUP
L161 • S122 • H50mm • 350cc

50994-5369
BOUILLON SAUCER
D171 • H18mm



50994-4583
COFFEE POT
W/COVER 810cc
L233 • S96 •
H162mm • 810cc



50994-4601
TEA POT
W/COVER 500cc
L210 • S97 • H120mm • 500cc



50994-45842
COVER FOR SUGAR BOWL
L100 • S85 • H42mm

50994-45841
SUGAR BOWL 300cc
L97 • S80 • H62mm • 300cc



50994-4589
CREAMER JUG 100cc
L89 • S62 • H43mm • 100cc



50994-2731
MUG
L115 • S84 • H112mm • 370cc

PATTERN VARIATIONS



8971 Golden Crown
8970 Briarcliffe (Platinum)



50200 Space Moon



50454 Rochelle



50064 Caress



52102 Botanica



51871 Patricia



51377 Anatolia Blue, White Background



97040 Anatolia Copper, Mix & Match
52266 Anatolia Copper, White Background



50736 Eloise



51685 Mirei Noir
51686 Mirei Elegant White
96405 Mirei Noir Mix & Match



51702 Mirei Rouge
51686 Mirei Elegant White
96422 Mirei Rouge Mix & Match



50832 Grace Garden



80740 Pembroke



51350 Pembroke Platinum



51289 Windsor



50938 Golden Coin



51774 Platinum Coin



51351 Swirl Ring



51010 Gold Diamond
51011 Platinum Diamond



51759 Tiara Gold
51760 Tiara Platinum



52116 Chester



51898 Duo Gold
51899 Duo Platinum



51955 Birch



52148 Shagreen Orange

FLAT RIM



51030-5495
33cm FLAT RIM PLATE
D336 • H17mm



51030-5461
30cm FLAT RIM PLATE
D302 • H17mm



51030-5513
29cm FLAT RIM PLATE
D291 • H20mm



51030-5462
27cm FLAT RIM PLATE
D272 • H16mm



51030-5514
23cm FLAT RIM PLATE
D236 • H13mm

51030-5963
25cm FLAT RIM PLATE
D253 • H16mm



51030-5463
21cm FLAT RIM PLATE
D214 • H12mm



51030-5472
16cm FLAT RIM PLATE
D164 • H12mm



51030-5239
25cm SOUP PLATE
D252 • H38mm



51030-5464
23cm SOUP PLATE
D237 • H33mm • 270cc



51030-9787
23cm BUTTER TRAY
L235 • S150 • H14mm



51030-3556
23cm VEGETABLE BOWL
D227 • H94mm • 1,940cc



51030-3665
19cm BOWL
D192 • H70mm • 1,250cc



51030-3633
16cm BOWL
D159 • H65mm • 760cc



51030-3555
14cm BOWL
D141 • H58mm • 540cc



51030-2882
12cm BOWL
D122 • H50mm • 350cc



51030-2762
TEA/COFFEE CUP
L111 • S87 • H61mm • 270cc
51030-5706
16cm SAUCER
D157 • H20mm



51030-2985
TEA/COFFEE CUP
L97 • S74 • H63mm • 200cc
51030-6009
15cm SAUCER
D151 • H18mm



51030-2876
ESPRESSO CUP
L80 • S59 • H53mm • 100cc
51030-5707
ESPRESSO SAUCER
D112 • H14mm



51030-2762
TEA/COFFEE CUP
L111 • S87 • H61mm • 270cc
51030-5561
COMMON SAUCER
D166 • H11mm



51030-2876
ESPRESSO CUP
L80 • S59 • H53mm • 100cc
51030-5562
ESPRESSO SAUCER
D127 • H11mm



51030-4740
TEA POT W/COVER 900cc
L254 • S118 • H128mm • 900cc



51030-4742
SUGAR BOWL W/COVER 250cc
L140 • S78 • H90mm • 250cc



51030-4741
CREAMER JUG 170cc
L110 • S60 • H93mm • 170cc



51030-2959
TEA/COFFEE CUP
L119 • S95 • H68mm • 250cc
51030-5706
16cm SAUCER
D157 • H20mm



51030-2970
ESPRESSO CUP
L85 • S67 • H61mm • 120cc
51030-5707
ESPRESSO SAUCER
D112 • H14mm



50763-2712
BOUILLON CUP 350cc
L161 • S122 • H50mm • 350cc
51030-5708
BOUILLON SAUCER
D166 • H20mm



50763-2712
BOUILLON CUP 350cc
L161 • S122 • H50mm • 350cc
51030-5627
BOUILLON SAUCER
D183 • H12mm



51030-2887
TEA/COFFEE CUP
L125 • S101 • H68mm • 270cc
51030-5706
16cm SAUCER
D157 • H20mm



51030-2888
ESPRESSO CUP
L93 • S74 • H60mm • 110cc
51030-5707
ESPRESSO SAUCER
D112 • H14mm



51030-2964
CAPPUCCINO CUP
L139 • S120 • H70mm • 345cc
51030-5706
COMMON SAUCER
D157 • H20mm



51030-2887
TEA/COFFEE CUP
L125 • S101 • H68mm • 270cc
51030-5561
COMMON SAUCER
D166 • H11mm



51030-2888
ESPRESSO CUP
L93 • S74 • H60mm • 110cc
51030-5562
ESPRESSO SAUCER
D127 • H11mm



51030-4656
COFFEE POT W/COVER 820cc
L232 • S93 • H166mm • 820cc
51030-4655
COFFEE POT W/COVER 600cc
L209 • S92 • H146mm • 600cc



51030-4658
TEA POT W/COVER 950cc
L261 • S120 • H140mm • 950cc
51030-4657
TEA POT W/COVER 710cc
L231 • S106 • H122mm • 710cc



51030-4659
SUGAR BOWL
W/COVER 250cc
L108 • S87 • H83mm • 250cc



51030-4667
CREAMER JUG
290cc
L145 • S78 • H102mm • 290cc



51030-4660
CREAMER JUG
170cc
L126 • S65 • H83mm • 170cc



51030-4666
CREAMER JUG
100cc
L100 • S53 • H70mm • 100cc



51030-2793
TEA/COFFEE CUP
L124 • S101 • H69mm • 270cc
51030-5561
COMMON SAUCER
D165 • H11mm



51030-2794
ESPRESSO CUP
L97 • S75 • H61mm • 110cc
51030-5562
ESPRESSO SAUCER
D127 • H11mm



51030-2928
CAPPUCCINO CUP
L146 • S119 • H71mm • 345cc
51030-5561
COMMON SAUCER
D166 • H11mm



51030-4623
COFFEE POT W/COVER 1,800cc
L271 • S117 • H215mm • 1,800cc
51030-4713
COFFEE POT W/COVER 600cc
L209 • S92 • H146mm • 600cc



51030-4622
TEA POT W/COVER 1,340cc
L280 • S136 • H150mm • 1,340cc
51030-4714
TEA POT W/COVER 710cc
L231 • S106 • H122mm • 710cc



51030-4625
CREAMER JUG 290cc
L143 • S76 • H103mm • 290cc
51030-4715
CREAMER JUG 170cc
L126 • S65 • H83mm • 170cc
51030-4716
CREAMER JUG 100cc
L100 • S53 • H70mm • 100cc



51030-4624
SUGAR BOWL
W/COVER 340cc
L159 • S89 • H97mm • 340cc



52457-5462
27cm FLAT RIM PLATE
D272 • H16mm



52457-5463
21cm FLAT RIM PLATE
D214 • H12mm



52457-5472
16cm FLAT RIM PLATE
D164 • H12mm



52457-3633
16cm BOWL
D159 • H65mm • 760cc



52457-3555
14cm BOWL
D141 • H58mm • 540cc



52457-2762
TEA/COFFEE CUP
L111 • S87 • H61mm • 270cc
52457-5706
16cm SAUCER
D157 • H20mm



52457-4740
TEA POT W/COVER 900cc
L254 • S118 • H128mm • 900cc



52457-4742
SUGAR BOWL W/COVER 250cc
L140 • S78 • H90mm • 250cc



52457-4741
CREAMER JUG 170cc
L110 • S60 • H93mm • 170cc



52087 Gold Dust
52086 Crystal Platinum



52087-5461
30cm FLAT RIM PLATE
D302 • H17mm

52087-5462
27cm FLAT RIM PLATE
D272 • H16mm

52087-5514
23cm FLAT RIM PLATE
D236 • H13mm

52087-5463
21cm FLAT RIM PLATE
D214 • H12mm

52087-5472
16cm FLAT RIM PLATE
D164 • H12mm



52087-5702
38cm PLATTER
L383 • S241 • H27mm

52087-5701
32cm PLATTER
L327 • S207 • H23mm



52087-2887
TEA/COFFEE CUP
L125 • S101 • H68mm • 270cc

52087-5706
16cm SAUCER
D157 • H20mm



52087-5464
23cm SOUP PLATE
D237 • H33mm • 270cc



52087-2888
ESPRESSO CUP
L93 • S74 • H60mm • 110cc

52087-5707
ESPRESSO SAUCER
D112 • H14mm



52087-3633
16cm BOWL
D159 • H65mm • 760cc

52087-3555
14cm BOWL
D141 • H58mm • 540cc

52087-2882
12cm BOWL
D122 • H50mm • 350cc



52087-4655
COFFEE POT W/COVER 600cc
L209 • S92 • H146mm • 600cc



52087-4658
TEA POT W/COVER 950cc
L261 • S120 • H140mm • 950cc

52087-4657
TEA POT W/COVER 710cc
L231 • S106 • H122mm • 710cc



52087-4659
SUGAR BOWL
W/COVER 250cc
L108 • S87 •
H83mm • 250cc



52087-4667
CREAMER JUG 290cc
L145 • S78 • H102mm • 290cc

52087-4660
CREAMER JUG 170cc
L126 • S65 • H83mm • 170cc



52435-5513
29cm FLAT RIM PLATE
D291 • H20mm

52435-5462
27cm FLAT RIM PLATE
D272 • H16mm



52435-5514
23cm FLAT RIM PLATE
D236 • H13mm



52435-5463
21cm FLAT RIM PLATE
D214 • H12mm



52435-5239
25cm SOUP PLATE
D252 • H38mm



52435-3556
23cm VEGETABLE BOWL
D227 • H94mm • 1,940cc



52435-3555
14cm BOWL
D141 • H58mm • 540cc



52435-1221
32cm OVAL PLATTER
L328 • S234 • H26mm



52435-2959
TEA/COFFEE CUP
L119 • S95 • H68mm • 250cc
52435-5561
COMMON SAUCER
D166 • H11mm



52435-9318
SALT SHAKER
(3HOLES)
L54 • S41 • H85mm
52435-9319
PEPPER SHAKER
(5HOLES)
L54 • S41 • H85mm



81739-5462
27cm FLAT RIM PLATE
D272 • H16mm



81739-5463
21cm FLAT RIM PLATE
D214 • H12mm



81739-5472
16cm FLAT RIM PLATE
D164 • H12mm



81739-4658
TEA POT W/COVER 950cc
L261 • S120 • H140mm • 950cc



81739-4657
TEA POT W/COVER 710cc
L231 • S106 • H122mm • 710cc



81739-4660
CREAMER JUG 170cc
L126 • S65 • H83mm • 170cc



81739-3555
14cm BOWL
D141 • H58mm • 540cc



81739-2959
TEA/COFFEE CUP
L119 • S95 • H68mm • 250cc
81739-5706
16cm SAUCER
D157 • H20mm



81739-2970
ESPRESSO CUP
L85 • S67 • H61mm • 120cc
81739-5707
ESPRESSO SAUCER
D112 • H14mm



51678-5461
30cm FLAT RIM PLATE
D302 • H17mm

51678-5462
27cm FLAT RIM PLATE
D272 • H16mm

51678-5514
23cm FLAT RIM PLATE
D236 • H13mm

51678-5463
21cm FLAT RIM PLATE
D214 • H12mm

51678-5472
16cm FLAT RIM PLATE
D164 • H12mm



51678-5702
38cm PLATTER
L383 • S241 • H27mm

51678-5701
32cm PLATTER
L327 • S207 • H23mm



51678-5239
25cm SOUP PLATE
D252 • H38mm

51678-5464
23cm SOUP PLATE
D237 • H33mm • 270cc



51678-3633
16cm BOWL
D159 • H65mm • 760cc

51678-3555
14cm BOWL
D141 • H58mm • 540cc

51678-2882
12cm BOWL
D122 • H50mm • 350cc



51678-2887
TEA/COFFEE CUP
L125 • S101 • H68mm • 270cc

51678-5561
COMMON SAUCER
D166 • H11mm



51678-2888
ESPRESSO CUP
L93 • S74 • H60mm • 110cc

51678-5562
ESPRESSO SAUCER
D127 • H11mm



51678-4656
COFFEE POT W/COVER 820cc
L232 • S93 • H166mm • 820cc

51678-4655
COFFEE POT W/COVER 600cc
L209 • S92 • H146mm • 600cc



51678-4658
TEA POT W/COVER 950cc
L261 • S120 • H140mm • 950cc

51678-4657
TEA POT W/COVER 710cc
L231 • S106 • H122mm • 710cc



51678-4659
SUGAR BOWL
W/COVER 250cc
L108 • S87 • H83mm • 250cc



51678-4667
CREAMER JUG 290cc
L145 • S78 • H102mm • 290cc

51678-4660
CREAMER JUG 170cc
L126 • S65 • H83mm • 170cc

51678-4666
CREAMER JUG 100cc
L100 • S53 • H70mm • 100cc



51928 Charlotte



52405 Urban Copper
51673 Gold Line
51450 Platinum Line



51288 Dover



51677 Aurora



51906 Aurora Champagne Gold



52267 Aurora Pink



51876 Claire Gold



51571 Claire



52070 Golden Net
52088 Platinum Net



96732 Ruffle Gold



96543 Ruffle



96658 Victoria



WHITE DECORATION

Inspired by nature, such as the flow of water, botanical elements and light-dark contrasts.





50180-5220
30cm SERVICE PLATE
D301 • H28mm



50180-5312
30cm PLATE
D300 • H22mm



50180-5242
27cm DEEP PLATE
D276 • H21mm



50180-5243
23cm PLATE
D233 • H20mm



50180-5244
21cm PLATE
D208 • H15mm



50180-5245
18cm PLATE
D180 • H15mm



50180-5703
16cm PLATE
D159 • H12mm



50180-5219
27cm DEEP PLATE
D273 • H45mm



50180-3452
23cm DEEP PLATE
D228 • H37mm



50180-5304
23cm SOUP BOWL
D233 • H34mm



50180-35352
COVER FOR 26cm MUFFIN DISH
D147 • H71mm
50180-5221
26cm MUFFIN PLATE
D263 • H50mm



50180-2687
TEA CUP
L127 • S107 • H51mm • 230cc
50180-5305
COMMON SAUCER
D166 • H19mm



50180-2703
COFFEE CUP
L113 • S90 • H65mm • 210cc
50180-5305
COMMON SAUCER
D166 • H19mm



50180-2690
ESPRESSO CUP
L90 • S67 • H60mm • 100cc
50180-5315
ESPRESSO SAUCER
D123 • H17mm



50180-2774
CAPPUCCINO CUP
L139 • S112 • H66mm • 350cc
50180-5305
COMMON SAUCER
D166 • H19mm



50180-2688
MUG
L120 • S93mm
H102mm • 370cc
50180-5705
17cm SAUCER
D168 • H18mm



50180-4580
COFFEE POT
W/COVER 700cc
L208 • S110 •
H148mm • 700cc



50180-4653
COFFEE POT
W/COVER 530cc
L192 • S100 •
H139mm • 525cc



50180-4565
TEA/COFFEE POT
W/COVER 1,270cc
L272 • S162 •
H163mm • 1,270cc



50180-4628
TEA/COFFEE POT
W/COVER 800cc
L235 • S142 • H128mm • 800cc



50180-4654
TEA POT
W/COVER 550cc
L219 • S129 •
H115mm • 550cc



50180-4564
CREAMER JUG
220cc
L136 • S90 • H71mm • 220cc
50180-4581
CREAMER JUG
160cc
L110 • S86 • H68mm • 160cc



50180-4563
SUGAR BOWL
W/COVER 340cc
D114 • H103mm • 340cc



50180-2877
SUGAR BOWL
W/COVER 270cc
D99 • H98mm • 270cc



50180-28782
COVER FOR
10cm BOWL
D110 • H38mm
50180-2699
10cm RICE BOWL
D107 • H58mm • 230cc



50180-54302
CHAPPEI SET
92626-93392
COVER FOR CHAPPEI
D85 • H23mm
50180-2837
CHAPPEI CUP
D98 • H67mm • 240cc
92626-9416
CHAPPEI SAUCER
D102 • H24mm



50180-2708
9cm FREE CUP
D92 • H61mm • 210cc



50180-3497
22cm BOWL
D220 • H96mm • 1,760cc



50180-3515
19cm BOWL
D195 • H80mm • 1,230cc



50180-3554
16cm BOWL
D165 • H64mm • 700cc



50180-5313
14cm BOWL
D140 • H56mm • 420cc



50180-3565
13cm BOWL
D133 • H53mm • 370cc

50180-5704
16cm SAUCER
D161 • H14mm

50767(ITEM No.BB) White Matte&Shiny
50829(ITEM No.BA) White Matte
Available for hollowware only



50667 Gold Line
50668 Platinum Line



50180-3449
43cm OBLONG TRAY
L437 • S155 • H30mm



50180-3448
28cm OBLONG TRAY
L287 • S154 • H30mm



50180-3430
33cm SQUARE TRAY
L339 • S339 • H36mm

50180-3450
28cm SQUARE TRAY
L285 • S285 • H30mm

50180-3598
22cm SQUARE TRAY
L217 • S217 • H28mm




50180-5314
38cm OVAL PLATTER
L385 • S207 • H40mm

50180-5555
44cm OVAL PLATTER
L443 • S246 • H41mm



50180-9718
23cm OVAL TRAY
L234 • S129 • H16mm



50180-3431
12cm SQUARE TRAY
L123 • S123 • H22mm



50180-35852
COVER FOR 11cm CUP
D113 • H48mm

50180-26561
11cm CUP
D110 • H64mm



50180-3561
19cm COVERED SOUP BOWL
W/HANDLE
L235 • S194 • H126mm • 1,260cc



50180-27092
COVER FOR BOUILLON CUP
D138 • H40mm

50180-27091
BOUILLON CUP
L148 • S133 • H53mm • 370cc

50180-5331
BOUILLON SAUCER
D180 • H15mm



50180-98942
COVER FOR BOUILLON CUP
D138 • H44mm

50180-27091
BOUILLON CUP
L148 • S133 • H53mm • 370cc

50180-5331
BOUILLON SAUCER
D180 • H15mm



51574 Meteor Silver



51574-5242
27cm PLATE
D276 • H21mm
51574-5243
23cm PLATE
D233 • H20mm
51574-5244
21cm PLATE
D208 • H15mm
51574-5245
18cm PLATE
D180 • H15mm



51574-2687
TEA CUP
L127 • S107 • H51mm • 230cc
51574-5305
COMMON SAUCER
D166 • H19mm



51574-2703
COFFEE CUP
L113 • S90 • H65mm • 210cc
51574-5305
COMMON SAUCER
D166 • H19mm



51574-2690
ESPRESSO CUP
L90 • S67 • H60mm • 100cc
51574-5315
ESPRESSO SAUCER
D123 • H17mm



51574-3554
16cm BOWL
D165 • H64mm • 700cc



51574-3565
13cm BOWL
D133 • H53mm • 370cc



51574-5304
23cm SOUP BOWL
D233 • H34mm



52194 Meteor Orange



52195 Meteor Purple



52196 Meteor Blue



51300-5621
30cm PLATE
D305 • H17mm
51300-5622
27cm PLATE
D273 • H14mm
51300-5623
21cm PLATE
D217 • H10mm
51300-5597
16cm PLATE
D166 • H14mm



51300-5527
27cm WIDE RIM PLATE
D276 • H23mm



58045-OC5527
27cm WIDE RIM PLATE
D276 • H23mm
<Black Matte&Shiny>



58045-OC5526
27cm PLATE
D276 • H22mm
<Black Matte&Shiny>



51300-5624
23cm RIM SOUP PLATE
D237 • H33mm • 270cc



50763-2710
TEA/COFFEE CUP
L114 • S88 • H65mm • 270cc
51300-5625
TEA/COFFEE SAUCER
D165 • H11mm



50763-2713
ESPRESSO CUP
L88 • S66 • H61mm • 140cc
51300-5660
ESPRESSO SAUCER
D126 • H11mm



51300-5524
27cm SQUARE 4 DIVIDED TRAY
L266 • S266 • H17mm

58045-OC5524
27cm SQUARE 4 DIVIDED TRAY
L266 • S266 • H17mm
<Black Matte&Shiny>



51299-5523
30cm SQUARE 6 DIVIDED TRAY
L300 • S200 • H15mm



51299-5602
16cm SQUARE DIVIDED TRAY
L160 • S80 • H13mm



51300-5525
34cm SQUARE 3 DIVIDED TRAY
L337 • S112 • H16mm



51300-5502
30cm SQUARE DIVIDED TRAY
L300 • S150 • H17mm



51299-5601
8cm SQUARE TRAY
L80 • S80 • H13mm



51299-9798
7cm SMALL STAND
(PLAIN)
L70 • S70 • H24mm



51300-9797
7cm SMALL STAND
(RELIEF)
L68 • S68 • H24mm



50763-5332
30cm PLATE
D302 • H17mm



50763-5333
27cm PLATE
D272 • H16mm



50763-5334
23cm PLATE
D233 • H15mm



50763-5335
21cm PLATE
D214 • H12mm



50763-5336
16cm PLATE
D164 • H12mm



50763-5613
27cm WIDE RIM PLATE
D274 • H24mm



50763-5473
29cm PASTA PLATE
D288 • H53mm



50763-5337
23cm RIM SOUP PLATE
D237 • H33mm



50763-2809
10cm BOWL
(Stackable)(RELIEF)
D101 • H53mm • 310cc



50763-3517
23cm ROUND
VEGETABLE BOWL
D227 • H94mm



50763-5338
14cm BOWL
D141 • H58mm



50763-5944
12cm BOWL
D122 • H50mm



50763-5342
38cm PLATTER
L384 • S280 • H18mm



50763-5532
31cm PLATTER
L310 • S224 • H16mm



50763-9733
23cm BUTTER TRAY
L237 • S141 • H13mm



50763-2710
TEA/COFFEE CUP
L114 • S88 • H65 • 270cc
50763-5563
COMMON SAUCER
D166 • H11mm



50763-2711
TEA CUP
L119 • S97 • H49mm • 240cc
50763-5563
COMMON SAUCER
D166 • H11mm



50763-2713
ESPRESSO CUP
L88 • S66 • H61mm • 140cc
50763-5564
ESPRESSO SAUCER
D127 • H11mm



50763-2807
COFFEE CUP(Stackable)
L106 • S85 • H57 • 200cc
50763-5587
COFFEE SAUCER
D158 • H19mm



50763-4579
TEA POT W/COVER 1,670cc
L304 • S135 • H170mm • 1,670cc



50763-4695
SUGAR BOWL W/COVER 400cc
L125 • S97 • H102mm • 400cc



50763-4578
CREAMER JUG 340cc
L160 • S75 • H78mm • 340cc



50763-2714
MUG
L119 • S92 • H103mm • 430cc

50764(ITEM No.BB) White Matte&Shiny



50763-2712
BOUILLON CUP 350cc
L161 • S122 • H50mm • 350cc
50763-5340
BOUILLON SAUCER
D183 • H12mm



50763-2737
BOUILLON CUP 240cc
L140 • S98 • H49mm • 240cc
50763-5563
COMMON SAUCER
D166 • H11mm



51270-5668
30cm PLATE
D302 • H24mm



51270-5670
27cm PLATE
D273 • H21mm



51270-5576
25cm PLATE
D253 • H19mm



51270-5671
23cm PLATE
D235 • H18mm



51270-5578
21cm PLATE
D215 • H17mm



51270-5579
17cm PLATE
D172 • H13mm



51270-3608
17cm BOWL
D174 • H100mm • 1,500cc



51270-3609
13cm BOWL
D136 • H78mm • 670cc



51270-5669
29cm PASTA PLATE
D288 • H53mm



51270-5580
24cm RIM SOUP PLATE
D240 • H36mm



51270-5581
16cm CEREAL BOWL
D165 • H48mm



51270-5582
15cm FRUIT BOWL
D152 • H32mm



51270-2839
TEA/COFFEE CUP(M)
L124 • S98 • H68mm • 280cc
51270-5672
COMMON SAUCER(M)
D155 • H21mm



51270-2875
ESPRESSO CUP
L83 • S63 • H53mm • 100cc
51270-5584
ESPRESSO SAUCER
D117 • H15mm



51270-2846
CAPPUCCINO CUP
L130 • S105 • H70mm • 370cc
51270-5672
COMMON SAUCER(M)
D155 • H21mm



51270-2847
BOUILLON CUP(M)
L162 • S111 • H68mm • 350cc
51270-5672
COMMON SAUCER(M)
D155 • H21mm



51270-4697
COFFEE POT W/COVER 570cc
L175 • S104 • H128mm • 570cc



51270-4696
TEA POT W/COVER 1,180cc
L248 • S155 • H124mm • 1,180cc



51270-4684
TEA POT W/COVER 660cc
L194 • S120 • H113mm • 660cc



51270-4685
SUGAR BOWL W/COVER(L)
D104 • H104mm • 430cc



51270-4699
CREAMER JUG 310cc
L125 • S95 • H95mm
310cc



51270-4686
CREAMER JUG 180cc
L102 • S70 • H78mm
180cc



51270-4700
SUGAR CONTAINER
L110 • S80 • H53mm • 160cc



51800-5812
27cm RIM PLATE
D278 • H27mm



51800-5822
25cm RIM PLATE
D260 • H24mm



51800-5823
23cm RIM PLATE
D238 • H22mm



51800-5824
21cm RIM PLATE
D215 • H20mm



51800-5825
17cm RIM PLATE
D168 • H16mm



51800-5814
28cm WIDE RIM PLATE
D279 • H34mm



51800-5813
28cm WIDE RIM DEEP PLATE
D277 • H46mm



51800-5821
21cm WIDE RIM SOUP PLATE
D212 • H41mm



51800-5772
29cm PASTA PLATE
D297 • H46mm



51800-5776
24cm RIM SOUP PLATE
D241 • H42mm



51800-3600
17cm BOWL
D169 • H42mm



51800-5818
15cm BOWL
D151 • H32mm



51800-5770
30cm COUPE PLATE
D304 • H25mm



51800-5774
27cm COUPE PLATE
D275 • H22mm



51800-5777
23cm COUPE PLATE
D235 • H20mm



51800-5778
21cm COUPE PLATE
D212 • H18mm



51800-5779
19cm COUPE PLATE
D196 • H16mm



51800-5780
16cm COUPE PLATE
D164 • H17mm



51800-5769
30cm PLATE
D304 • H25mm



51800-5773
27cm PLATE
D275 • H22mm



51800-4710
COFFEE POT
W/COVER 650cc
L186 • S108 • H134mm • 650cc



51800-4687
TEA POT
W/COVER 840cc
L223 • S142 • H108mm • 840cc



51800-4691
SUGAR BOWL
W/COVER 250cc
D96 • H77mm • 250cc



51800-2910
9cm SUGAR BOWL
D90 • H43mm • 160cc



51800-4708
CREAMER JUG 320cc
L108 • S81 • H113mm • 320cc



51800-4692
CREAMER JUG 180cc
L89 • S67 • H93mm • 180cc



51800-36132
COVER FOR SOUP CUP
D125 • H41mm

92626-32681
SOUP CUP
L142 • S121 • H56mm • 340cc



51800-54590
CHAPPEI SET
D102 • H78mm • 210cc

51800-98402
COVER
D85 • H24mm



51800-3602
10cm BOWL
D108 • H54mm • 230cc



51800-3607
9cm BOWL
D96 • H46mm



51800-5781
10cm SAUCE DISH
D105 • H16mm

51800-5793
18cm SAUCER
D178 • H20mm

92626-93391
CHINESE TEA CUP(L)
D98 • H57mm • 210cc

51800-9841
SAUCER
D102 • H24mm

51798(ITEM No.BB) White Matte&Shiny



51998 Gold Line
51913 Platinum Line



51799-2911
COFFEE CUP(PLAIN)
L110 • S89 • H66mm • 210cc
51800-5784
16cm SAUCER
D164 • H19mm



51799-2914
TEA CUP(PLAIN)
L125 • S105 • H56mm • 250cc
51800-5784
16cm SAUCER
D164 • H19mm



51799-2912
ESPRESSO CUP(PLAIN)
L89 • S70 • H57mm • 110cc
51800-5783
13cm SAUCER
D133 • H15mm



51799-2915
CAPPUCCINO CUP(PLAIN)
L137 • S113 • H63mm • 330cc
51800-5784
16cm SAUCER
D164 • H19mm



51799-2903
COFFEE CUP(Stackable/PLAIN)
L105 • S81 • H64mm • 240cc
51800-5784
16cm SAUCER
D164 • H19mm



51799-2913
BOUILLON CUP(PLAIN)
L150 • S110 • H54mm • 260cc
51800-5784
16cm SAUCER
D164 • H19mm



51800-2902
COFFEE CUP
L110 • S89 • H66mm • 210cc
51800-5784
16cm SAUCER
D164 • H19mm



51800-2904
TEA CUP
L125 • S105 • H56mm • 250cc
51800-5784
16cm SAUCER
D164 • H19mm



51800-2901
ESPRESSO CUP
L89 • S70 • H57mm • 110cc
51800-5783
13cm SAUCER
D133 • H15mm



51800-2909
CAPPUCCINO CUP
L137 • S113 • H63mm • 330cc
51800-5784
16cm SAUCER
D164 • H19mm



51800-2907
BOUILLON CUP
L150 • S110 • H54mm • 260cc
51800-5784
16cm SAUCER
D164 • H19mm



51800-2927
MUG
L124 • S92 • H98mm • 410cc



51800-5786
43cm OVAL PLATTER
L440 • S318 • H32mm



51800-5787
38cm OVAL PLATTER
L380 • S270 • H27mm



51800-5788
32cm OVAL PLATTER
L322 • S236 • H24mm



51800-5790
23cm TRAY
L235 • S145 • H17mm



51800-5836
28cm SQUARE TRAY
L278 • S278 • H22mm



51800-5850
24cm SQUARE FLAT TRAY
L240 • S238 • H13mm



51800-5828
28cm OBLONG FLAT TRAY
L280 • S140mm • H13mm



51800-5829
30cm OBLONG RIM TRAY
L299 • S154mm • H21mm



51800-3616
CASSEROLE
W/COVER 3,600cc
L285 • S238 • H160mm • 3,600cc



51800-3617
23cm BOWL
D235 • H89mm



51800-9846
SALT SHAKER
(1HOLE)
L40 • S33 • H93mm



51800-9847
PEPPER SHAKER
(3HOLES)
L40 • S33 • H93mm



51298-5635
31cm PLATE
D312 • H26mm

51298-5636
28cm PLATE
D285 • H26mm

51298-5943
25cm PLATE
D257 • H27mm

51298-5649
23cm PLATE
D233 • H25mm

51298-5638
21cm PLATE
D215 • H20mm

51298-5617
19cm PLATE
D190 • H20mm

51298-5667
16cm PLATE
D165 • H15mm



92626-1231
38cm OVAL COUPE PLATTER
L384 • S275 • H31mm



51298-9807
22cm BUTTER TRAY
L225 • S128 • H17mm



51298-5677
28cm DEEP PLATE
D280 • H62mm



51298-5637
23cm SOUP PLATE
D230 • H46mm



51298-5640
17cm DEEP PLATE
D174 • H39mm



51298-5641
16cm SOUP PLATE
D160 • H32mm



51298-5642
12cm DEEP DISH
D121 • H27mm



51050-3536
28cm SERVING BOWL
D284 • H80mm • 2,750cc



51050-5361
17cm BOWL
D173 • H52mm • 420cc



51298-5650
16cm BOWL
D162 • H55mm • 370cc



51298-3657
14cm DEEP BOWL
D140 • H45mm • 340cc



51298-2831
TEA/COFFEE CUP
L124 • S98 • H68mm • 280cc
8531-1217
16cm SAUCER
D158 • H19mm



51298-2830
ESPRESSO CUP
L83 • S63 • H44 • 80cc
51298-5639
ESPRESSO SAUCER
D120 • H14mm



51050-2759
CAPPUCCINO CUP
L135 • S110 • H63mm • 350cc
8531-1217
16cm SAUCER
D158 • H19mm
9265-1677
18cm SAUCER
D177 • H22mm



51050-2786
CAPPUCCINO CUP
L130 • S105 • H70mm • 370cc
8531-1217
16cm SAUCER
D158 • H19mm



51298-2845
BOUILLON CUP
L162 • S111 • H68mm • 350cc
9265-1677
18cm SAUCER
D177 • H22mm



51298-4662
COFFEE POT
W/COVER 1,700cc
L240 • S140 • H195mm • 1,700cc



51298-4663
TEA POT
W/COVER 1,180cc
L248 • S155 • H124mm • 1,180cc



51298-4664
TEA POT
W/COVER 660cc
L194 • S120 • H113mm • 660cc



51298-4665
COFFEE POT
W/COVER 570cc
L175 • S104 • H128mm • 570cc



51298-4636
SUGAR BOWL
W/COVER 430cc
D104 • H104mm • 430cc



51298-46362
COVER FOR SUGAR BOWL
D70 • H25mm
51298-46821
SUGAR BOWL 215cc
D82 • H65mm • 215cc



51298-46821
SUGAR BOWL 215cc
D82 • H65mm • 215cc



51298-4643
SUGAR CONTAINER
L110 • S80 • H53mm • 160cc



51298-4637
CREAMER JUG
310cc
L125 • S84 • H95mm • 310cc



51298-4642
CREAMER JUG
180cc
L102 • S70 • H78mm • 180cc



51050-3572
25cm ROUND BOWL
D252 • H120mm • 3,720cc



51050-3578
22cm ROUND BOWL
D221 • H114mm • 2,660cc



51050-3552
17cm ROUND BOWL
D174 • H100mm • 1,500cc



51050-3571
13cm ROUND BOWL
D136 • H78mm • 670cc



51050-35662
COVER FOR 14cm BOWL
D153 • H56mm
51050-3566
14cm ROUND BOWL
D145 • H91mm • 940cc



51050-35382
COVER FOR 12cm BOWL
D122 • H41mm
51050-35381
12cm ROUND BOWL
D117 • H68mm • 470cc
8531-1218
18cm SAUCER
D177 • H22mm



51050-35642
COVER FOR 11cm BOWL
D110 • H39mm
51050-35641
11cm ROUND BOWL
D105 • H70mm • 370cc



51050-35832
COVER FOR 10cm BOWL
D102 • H39mm
51050-35831
10cm ROUND BOWL
D98 • H67mm • 260cc



51298-2823
MUG
L130 • S93 • H95mm • 460cc
8531-1217
16cm SAUCER
D158 • H19mm

TASTE OF EAST

The designs inspired by locally unique culture and traditions, re-edited to fit contemporary dining.







92626-1536
42cm ROUND COUPE PLATE
D426 · H43mm



92626-1074
38cm ROUND COUPE PLATE
D385 · H38mm



92626-1537
35cm ROUND COUPE PLATE
D344 · H32mm



92626-1232
31cm ROUND COUPE PLATE
D309 · H32mm



92626-1223
27cm ROUND COUPE PLATE
D269 · H23mm



92626-1598
25cm ROUND COUPE PLATE
D256 · H26mm



92626-1288
23cm ROUND COUPE PLATE
D228 · H22mm



92626-1643
21cm ROUND COUPE PLATE
D213 · H21mm



92626-1224
19cm ROUND COUPE PLATE
D193 · H21mm



92626-1225
16cm ROUND COUPE PLATE
D167 · H17mm



92626-1599
14cm ROUND COUPE PLATE
D139 · H20mm



92626-1313
12cm ROUND COUPE PLATE
D128 · H18mm



92626-1597
10cm ROUND COUPE PLATE
D103 · H21mm



92626-9277
9cm ROUND COUPE PLATE
D95 · H14mm



92626-1842
36cm ROUND COUPE PLATE DEEP
D361 · H51mm



92626-1843
32cm ROUND COUPE PLATE DEEP
D320 · H48mm



92626-1844
27cm ROUND COUPE PLATE DEEP
D275 · H44mm



92626-1845
25cm ROUND COUPE PLATE DEEP
D259 · H40mm



92626-1926
23cm ROUND COUPE PLATE DEEP
D231 · H28mm



92626-1144
21cm ROUND COUPE PLATE DEEP
D215 · H34mm



92626-1226
19cm COUPE SOUP PLATE
D196 · H34mm · 590cc



92626-1041
16cm FRUIT BOWL
D164 · H33mm



92626-1227
14cm FRUIT BOWL
D143 · H31mm



92626-1063
50cm OVAL COUPE PLATTER
L505·S345·H43mm



92626-1230
43cm OVAL COUPE PLATTER
L438·S316·H33mm



92626-1231
38cm OVAL COUPE PLATTER
L384·S275·H31mm



92626-1538
30cm OVAL COUPE PLATTER
L309·S227·H26mm



92626-1539
25cm OVAL COUPE PLATTER
L258·S185·H27mm



92626-1540
23cm OVAL COUPE PLATTER
L235·S159·H23mm



92626-1877
35cm DEEP OVAL PLATTER
L354·S263·H29mm



92626-1757
47cm OVAL RIM PLATTER
L475·S345·H46mm



92626-1759
35cm OVAL RIM PLATTER
L357·S262·H37mm



92626-1761
25cm OVAL RIM PLATTER
L254·S193·H30mm



92626-1881
18cm OVAL RIM PLATTER
L180·S130·H24mm

92626-1802
40cm OVAL RIM PLATTER
L405·S288·H42mm

92626-1760
30cm OVAL RIM PLATTER
L305·S220·H32mm

92626-1042
23cm OVAL RIM PLATTER
L229·S172·H27mm



92626-3293
25cm SOUP BOWL
D252·H90mm·2,500cc



92626-3294
23cm SOUP BOWL
D232·H82mm·1,990cc



92626-3295
20cm SOUP BOWL
D197·H71mm·1,290cc



92626-3221
19cm NOODLE BOWL
D191·H70mm·1,120cc



92626-1578
16cm SOUP BOWL
D160·H56mm·660cc



92626-3508
12cm ALL PURPOSE BOWL
D121·H46mm·300cc

CHINESE



92626-51158
CHAPPEI(L)

92626-93392
COVER
D85-H23mm

92626-93391
CHINESE TEA CUP(L)
D98-H57mm-210cc

92626-9416
CHAPPEI SAUCER
D102-H24mm



92626-54633
CHAPPEI(L)

92626-98792
COVER
D85-H29mm

92626-93391
CHINESE TEA CUP(L)
D98-H57mm-210cc

92626-9416
CHAPPEI SAUCER
D102-H24mm



92626-20903
CHAPPEI(M)

92626-95182
COVER
D72-H12mm

92626-95181
CHINESE TEA CUP(M)
D83-H50mm-160cc

92626-9416
CHAPPEI SAUCER
D102-H24mm



92626-51202
CHAPPEI(S)

92626-94442
COVER
D65-H12mm

92626-94441
CHINESE TEA CUP(S)
D74-H44mm-110cc

92626-94444
CHAPPEI SAUCER
D95-H16mm



92626-54711
CHAPPEI(S)

92626-29762
COVER
D74-H28mm

92626-29761
CHINESE TEA CUP(S)
D89-H52mm-130cc

92626-5975
CHAPPEI SAUCER
D87-H18mm



92626-3268
SOUP CUP W/COVER(L)
L142-S121-H93mm-340cc

92626-1218
SAUCER
D177-H22mm

92626-5329
SAUCER
(REINFORCED EDGE)
D177-H22mm



92626-3328
SOUP CUP W/COVER(S)
L142-S121-H62mm-300cc

92626-1218
SAUCER
D177-H22mm



92626-32682
COVER FOR SOUP CUP
D121-H40mm

92626-3641
SOUP CUP
WITHOUT HANDLE
D121-H56mm-340cc

92626-1218
SAUCER
D177-H22mm



51050-35642
COVER FOR 11cm BOWL
D110-H39mm

51050-36301
11cm SOUP BOWL
L132-S105-H70mm-360cc

8531-1217
16cm SAUCER
D158-H19mm



92626-3601
SOUP BOWL W/COVER 570cc
L150-S121-H147mm-570cc

92626-1218
SAUCER
D177-H22mm



92626-1762
13cm PORRIDGE BOWL
D127-H56mm-390cc



92626-1763
12cm NOODLE SOUP BOWL
D117-H51mm-260cc



92626-1913
11cm RICE BOWL
D118-H57mm-330cc



52090-3637
11cm BOWL
D113-H57mm-310cc



92626-1541
10cm RICE BOWL
D106-H50mm-240cc



92626-3662
10cm SHALLOW BOWL
D104-H43-190cc



92626-5170
10cm BOWL
D99-H45mm-195cc



92626-1765
9cm SHARK'S FIN BOWL
D97-H44mm-170cc



92626-1659
12cm SAUCE DISH DEEP
D120-H20mm



92626-1882
10cm SAUCE DISH DEEP
D105-H29mm



9795-5933
10cm SAUCE DISH
D105-H25mm



92626-1690
7cm SAUCE DISH
D71-H20mm-40cc



9795-9380
DIVIDED DISH
L150-S102-H28mm



92626-9428
DIVIDED DISH
L87-S87-H19mm



92626-9780
ROUND DIVIDED DISH
(Stackable)
D95-H20mm



51298-9810
CHOPSTICKS &
SPOON REST
L130-S42-H12mm



92626-9834
CHOPSTICKS &
SPOON REST
L103-S36-H10mm



92626-9468
CHOPSTICKS &
SPOON REST
L110-S55-H15mm



92626-9334
CHOPSTICKS REST
L61-S18-H12mm



8531-9286
NAPKIN RING
L48-S24-H42mm



92626-4266
SAMSHU POT 400cc
L135-S73-H189mm-400cc

92626-4313
SAMSHU POT 240cc
L127-S66-H157mm-240cc



92626-2318
SAMSHU CUP(L)
D63-H46mm-70cc



92626-2977
SMALL CUP
D56-H29mm-30cc



92626-9338
SAMSHU CUP
D61-H33mm-40cc



92626-9832
CHINESE WINE CUP
D40-H82mm-25cc



92626-9321
SPOON(L)
L138 · S45 · H50mm
<For Home Use>



92626-9382
SPOON(S)
L124 · S45 · H43mm
<For Home Use>



92626-9548
SPOON(L)
L140 · S45 · H47mm



92626-9549
SPOON(S)
L130 · S46 · H40mm



92626-9884
SPOON
L155 · S41 · H45mm



51298-9808
SPOON
L175 · S40 · H28mm



92626-9322
SPOON HOLDER (L)
L84 · S57 · H25mm



92626-9505
SPOON HOLDER (S)
L75 · S55 · H20mm



9265-9453
LADLE
L172 · S63mm



92626-3212
SOUP TUREEN(L)
L332 · S254 · H228mm · 4,700cc



92626-3225
SOUP TUREEN(S)
L292 · S215 · H179mm · 2,830cc



92626-3286
SOUP TUREEN(L)
L303 · S254 · H228mm · 4,700cc



92626-3288
SOUP TUREEN(S)
L252 · S215 · H179mm · 2,830cc



92626-3387
CASSEROLE W/COVER(12-P)
D270 · H136mm · 3,140cc



92626-3255
CASSEROLE W/COVER(10-P)
D246 · H108mm · 1,700cc



92626-3303
CASSEROLE W/COVER(6-P)
D223 · H99mm · 1,240cc



92626-3256
CASSEROLE W/COVER(4-P)
D198 · H93mm · 810cc



9265-1986
29cm FLAT PLATE
D288 · H17mm




92626-1866
26cm FLAT PLATE
D259 · H14mm



92626-1102
23cm FLAT PLATE
D230 · H8mm



92626-5270
27cm SQUARE PLATE
L275 · S275 · H 29mm



92626-530
25cm OBLONG COUPE PLATE
L251 · S195 · H25mm

CHINESE



51290-54314
TEA POT W/COVER 1,070cc
L165-S125-H129mm-1,070cc



51290-54313
SOUP BOWL W/COVER 360cc
L104-S102-H79mm-360cc



51290-9801
WARMER FOR SOUP BOWL
L118-S116-H51mm



92626-4294
CHINESE TEA POT 1,570cc
L212-S121-H194mm-1,570cc



92626-4295
CHINESE TEA POT 1,130cc
L200-S119-H163mm-1,130cc



92626-4337
CHINESE TEA POT 1,060cc
L232-S149-H99mm-1,060cc



51050-4627
TEA POT W/COVER 1,060cc
L232-S149-H124mm-1,060cc



92626-93391
CHINESE TEA CUP(L)
D98-H57mm-210cc



92626-2319
CHINESE TEA CUP
D81-H58mm-170cc



92626-2660
ARABIC COFFEE CUP
D67-H45mm-60cc



92626-2391
TEA CUP
L100-S77-H56mm-160cc
9795-1453
SAUCER
D125-H20mm



9795-9484
15cm CASTER TRAY
L153-S88-H10mm



50481-3573
15cm OBLONG TRAY
L154-S83-H15mm



92626-9515
25cm CASTER TRAY
(3 PORTIONS)
L248-S83-H15mm



92626-9977
18cm CASTER TRAY
(2 PORTIONS)
L181-S82-H16mm



9265-9905
TOOTHPICK HOLDER
D42-H60mm



92626-9323
TOOTHPICK HOLDER
D54-H46mm



92626-331
MUSTARD POT
D68-H40mm-60cc



92626-4267S (醬油)
92626-4267SC (醬油)
92626-4267SE (S)
SOYA CONTAINER
L90-S73-H102mm-120cc
92626-4267R (辣油)
92626-4267RE (O)
OIL CONTAINER
L90-S73-H102mm-120cc
92626-4267V (醋)
92626-4267VC (醋)
92626-4267VE (V)
VINEGAR CONTAINER
L90-S73-H102mm-120cc



92626-4461S
SOYA CONTAINER
L107-S58-H105mm-110cc

92626-4461R
OIL CONTAINER
L107-S58-H105mm-110cc

92626-4461V
VINEGAR CONTAINER
L107-S58-H105mm-110cc



92626-4476S
SOYA CONTAINER
L86-S55-H74mm-60cc

92626-4476R
OIL CONTAINER
L86-S55mm-H74mm-60cc

92626-4476V
VINEGAR CONTAINER
L86-S55-H74mm-60cc



92626-4340
SOYA/VINEGAR POT
D71-H118mm-140cc

The items on this page are engineered for maximum thickness of the body and feature rolled and reinforced edges. They exhibit the highest standards of durability and edge-chipping resistance that are demanded by the operating pressures of the busiest catering facilities.



92626-1172
42cm ROUND
COUPE PLATE(B)
D428 • H42mm

92626-1173
35cm ROUND
COUPE PLATE(B)
D354 • H35mm

92626-1174
31cm ROUND
COUPE PLATE(B)
D312 • H31mm



92626-1175
27cm ROUND
COUPE PLATE(B)
D275 • H28mm

92626-1176
25cm ROUND
COUPE PLATE(B)
D253 • H25mm

92626-1177
23cm ROUND
COUPE PLATE(B)
D235 • H23mm



92626-1178
21cm ROUND
COUPE PLATE(B)
D214 • H22mm

92626-1179
19cm ROUND
COUPE PLATE(B)
D196 • H20mm

92626-1180
16cm ROUND
COUPE PLATE(B)
D165 • H20mm



92626-1181
14cm ROUND
COUPE PLATE(B)
D146 • H20mm

92626-1182
12cm ROUND
COUPE PLATE(B)
D123 • H20mm

92626-1183
10cm ROUND
COUPE PLATE(B)
D103 • H19mm



92626-5002
36cm ROUND
COUPE PLATE DEEP(B)
D360 • H52mm

92626-5003
32cm ROUND
COUPE PLATE DEEP(B)
D325 • H48mm

92626-5004
27cm ROUND
COUPE PLATE DEEP(B)
D276 • H45mm



92626-5005
25cm ROUND
COUPE PLATE DEEP(B)
D256 • H40mm

92626-5006
23cm ROUND
COUPE PLATE DEEP(B)
D238 • H37mm



92626-5011
43cm OVAL
COUPE PLATTER(B)
D435 • S310 • H35mm

92626-5012
38cm OVAL
COUPE PLATTER(B)
D382 • S272 • H31mm

92626-5013
30cm OVAL
COUPE PLATTER(B)
D304 • S215 • H28mm



92626-5014
25cm OVAL
COUPE PLATTER(B)
D256 • S181 • H23mm

92626-5015
23cm OVAL
COUPE PLATTER(B)
D235 • S165 • H22mm



92626-3379
21cm NOODLE
BOWL(B)
D213 • H82mm • 1,370cc



92626-3380
19cm NOODLE
BOWL(B)
D193 • H72mm • 1,100cc



92626-1184
13cm PORRIDGE
BOWL(B)
D133 • H60mm • 400cc



92626-1185
12cm NOODLE
SOUP BOWL(B)
D123 • H55mm • 290cc



92626-1186
11cm RICE BOWL(B)
D115 • H60mm • 300cc



92626-1187
10cm RICE BOWL(B)
D107 • H55mm • 260cc



92626-1188
9cm SHARK'S
FIN BOWL(B)
D97 • H46mm • 160cc



92626-1198
14cm FRUIT BOWL(B)
D143 • H31mm



92626-2572
CHINESE TEA CUP(B)
D84 • H57mm • 170cc



92626-9548
SPOON(L)
L140 • S45 • H47mm



92626-9549
SPOON(S)
L130 • S46 • H40mm

PATTERN VARIATIONS



51618 Golden Stroke
52006 Silver Stroke



50762 Gold Line
50771 Platinum Line



51349 Ensemble



50796 Gold Band
50822 Platinum Band



51802 Gold Line
51302 Platinum Line



51733 Pink Rose



51694 Pearl Diamond Mosaic



51473 Miko



52170 Galaxy Gold



50584 Laetitia



96760 Cottonrose Orange



96761 Cottonrose Blue



52100-5864
31cm OCTAGONAL PLATE
L312 · S279 · H23mm

52100-5865
29cm OCTAGONAL PLATE
L293 · S260 · H22mm

52100-5866
25cm OCTAGONAL PLATE
L244 · S217 · H19mm

52100-5867
23cm OCTAGONAL PLATE
L227 · S202 · H17mm

52100-5868
21cm OCTAGONAL PLATE
L209 · S186 · H18mm

52100-5869
18cm OCTAGONAL PLATE
L182 · S162 · H16mm



52100-5874
29cm ROUND PLATE
D296 · H22mm

52100-5875
27cm ROUND PLATE (SHALLOW)
D275 · H22mm

52100-5876
27cm ROUND PLATE (DEEP)
D277 · H28mm

52100-5878
23cm ROUND PLATE
D230 · H20mm

52100-5880
21cm ROUND PLATE
D212 · H20mm

52100-5881
19cm ROUND PLATE
D190 · H19mm

52100-5882
16cm ROUND PLATE
D166 · H16mm



52100-5886
29cm ROUND PLATE
(WITHOUT FRAME)
D295 · H23mm



52100-5877
25cm DEEP PLATE
D251 · H43mm




52100-5885
19cm ROUND STEP PLATE
D191 · H19mm



52100-5901
31cm OCTAGONAL FLAT PLATE
(WITHOUT FRAME)
L312 · S279 · H14mm



52100-5879
22cm SOUP PLATE
D222 · H48mm





52193 Sui



52100-4719
TEA POT W/COVER
900cc
L215 • S138 • H104mm • 900cc



52100-54653
CHAPPEI SET
52100-29452
COVER
D86 • H26mm
52100-29451
CHAPPEI CUP
D98 • H58mm • 200cc
52100-5870
SAUCER (OCTAGONAL)
L114 • S100 • H17mm



52100-54654
CHAPPEI SET
52100-29452
COVER
D86 • H26mm
52100-29451
CHAPPEI CUP
D98 • H58mm • 200cc
52100-5883
SAUCER (ROUND)
D108 • H18mm



52100-2952
TEA CUP
L108 • S90 • H63mm • 150cc
52100-5927
TEA SAUCER
(OCTAGONAL)
L136 • S120 • H17mm



52100-2952
TEA CUP
L108 • S90 • H63mm • 150cc
52100-5928
TEA SAUCER
(ROUND)
D125 • H15mm



52100-54635
SOUP CUP W/COVER
L142 • S121 • H87mm • 340cc
52100-36402
COVER FOR SOUP CUP
D124 • H36mm
92626-32681
SOUP CUP
L142 • S121 • H56mm • 340cc
92626-1218
SAUCER
D177 • H22mm



52100-54641
SOUP CUP W/COVER
WITHOUT HANDLE
L124 • H87mm • 340cc
52100-36402
COVER FOR SOUP CUP
D124 • H36mm
92626-3641
SOUP CUP
WITHOUT HANDLE
D121 • H56mm • 340cc
92626-1218
SAUCER
D177 • H22mm



52100-5871
10cm SAUCE DISH
(OCTAGONAL)
L105 • S94 • H20mm
52100-5872
9.5cm SAUCE DISH
(OCTAGONAL)
L95 • S85 • H22mm



52100-5884
8cm SAUCE DISH
(ROUND)
D80 • H22mm



52100-3639
10cm RICE BOWL
D108 • H56mm • 230cc



52100-5873
26cm TRAY
L262 • S91 • H14mm

OPERA



50827-5362
30cm PLATE
L302 • S300 • H18mm



51303 Opera Gold



50853 Opera Platinum

50827-5363
27cm PLATE
L276 • S276 • H16mm

50827-5365
23cm PLATE
L235 • S235 • H15mm

50827-5366
21cm PLATE
L215 • S215 • H12mm

50827-5367
17cm PLATE
L169 • S168 • H12mm



50827-5364
25cm PASTA PLATE
L258 • S255 • H26mm



50827-5407
23cm SOUP PLATE
L238 • S235 • H38mm



50763-2710
TEA/COFFEE CUP
L114 • S88 • H65mm • 270cc
50827-5368
COMMON SAUCER
D159 • H18mm



50763-2711
TEA CUP
L119 • S97 • H49mm • 240cc
50827-5368
COMMON SAUCER
D159 • H18mm



50763-2713
ESPRESSO CUP
L88 • S66 • H61mm • 140cc
50827-5370
ESPRESSO SAUCER
D125 • H20mm



50763-2712
BOUILLON CUP 350cc
L161 • S122 • H50mm • 350cc
50827-5369
BOUILLON SAUCER
D171 • H18mm



50763-2737
BOUILLON CUP 240cc
L140 • S98 • H49mm • 240cc
50827-5368
COMMON SAUCER
D159 • H18mm



50827-4604
TEA POT W/COVER 1,670cc
L304 • S135 • H170mm • 1,670cc



50827-4583
COFFEE POT W/COVER 810cc
L233 • S96 • H162mm • 810cc



50827-4601
TEA POT W/COVER 500cc
L210 • S97 • H120mm • 500cc



50827-4671
SUGAR BOWL W/COVER 400cc
L125 • S97 • H102mm • 400cc



50827-45842
COVER FOR
SUGAR BOWL
L100 • S85 • H42mm
50827-45841
SUGAR BOWL 300cc
L97 • S80 • H62mm • 300cc



50827-45882
COVER FOR
7cm PETIT BOWL
L77 • S67 • H33mm
50827-45881
7cm PETIT BOWL 100cc
L73 • S62 • H43mm • 100cc



50827-4603
CREAMER JUG 340cc
L160 • S73 • H83mm • 340cc



50827-4585
CREAMER JUG 170cc
L127 • S66 • H70mm • 170cc



50827-4589
CREAMER JUG 100cc
L89 • S62 • H43mm • 100cc



50481-5318
31cm SQUARE PLATE
D379 • L310 • S310 • H41mm



50481-5183
20cm SQUARE PLATE
D245 • L199 • S199 • H22mm



50481-5321
23cm SQUARE PASTA PLATE
D289 • L235 • S235 • H47mm

50481-5182
27cm SQUARE PLATE
D324 • L269 • S269 • H37mm

50481-5263
17cm SQUARE PLATE
D210 • L176 • S176 • H21mm

50481-5320
24cm SQUARE PLATE
D292 • L240 • S240 • H32mm

50481-5289
14cm SQUARE PLATE
D169 • L141 • S141 • H24mm



50481-5290
43cm RECTANGLE PLATTER
L434 • S330 • H35mm



50481-9694
23cm RECTANGLE TRAY
L230 • S130 • H24mm



50481-9736
32cm OBLONG TRAY
L318 • S88 • H22mm

50481-5186
33cm RECTANGLE PLATTER
L338 • S265 • H32mm

50481-5185
31cm SQUARE PLATTER
D385 • L310 • S310 • H31mm



50481-3410
24cm SQUARE BOWL
D283 • L238 • S238 • H74mm



50481-3481
21cm SQUARE BOWL
D227 • L210 • S210 • H72mm



50481-3411
18cm SQUARE BOWL
D208 • L180 • S180 • H50mm



50481-3409
15cm SQUARE BOWL
D183 • L155 • S155 • H66mm



50481-3414
13cm SQUARE BOWL
D156 • L133 • S133 • H60mm



50481-3480
11cm SQUARE BOWL
D129 • L107 • S107 • H50mm



50481-3502
6cm SQUARE BOWL
D75 • L64 • S64 • H30mm



50481-2824
13cm SQUARE SOUP BOWL
D156 • L136 • S136 • H53mm



50481-5401
15cm SQUARE BOWL
D163 • L145 • S145 • H39mm

50481-5614
18cm SAUCER
D215 • L183 • S183 • H16mm



50481-2663
BREAKFAST CUP
L135 • S108 • H74mm • 450cc



50481-2652
TEA/COFFEE CUP
L108 • S88 • H58mm • 240cc




50481-2634
ESPRESSO CUP
L80 • S60 • H55mm • 100cc

50481-5262
BREAKFAST SAUCER
D212 • L177 • S177mm • H19mm

50481-5230
TEA/COFFEE SAUCER
D176 • L148 • S148 • H22mm

50481-5194
ESPRESSO SAUCER
D150 • L126 • S126 • H20mm



L = Long Length
S = Short Length
H = Height
D = Diameter



50983 DICE



50983-5467
30cm PLATE
D302 • H18mm

50983-5417
27cm PLATE
D272 • H16mm

50983-5419
21cm PLATE
D214 • H12mm

50983-5425
16cm PLATE
D164 • H12mm



50983-5418
23cm ACCENT PLATE
D233 • H15mm



50983-5673
29cm PASTA PLATE
D290 • H46mm



50983-5420
23cm RIM SOUP PLATE
D237 • H33mm

50945 HAMMER



50945-5377
32cm PLATE
D320 • H29mm

50945-5355
28cm PLATE
D282 • H24mm

50945-5356
21cm PLATE
D213 • H20mm

50945-5357
17cm PLATE
D173 • H16mm



50945-5469
21cm ACCENT PLATE
(ALLOVER RELIEF)
D213 • H20mm

51031 BEAT



51031-5503
30cm CAT'S EYE PLATE
D300 • H20mm



51031-5505
30cm PLATE
L303 • S264 • H24mm



51031-5538
29cm DEEP PLATE
L289 • S256 • H44mm



51031-5536
16cm PLATE
L162 • S150 • H13mm



51031-5702
38cm PLATTER
L383 • S241 • H27mm



51031-5700
27cm PLATTER
L275 • S171 • H15mm



51031-5698
37cm OVAL TRAY
L371 • S114 • H12mm

51031-5701
32cm PLATTER
L327 • S207 • H23mm

51031-5699
23cm TRAY
L235 • S143 • H15mm

51031-5539
33cm OVAL TRAY
L329 • S114 • H17mm

50617 OVAL



50617-5295
32cm OVAL PLATE
L318 • S289 • H28mm



50617-5301
30cm OVAL PLATE
L297 • S262 • H40mm



50617-5298
28cm TEARDROP DEEP PLATE
L285 • S253 • H58mm



50617-5300
28cm TEARDROP PLATE
L280 • S253 • H28mm

50617-5296
28cm OVAL PLATE
L280 • S250 • H22mm

50617-5302
17cm OVAL PLATE
L175 • S152 • H25mm

50617-5299
21cm TEARDROP DEEP PLATE
L212 • S183 • H40mm

50617-5297
20cm OVAL PLATE
L204 • S183 • H15mm



50617-3487
25cm TEARDROP TRAY
L252 • S158 • H21mm



50617-3488
18cm TEARDROP BOWL
L185 • S152 • H62mm



50617-3489
16cm TEARDROP BOWL
L165 • S117 • H64mm



50617-5303
20cm OVAL DEEP PLATE
L200 • S175 • H47mm



50617-3563
30cm TEARDROP BOWL
L300 • S187 • H46mm



50617-3486
30cm TEARDROP BOWL
L300 • S187 • H46mm



9265-1876
30cm PLATE
D308 • H29mm



9265-1671
27cm PLATE
D269 • H21mm



9265-1672
25cm PLATE
D256 • H21mm



9265-1673
23cm PLATE
D236 • H21mm



9265-1674
20cm PLATE
D200 • H19mm



9265-1905
18cm PLATE
D182 • H19mm



9265-1675
16cm PLATE
D167 • H17mm



9265-1906
14cm PLATE
D142 • H16mm



9795-1024
24cm PASTA PLATE
D240 • H47mm



9795-1644
23cm RIM SOUP PLATE
D234 • H35mm • 300cc



9265-1099
19cm MEZZA BOWL
D191 • H44mm • 380cc



9265-1963
16cm MEZZA BOWL
D161 • H43mm



9265-1723
16cm CEREAL BOWL
D167 • H45mm



9265-1746
15cm PORRIDGE BOWL
D153 • H44mm



9265-2435
AMERICAN COFFEE CUP
L119 • S92 • H75mm • 270cc
9265-1720
COMMON SAUCER
D155 • H21mm



9265-2369
COFFEE CUP
L103 • S81 • H67mm • 190cc
9265-1720
COMMON SAUCER
D155 • H21mm



9265-2370
TEA CUP
L119 • S96 • H51mm • 210cc
9265-1720
COMMON SAUCER
D155 • H21mm



9265-2382
TEA/COFFEE CUP
L116 • S94 • H59mm • 230cc
9265-1720
COMMON SAUCER
D155 • H21mm



9265-2372
ESPRESSO CUP
L84 • S67 • H54mm • 100cc
9265-1721
ESPRESSO SAUCER
D123 • H17mm



9265-4336
COFFEE POT
W/COVER 1,100cc
L207 • S109 • H180mm • 1,100cc



9265-4326
COFFEE POT
W/COVER 500cc
L165 • S92 • H118mm • 500cc



9265-4328
TEA POT
W/COVER 840cc
L200 • S121 • H124mm • 840cc



9265-4327
TEA POT
W/COVER 540cc
L175 • S106 • H107mm • 540cc



9265-4325
SUGAR BOWL
W/COVER
D95 • H85mm • 330cc



9265-4324
CREAMER
JUG 230cc
L98 • S72 • H81mm • 230cc



9265-4323
CREAMER
JUG 160cc
L89 • S67 • H70mm • 160cc



9265-2371
BOILLON CUP
L151 • S109 • H49mm • 270cc
9265-1677
18cm SAUCER
D177 • H22mm



50690 Gold Pia




50689 Esmeralda



51398 Gold Embossment
51399 Platinum Embossment



52142 Jupiter's Ring



8531-5379
30cm BOWL
D299 • H68mm



8531-3402
26cm BOWL
D254 • H67mm



8531-5134
21cm BOWL
D214 • H48mm



8661 Sharilamoon



8720 Esperar



51651 Esperar Champagne Gold



51220 Blooming Rosy Lane



51408 Lotus Gold
51213 Lotus Platinum



8740-1136
30cm PLATE
D309 • H30mm



8740-1120
27cm PLATE
D276 • H31mm
8740-5820
27cm PLATE (SHALLOW)
D277 • H25mm



8740-1131
25cm PLATE
D253 • H27mm



8740-1121
23cm PLATE
D233 • H24mm
8740-1122
21cm PLATE
D218 • H24mm



8740-1138
19cm PLATE
D196 • H22mm
8740-1123
17cm PLATE
D177 • H19mm



8740-2540
COFFEE CUP
L113 • S84 • H63mm • 210cc
8740-1128
COMMON SAUCER
D159 • H23mm



8740-2541
TEA CUP
L121 • S97 • H60mm • 230cc
8740-1128
COMMON SAUCER
D159 • H23mm



8740-2548
ESPRESSO CUP
L91 • S67 • H60mm • 110cc
8740-1132
ESPRESSO SAUCER
D108 • H16mm



8740-2549
BOUILLON CUP
L131 • S109 • H54mm • 290cc
8740-1128
COMMON SAUCER
D159 • H23mm



8740-4486
COFFEE POT
W/COVER 1,350cc
L272 • S132 • H202mm • 1,350cc



8740-4472
TEA/COFFEE POT
W/COVER 960cc
L247 • S122 • H183mm • 960cc



8740-4475
TEA POT
W/COVER 600cc
L217 • S120 • H140mm • 600cc



8740-4471
SUGAR BOWL
W/COVER 290cc
L150 • S104 • H113mm • 290cc



8740-4470
CREAMER JUG 170cc
L120 • S70 • H80mm • 170cc



8740-4723
CREAMER JUG 170cc
L84 • S70 • H80mm • 170cc



8740-36592
COVER FOR 30cm PLATE
D217 • H111mm



8740-36602
COVER FOR 25cm MUFFIN DISH
D176 • H104mm



8740-36562
COVER FOR 12cm BOWL
D122 • H51mm

8740-1136
30cm PLATE
D309 • H30mm

9795-32704
25cm MUFFIN DISH
D258 • H33mm

51050-35381
12cm ROUND BOWL
D117 • H68mm • 470cc

8531-1218
18cm SAUCER
D177 • H22mm



8740-1171
23cm RIM SOUP PLATE
D240 • H35mm • 350cc



8740-1124
20cm COUPE SOUP BOWL
D206 • H35mm • 570cc



8740-1125
15cm FRUIT BOWL
D150 • H29mm



8740-1133
17cm BOWL
D168 • H42mm



52480-9314
SALT SHAKER
(3HOLES)
L53 • S40 • H72mm



52480-9313
PEPPER SHAKER
(5HOLES)
L53 • S40 • H72mm



8740-1126
41cm OVAL PLATTER
L408 • S288 • H31mm

8740-1167
38cm OVAL PLATTER
L382 • S270 • H35mm



8740-1170
23cm BUTTER TRAY
L244 • S146 • H21mm



8740-3337
23cm SALAD BOWL
L272 • S233 • H91mm • 1,980cc



8740-3375
CASSEROLE W/COVER
L335 • S251 • H197mm • 3,615cc



8967 Remembrance



8128 Solaria



8968 Simply Gold
51244 Simply Platinum



8969-1747
27cm PLATE
D270 • H27mm



8969-1748
23cm PLATE
D236 • H23mm



8969-1749
20cm PLATE
D200 • H20mm



8969-1750
17cm PLATE
D168 • H18mm



8969-2376
TEA CUP
L112 • S89 • H69mm • 200cc
8969-1730
TEA/COFFEE SAUCER
D147 • H19mm



8969-2385
ESPRESSO CUP
L90 • S69 • H62mm • 120cc
8969-1751
ESPRESSO SAUCER
D128 • H18mm



8969-2397
BOUILLON CUP
L159 • S122 • H63mm • 350cc
8969-1783
17cm SAUCER
D172 • H23mm



8969-2596
COFFEE CUP
L106 • S84 • H68mm • 200cc
8969-1730
TEA/COFFEE SAUCER
D147 • H19mm



8969-2944
ESPRESSO CUP
L86 • S67 • H53mm • 100cc
8969-1751
ESPRESSO SAUCER
D128 • H18mm



8969-2943
CAPPUCCINO CUP
L121 • S96 • H71mm • 280cc
8969-1783
17cm SAUCER
D172 • H23mm



8969-4338
TEA/COFFEE POT
W/COVER 1,200cc
L259 • S192 • H156mm • 1,200cc



8969-4334
SUGAR BOWL
W/COVER 140cc
L117 • S85 • H93mm • 140cc



8969-4722
SUGAR BOWL
140cc
L117 • S85 • H59mm • 140cc



8969-4333
CREAMER JUG
100cc
L113 • S55 • H82mm • 100cc



8969-2954
MUG
L132 • S103 • H100mm • 490cc



8969-3261
CASSEROLE W/COVER
L299 • S200 • H168mm • 2,000cc



8969-3259
23cm ROUND
VEGETABLE BOWL
D230 • H62mm



8969-5533
RICE BOWL
D119 • H57mm • 310cc



8969-52217
SALT&PEPPER SHAKER
8969-9426
SALT SHAKER(3HOLES)
L42 • S36 • H78mm
8969-9427
PEPPER SHAKER(5HOLES)
L42 • S36 • H78mm



8969-1752
19cm COUPE SOUP BOWL
D201 • H38mm



8969-1753
15cm FRUIT BOWL
D153 • H23mm



8969-1784
42cm OVAL PLATTER
L419 • S289 • H34mm



8969-1785
38cm OVAL PLATTER
L377 • S259 • H27mm



8969-1786
32cm OVAL PLATTER
L324 • S221 • H25mm



8969-1887
23cm BUTTER TRAY
L243 • S148 • H24mm



52480-1436
27cm PLATE
D273 • H26mm



52480-1412
23cm PLATE
D234 • H22mm



52480-1410
19cm PLATE
D196 • H21mm



52480-1413
17cm PLATE
D175 • H20mm



52480-1506
23cm RIM SOUP PLATE
D235 • H36mm • 290cc



52480-2229
TEA CUP
L128 • S100 • H67mm • 210cc
52480-1394
16cm SAUCER
D162 • H19mm



52480-2455
COFFEE CUP
L118 • S92 • H72mm • 210cc
52480-1394
16cm SAUCER
D162 • H19mm



52480-332
10cm PETIT TRAY
L108 • S96 • H20mm



52480-329
23cm TRAY
L230 • S122 • H24mm



52480-9313
PEPPER SHAKER(5HOLES)
L53 • S40 • H72mm
52480-9314
SALT SHAKER(3HOLES)
L53 • S40 • H72mm



9072-1544
27cm PLATE
D266-H22mm



9072-1525
23cm PLATE
D234-H25mm



9072-1526
19cm PLATE
D197-H22mm



9072-1527
16cm PLATE
D169-H19mm



9072-2290
TEA CUP LARGE
L116-S91-H76mm-290cc
9072-1543
COMMON SAUCER
D162-H23mm



9072-2306
TEA CUP
L115-S91-H71mm-230cc
9072-1543
COMMON SAUCER
D162-H23mm



9072-2283
COFFEE CUP
L100-S78-H67mm-190cc
9072-1530
COFFEE SAUCER
D139-H24mm



9072-2289
ESPRESSO CUP
L88-S67-H57mm-120cc
9072-1542
ESPRESSO SAUCER
D121-H19mm



9072-2297
BOUILLON CUP
L142-S101-H56mm-290cc
9072-1543
COMMON SAUCER
D162-H23mm



9072-4344
TEA POT W/COVER 1,450cc
L254-S95-H177mm-1,450cc



9072-4284
SUGAR BOWL W/COVER
450cc
L104-S81-H115mm-450cc



9072-4283
CREAMER JUG 260cc
L127-S58-H96mm-260cc



9072-3207
22cm ROUND VEGETABLE BOWL
D232-H78mm-1,950cc



9072-3223
27cm OVAL VEGETABLE BOWL
L263-S195-H56mm-1,200cc



9072-1658
16cm CEREAL BOWL
D159-H49mm



9072-1883
23cm RIM SOUP PLATE
D227-H35mm



9072-1528
19cm COUPE SOUP BOWL
D199-H38mm



9072-1529
14cm FRUIT BOWL
D149-H34mm



9072-1531
37cm OVAL PLATTER
L376-S250-H30mm



9072-1532
30cm OVAL PLATTER
L299-S173-H25mm



9072-3222
CASSEROLE W/COVER 2,200cc
L277-S177-H168mm-2,200cc



TEA ACCESSORIES

NARUMI's tea accessories are designed to be functional and easy to handle without compromising on elegance. They are indispensable for lounges and guest rooms where guests enjoy the most relaxed time of the day.



58081-2923
MUG
L117 · S90 · H88mm
320cc
<Black Matte&Shiny>



58082-2923
MUG
L117 · S90 · H88mm
320cc
<White Matte&Shiny>



58083-2923
MUG
L117 · S90 · H88mm
320cc
<Gray Matte&Shiny>



58081-2956
MUG
L107 · S80 · H89mm
330cc
<Black Matte&Shiny>



58082-2956
MUG
L107 · S80 · H89mm
330cc
<White Matte&Shiny>



58083-2956
MUG
L107 · S80 · H89mm
330cc
<Gray Matte&Shiny>



8531-2923
MUG
L117 · S90 · H88mm
320cc



8531-2834
MUG
L120 · S95 · H100mm
350cc



8531-2900
MUG
L117 · S91 · H103mm
430cc



51298-2823
MUG
L130 · S93 · H95mm
460cc



8531-2685
MUG
L123 · S94 · H114mm
370cc



8531-2635
MUG
L113 · S84 · H90mm
290cc



52143-2956
MUG
L107 · S80 · H89mm
330cc



50481-2633
MUG
L113 · S81 · H101mm
370cc



8531-2684
MUG
L113 · S78 · H100mm
370cc



8531-2616
MUG
L127 · S92 · H100mm
490cc



8531-2689
MUG
L117 · S78 · H100mm
370cc



8531-2880
MUG(Stackable)
L111 · S81 · H94mm
300cc



51180-2816
MUG
L127 · S90 · H80mm
350cc



51180-2815
MUG
L112 · S80 · H110mm
400cc



8531-9789
MUG COVER
W/O KNOB
D87 · H8mm
50481-2697
MUG
L115 · S84 · H88mm
290cc



8531-9788
MUG COVER
W/KNOB
D87 · H20mm
8531-2731
MUG
L117 · S84 · H112mm
390cc



51090-9811
MUG COVER
W/KNOB
D87 · H20mm
8531-2530
MUG
L116 · S82 · H90mm
310cc



8531-2898
SHORT MUG
L106 · S77 · H78mm
240cc



50131-3707
8cm PLATE
MUG COVER
D80 · H15mm
50131-2991
MUG
L110 · S80 · H80mm
300cc



51290-99762
MUG COVER
D91 · H44mm
51290-2993
MUG
L115 · S82 · H95mm
350cc

TEA ACCESSORIES



58081-2924
TEA/COFFEE CUP
L104 · S81 · H68mm · 220cc
58081-5720
COMMON SAUCER
D150 · H18mm
<Black Matte&Shiny>



58082-2924
TEA/COFFEE CUP
L104 · S81 · H68mm · 220cc
58082-5720
COMMON SAUCER
D150 · H18mm
<White Matte&Shiny>



58083-2924
TEA/COFFEE CUP
L104 · S81 · H68mm · 220cc
58083-5720
COMMON SAUCER
D150 · H18mm
<Gray Matte&Shiny>



50617-2696
MUG
L117 · S91 · H84mm · 280cc
8531-1217
16cm SAUCER
D158 · H19mm



50617-2695
TEA/COFFEE CUP
L113 · S90 · H65mm · 210cc
8531-1946
TEA/COFFEE SAUCER
D146 · H21mm



50945-2757
ESPRESSO CUP
L93 · S72 · H58mm · 120cc
8531-1222
ESPRESSO SAUCER
D124 · H18mm



52080-2473
TEA/COFFEE CUP
L124 · S98 · H59mm · 200cc
8531-1946
TEA/COFFEE SAUCER
D146 · H21mm



52080-2942
ESPRESSO CUP
L91 · S71 · H57mm · 95cc
8531-1222
ESPRESSO SAUCER
D124 · H18mm



51090-2764
TEA CUP
L118 · S101 · H59mm · 210cc
8531-1946
TEA/COFFEE SAUCER
D146 · H21mm



51090-2766
COFFEE CUP
L102 · S81 · H76mm · 210cc
8531-1946
TEA/COFFEE SAUCER
D146 · H21mm



51090-2768
ESPRESSO CUP
L83 · S68 · H58mm · 110cc
8531-1222
ESPRESSO SAUCER
D124 · H18mm



51799-2903
COFFEE CUP(Stackable)
L105 · S81 · H64mm · 240cc
8531-1946
TEA/COFFEE SAUCER
D146 · H21mm



9795-2390
BOUILLON CUP(Stackable)
L140 · S101 · H53mm · 310cc
9795-1452
16cm SAUCER
D155 · H21mm



9795-2918
COFFEE CUP(Stackable)
L110 · S86 · H70mm · 260cc
9795-1452
SAUCER
D155 · H21mm



9795-2389
COFFEE CUP(Stackable)
L106 · S85 · H57mm · 200cc
9795-1452
16cm SAUCER
D155 · H21mm



9795-2392
ESPRESSO CUP(Stackable)
L83 · S65 · H51mm · 110cc
9795-1453
ESPRESSO SAUCER
D125 · H20mm



51050-2754
TEA CUP
D79 • H68mm • 230cc
8531-1222
SAUCER
D124 • H18mm



92626-2430
JAPANESE TEA CUP
D87 • H54mm • 210cc



8725-2916
FREE CUP 170cc
D76 • H77mm • 170cc



92626-54607
TEA POT W/COVER 730cc
L168 • S136 • H105mm • 730cc



52080-4393
TEA/COFFEE POT
W/COVER 920cc
L218 • S124 • H180mm • 920cc



52080-4718
TEA POT
W/COVER 1,200cc
L250 • S160 • H163mm • 1,200cc



52080-4717
TEA POT
W/COVER 720cc
L215 • S126 • H152mm • 720cc



52080-4392
SUGAR BOWL
W/COVER 250cc
L138 • S104 • H100mm • 250cc



52080-4391
CREAMER JUG 170cc
L104 • S72 • H91mm • 170cc



9795-4238
MILK POT 340cc
L120 • S87 • H101mm • 340cc



9795-4286
CREAMER JUG 190cc
L96 • S74 • H69mm • 190cc



9795-4287
CREAMER JUG 90cc
L76 • S59 • H52mm • 90cc



9795-4235
MILK PITCHER 160cc
D67 • H74mm • 160cc



9795-9278
MILK PITCHER 70cc
D53 • H58mm • 70cc



9795-9502
MILK PITCHER 40cc
D46 • H47mm • 40cc



9265-4515
PETIT POT W/COVER 330cc
L143 • S90 • H100mm • 330cc



9795-795
SUGAR CONTAINER
L88 • S77 • H45mm



9795-4361
MARMALADE POT
D60 • H61mm • 80cc



8725-676
POT WARMER
D135 • H70mm



TABLE ACCESSORIES

A wide variety of amuse and condiment items add more fun to food presentation.



9265-9781
5 COMPARTMENT DISH
L260 • S79 • H27mm



9265-9782
3 COMPARTMENT DISH
L170 • S79 • H27mm



9265-9830
6cm SQUARE BOWL(Stackable)
L62 • S62 • H32mm



9265-9830
6cm SQUARE BOWL(Stackable)
L62 • S62 • H32mm
9265-9829
20cm CASTER TRAY(3 PORTIONS)
L200 • S71 • H15mm



9265-9830
6cm SQUARE BOWL(Stackable)
L62 • S62 • H32mm
9265-9882
13cm CASTER TRAY(2 PORTIONS)
L136 • S71 • H15mm



8531-1597
10cm BUTTER DISH
D103 • H21mm



9795-9277
9cm BUTTER DISH
D95 • H14mm



9795-973
8cm DIP DISH
D82 • H25mm



92626-9660
10cm DISH
D101 • H20mm



9795-9526
7cm BUTTER DISH
D68 • H12mm



9795-9659
5cm DISH
D49 • H16mm



9265-98432
COVER FOR BUTTER DISH
D82 • H60mm

9265-98431
9.5cm BUTTER DISH
D94 • H30mm

9265-9843
9.5cm BUTTER DISH
W/COVER
D94 • H70mm



50481-5615
SQUARE BUTTER DISH
D95 • L81 • S81 • H12mm



50131-5605
24cm L TRAY
L239 • S130 • H14mm



50131-5604
16cm L TRAY
L163 • S130 • H14mm



9795-42482
SMALL CUP COVER
D70 • H29mm

9795-9447
SMALL CUP(1-pc)(Stackable)
D68 • H33mm • 80cc



50576-9680
GINKGO REST
L88 • S87 • H19mm



50576-9681
ELM REST
L122 • S47 • H21mm



50576-9685
3 STEPS REST
L90 • S20 • H18mm



50576-9684
2 STEPS REST
L75 • S20 • H11mm



50576-9833
10cm 3 SQUARES REST
L100 • S37 • H11mm



50576-9687
3 SQUARES REST
L80 • S30 • H10mm



9265-9899
SALT SHAKER
(3HOLES)
D48 • H78mm



9265-9900
PEPPER SHAKER
(5HOLES)
D48 • H78mm



50481-9695
SALT SHAKER
(3HOLES)
D61 • L52 • S52 • H82mm



50481-9696
PEPPER SHAKER
(5HOLES)
D61 • L52 • S52 • H82mm



9795-9558
SALT SHAKER
(3HOLES)
D46 • H90mm



9795-9559
PEPPER SHAKER
(5HOLES)
D46 • H90mm



9795-9466
SALT SHAKER
(3HOLES)
D43 • H54mm



9795-9467
PEPPER SHAKER
(5HOLES)
D43 • H54mm



8531-9318
SALT SHAKER
(3HOLES)
L54 • S41 • H85mm



8531-9319
PEPPER SHAKER
(5HOLES)
L54 • S41 • H85mm



9265-9539
SALT SHAKER
(1HOLES)
D42 • H59mm



9265-9540
PEPPER SHAKER
(3HOLES)
D42 • H59mm



9795-9211
EGG CUP
D52 • H60mm



9795-9398
18cm OVAL DISH
L178 • S95 • H19mm



9265-508
21cm CRESCENT DISH
L207 • S143 • H23mm



9795-675
BUD VASE
D71 • H126mm



9795-9785
ASHTRAY
L151 • S121 • H26mm



9795-9429
ASHTRAY
D89 • H33mm

BUFFET ITEMS



50131-3702
28cm LARGE BOWL
D281 • H86mm • 4,600cc



50131-3703
18cm DEEP BOWL
D180 • H100mm • 2,200cc



50131-3705
DRESSING POT
D109 • H142mm • 1,090cc



50180-3429
27cm SQUARE PLATE
L272 • S272 • H31mm



50180-887
40cm PALETTE PLATE
L405 • S275 • H12mm



50481-3510
30cm BUFFET TRAY
L308 • S234 • H15mm



50481-3503
20cm TIDBIT TRAY
L206 • S134 • H16mm



50481-3482
33cm OBLONG BOWL
L333 • S130 • H53mm



9265-5710
35cm OBLONG TRAY
L350 • S160 • H18mm

9265-5709
28cm OBLONG TRAY
L280 • S140 • H18mm

9265-5923
28cm OBLONG TRAY
L280 • S109 • H16mm



50180-9557
48cm OBLONG TRAY
L480 • S160 • H25mm



50180-5153
34cm SQUARE PLATE, DEEP
L345 • S345 • H48mm



9265-5738
36cm OBLONG TRAY
L360 • S210 • H20mm



50180-3406
50cm LEAF BOWL
L496 • S228 • H80mm



50180-3426
36cm LEAF BOWL
L360 • S160 • H63mm

SIDE VIEW



50180-3407
26cm LEAF BOWL
L254 • S135 • H46mm



50180-3412
18cm LEAF BOWL
L183 • S101 • H33mm



50180-3408
13cm LEAF BOWL
L131 • S75 • H31mm



50131-5658
27cm SQUARE 4 DIVIDED PLATE
L267 • S267 • H18mm

50131-5729
23cm SQUARE 4 DIVIDED PLATE
L225 • S225 • H17mm

50131-5659
18cm SQUARE 4 DIVIDED PLATE
L180 • S180 • H18mm



51290-5611
4 DIVIDED DISH
L201 • S201 • H14mm



50617-3496
25cm ROUND 3 DIVIDED PLATE
D249 • H27mm



50617-3490
38cm OVAL 3 DIVIDED PLATE
L375 • S144 • H22mm



50131-5353
27cm SQUARE RIM PLATE
L275 • S275 • H15mm

50131-5599
24cm SQUARE RIM PLATE
L240 • S240 • H13mm



51396-5727
30cm PLATE
D306 • H25mm

51396-5666
27cm PLATE
D278 • H23mm



52090-5861
28cm PLATE
D280 • H35mm

52090-5862
22cm PLATE
D214 • H38mm



51090-5832
20cm FLAT PLATE
D204 • H19mm

51090-5428
17cm FLAT PLATE
D170 • H17mm

51090-5541
11cm FLAT PLATE
D113 • H16mm




50450-5277
28cm PLATE
D285 • H33mm

50450-5278
24cm PLATE
D243 • H33mm



50450-3470
24cm SOUP PLATE
D237 • H53mm



8725-9749
26cm OBLONG TRAY
L263 • S192 • H15mm



51395-5661
28cm OBLONG TRAY
L283 • S130 • H24mm



51395-5628
20cm OBLONG TRAY
L197 • S197 • H24mm



51091-5553
32cm DOUBLE SPOON TRAY
L325 • S142 • H35mm



51091-5554
25cm SPOON TRAY
L252 • S111 • H36mm

BUFFET ITEMS



50827-5619
45cm DEEP PLATE
L459 • S252 • H37mm



50827-5620
35cm DEEP PLATE
L356 • S232 • H27mm



50827-5374
34cm PLATTER
L348 • S234 • H19mm



50827-9743
23cm BUTTER TRAY
L238 • S144 • H12mm



50827-5373
60cm FISH TRAY
L614 • S197 • H35mm



50827-5381
46cm BUFFET TRAY
L455 • S198 • H35mm



50827-5382
51cm BUFFET TRAY (SINGLE-RIM TYPE)
L523 • S165 • H28mm



50827-5383
40cm BUFFET TRAY (SINGLE-RIM TYPE)
L400 • S174 • H26mm



50827-5498
36cm TRAY (SINGLE-RIM TYPE)
L365 • S129 • H26mm



50827-5371
60cm BUFFET PLATTER
L610 • S260 • H30mm



50827-5372
60cm BUFFET FISH PLATTER
L614 • S197 • H21mm



50827-5499
35cm TRAY
L346 • S95 • H15mm



50827-3532
46cm BUFFET BOWL
L467 • S203 • H82mm



50827-3576
23cm SOUP BOWL
L227 • S184 • H54mm



50827-3528
25cm LARGE BOWL
L254 • S196 • H80mm



50827-3529
20cm MEDIUM BOWL
L198 • S152 • H63mm



50827-3530
14cm SMALL BOWL
L146 • S112 • H47mm



50180-35332
COVER FOR 25cm MUFFIN DISH
D178 • H91mm
9795-32704
25cm MUFFIN DISH
D258 • H33mm



50180-35342
COVER FOR 23cm MUFFIN DISH
D174 • H84mm
9795-33154
23cm MUFFIN DISH
D230 • H33mm



50180-35352
COVER FOR 20/26cm MUFFIN DISH
D147 • H71mm
9795-32874
20cm MUFFIN DISH
D199 • H37mm



51290-99752
DOME COVER
D253 • H166mm



9795-33612
COVER FOR 25cm MUFFIN DISH
D178 • H91mm
9795-32704
25cm MUFFIN DISH
D258 • H33mm



9795-33362
COVER FOR 23cm MUFFIN DISH
D174 • H84mm
9795-33154
23cm MUFFIN DISH
D230 • H33mm



9795-33412
COVER FOR 20cm MUFFIN DISH
D147 • H71mm
9795-32874
20cm MUFFIN DISH
D199 • H37mm



51090-27702
COVER FOR 17cm SALAD BOWL
D172 • H30mm
51090-27701
17cm SALAD BOWL
D168 • H50mm • 610cc



9265-3612
THAI CURRY POT W/COVER 1,100cc
L190 • S160 • H150mm • 1,100cc



9265-3611
INDIAN CURRY POT W/COVER 900cc
D190 • H110mm • 900cc



9265-3610
BRIYANI POT W/COVER 1,000cc
D168 • H138mm • 1,000cc



9265-9842
CURRY/BRIYANI POT STAND
D145 • H68mm

ACCESSORY-AMUSE



51031-27802
COVER FOR 10cm PETIT BOWL
D70 • H38mm
51031-27801
10cm PETIT BOWL
L100 • S88 • H43mm • 40cc



50460-96572
COVER FOR PEACH BOX
D59 • H32mm
50460-96571
PEACH BOX
D63 • H39mm



50460-96582
COVER FOR PUMPKIN BOX
D67 • H33mm
50460-96581
PUMPKIN BOX
D67 • H28mm



50460-96562
COVER FOR WOVEN BOX
L67 • S60 • H24mm
50460-96561
WOVEN BOX
L66 • S59 • H29mm



50460-96762
COVER FOR RIBBON BOX
D65 • H23mm
50460-96761
RIBBON BOX
D64 • H35mm



50460-96752
COVER FOR POUCH BOX
L68 • S58 • H35mm
50460-96751
POUCH BOX
L70 • S60 • H38mm



50460-9655
SQUARE BOX W/COVER
L79 • S79 • H65mm



50827-45882
COVER FOR 7cm PETIT BOWL
L77 • S67 • H33mm
50827-45881
7cm PETIT BOWL
L73 • S62 • H43mm • 100cc



50576-9701
ESCARGOT DISH
L130 • S100 • H35mm



50576-9702
MOULE DISH
L157 • S90 • H24mm



50576-9703
ABALONE DISH
L128 • S102 • H27mm



50576-9704
OYSTER DISH
L140 • S82 • H30mm



50576-9705
SHELL DISH
L120 • S100 • H39mm



50460-9651
SHELL DISH
L92 • S86 • H35mm



50460-9653
LEAF DISH
L114 • S99 • H25mm



50460-9652
ROSE DISH
L86 • S83 • H24mm



50460-9654
10cm PETIT TRAY
L105 • S70 • H13mm



50460-9712
11cm TEARDROP BOAT
L112 • S72 • H35mm



50460-9714
11cm OVAL BOAT
L110 • S68 • H40mm



50131-9800
SQUARE AMUSE CUP
L48 • S48 • H77mm



51290-9802
AMUSE CUP(HIGH)
L34 • S34 • H58mm • 40cc



51290-9803
AMUSE CUP(LOW)
L45 • S45 • H30mm • 30cc



50481-2678
FREE CUP
D85 • H65mm • 140cc



51290-2820
TEA CUP(L)
L83 • S80 • H75mm • 230cc



51290-2821
TEA CUP(S)
L72 • S71 • H67mm • 160cc



8531-2741
TEA CUP
D65 • H66mm • 100cc



50460-2657
PETIT CUP
D65 • H54mm • 80cc



50180-2646
GRANITE CUP
D60 • H55mm • 80cc



51298-2955
8cm BOWL
D79 • H42mm • 100cc



50460-9707
BABY SPOON
L81 • S33 • H29mm



50576-9706
LEAF SPOON
L162 • S32 • H22mm



51091-9786
12cm SPOON
L110 • S47 • H19mm



51298-9813
11cm SPOON
L114 • S38mm • H39mm



9795-9544
AMUSEMENT SPOON
L105 • S39 • H34mm

Multi - Purpose Bowls



51050-3589
19cm BOWL
D195 • H82mm



51050-3588
16cm BOWL
D164 • H64mm



51050-3587
14cm BOWL
D143 • H59mm



51050-3586
13cm BOWL
D132 • H53mm



51050-2879
10cm BOWL
D108 • H61mm



50481-3507
CAFE AU LAIT BOWL 630cc
D141 • H80mm • 630cc



50481-2680
CAFE AU LAIT BOWL 380cc
D112 • H72mm • 380cc



52090-3635
16cm BOWL
D155 • H63mm • 770cc



52090-3636
14cm BOWL
D137 • H55mm • 500cc



51327-2883
14cm BOWL
L143 • S122 • H58mm



50450-3473
16cm BOWL
D158 • H61mm



50450-3474
14cm PETAL BOWL
L148 • S125 • H39mm



50460-9679
10cm PETAL DISH
L100 • S83 • H28mm



50763-2809
10cm BOWL
(Stackable)(RELIEF)
D101 • H53mm • 310cc



9795-2838
10cm BOWL
(Stackable)
D101 • H53mm • 310cc

Covered Bowls



51090-27652
COVER FOR SOUP CUP
D105 • H26mm



51090-27672
COVER FOR FREE CUP
D83 • H24mm



51090-27692
COVER FOR PETIT CUP
D70 • H21mm



50828-27392
COVER FOR RELIEF CUP
D110 • H35mm



50460-9716
10cm TEARDROP BOX
W/COVER
L105 • S85 • H63mm

51090-27651
SOUP CUP
D101 • H59mm • 210cc

51090-27671
FREE CUP
D81 • H76mm • 210cc

51090-27691
PETIT CUP
D68 • H58mm • 110cc

50828-27391
RELIEF CUP
D107 • H59mm • 260cc

8531-1946
TEA/COFFEE SAUCER
D146 • H21mm

8531-1946
TEA/COFFEE SAUCER
D146 • H21mm

8531-1222
SAUCER
D124 • H18mm

50180-5331
COMMON SAUCER
D180 • H15mm



50450-34722
COVER FOR 19cm PETAL BOWL
L156 • S136 • H56mm



50828-27382
COVER FOR PLAIN CUP
D102 • H33mm



51031-27712
COVER FOR 13cm SOUP BOWL
D106 • H84mm



51090-36292
COVER FOR 13cm BOWL
D140 • H36mm

50450-34721
19cm PETAL BOWL
L190 • S159 • H58mm

50828-27381
PLAIN CUP
D98 • H75mm • 250cc

51031-27711
13cm SOUP BOWL
L136 • S125 • H51mm • 210cc

51090-36291
13cm BOWL
D132 • H45mm • 370cc

Dressing Boat / Sauce Boat



9795-3249
DRESSING BOAT
L210 • S93 • H92mm • 340cc



9795-3189
SAUCE BOAT(1-P)
L119 • S65 • H43mm • 110cc



8531-4562
CREAMER JUG 120cc
L102 • S43 • H68mm • 120cc



50460-9715
9cm DRESSING BOAT
L98 • S81 • H45mm • 110cc



50827-4589
CREAMER JUG 100cc
L89 • S62 • H43mm • 100cc



Custom-made Solutions

Specially Designed for Special Occasions

NARUMI offers a range of customized solutions to produce outstanding food presentation.

As you consider with whom you should partner, please consider these advantages of NARUMI's customization:

- Long-standing trust from the world's leading hotels and restaurants
- A range of available customization options (from a one-point logo to detailed artwork)
- In-house designers who can create designs based on customers' requests and interior images
- Expertise in realizing complex and delicate design on actual products

Order Process





Pan Pacific London

Pan Pacific London opened in September 2021. Its signature restaurant, Straits Kitchen, serves authentic Singaporean cuisine in the heart of London. A design that would evoke Singaporean culture was requested, and we incorporated patterns found in traditional Peranakan culture into the chinaware.

With in-house designers specializing in bone china design, NARUMI offers flexible design proposals to meet the diverse needs of F&B professionals.



Rosewood Hong Kong

At Rosewood Hong Kong, which opened in March 2019, custom-made tableware welcomes guests to its banquet halls. Designed to match the interior, the customized show plates make the diners' experience at the restaurant even more special.

NARUMI's custom designs are available in a variety of shapes to choose from. Based on the interior and menu image provided by the client, NARUMI will propose the most appropriate design for the venue.





Design concept by Wesley Holton, Corporate Executive Chef - MGM Resorts International
Photo by Nathan Frost, Property Executive Chef - Bellagio
Christopher Heisinger, Property Assistant Executive Chef - Bellagio

Bellagio Las Vegas

Catering and Banquets at the Bellagio, one of the most prestigious hotels in Las Vegas, features custom-made blue dinnerware. The intricate geometric patterns are carefully designed to match the size and rim width of each plate. This beautifully showcases NARUMI's craftsmanship in designing and applying complex patterns to a chinaware body.



Capella Hanoi

Capella Hanoi is a 5-star hotel that offers a palace-like setting full of artistry. All-day dining at the Backstage restaurant combines Northern Vietnamese traditions and modern culinary techniques. The vintage-inspired crockery is specially designed for the hotel. NARUMI's highly skilled designers and engineers incorporated customers' design ideas into the tableware with precision and creativity.





RESORTS WORLD LAS VEGAS



BELLAGIO LAS VEGAS



PAN PACIFIC YANGON



MANDARIN ORIENTAL HYDE PARK LONDON



PAN PACIFIC LONDON



FOUR SEASONS HOTEL LONDON AT TEN TRINITY SQUARE



FAIRMONT RIYADH



BVLGARI HOTEL BEIJING



PARK HYATT HYDERABAD



AL FAISALIAH HOTEL



GRAND HYATT ISTANBUL



SHANGRI-LA HOTEL JEDDAH



GRAND HYATT ABU DHABI



EMBASSY OF THE REPUBLIC OF INDONESIA



SINGAPORE MINISTRY OF FOREIGN AFFAIRS



AMUZ



METROPOLE HANOI



INTERCONTINENTAL SINGAPORE



HOIANA CASINO VIETNAM



VENETIAN COTAÏ



THE PENINSULA CHICAGO



W CHANGSHA



TAIPEI MARRIOTT HOTEL




MGM COTAÏ



HILTON OKINAWA CHATAN RESORT



JW MARRIOTT HOTEL YINCHUAN



FAIRMONT JAKARTA



RENAISSANCE ZHUHAI



JUMEIRAH HOTEL GUANGZHOU



INTERCONTINENTAL DONGGUAN

INDEX

Pattern	Item	Description	Page		
8128		Solaria	96		
8353	1866	26cm FLAT PLATE	30		
	1986	29cm FLAT PLATE	30		
8531 New Rim	1086	21cm PLATE	42		
	1214	16cm PLATE	42		
	1217	16cm SAUCER	43	75	80 102
	1218	18cm SAUCER	43	75	80 95
	1219	43cm OVAL PLATTER	42		
	1220	38cm OVAL PLATTER	42		
	1221	32cm OVAL PLATTER	42		
	1222	ESPRESSO SAUCER	43	102	103 111
	1269	23cm PLATE	42		
	1557	27cm PLATE	42		
	1558	19cm PLATE	42		
	1597	10cm BUTTER DISH	42	105	
	1646	23cm RIM SOUP PLATE	42		
	1670	30cm PLATE	42		
	1857	13cm FRUIT BOWL	42		
	1946	TEA/COFFEE SAUCER	102	111	
	2423	TEA/COFFEE CUP	43		
	2427	ESPRESSO CUP	43		
	2428	BOUILLON CUP	43		
	2438	TEA CUP	43		
	2530	MUG	101		
	2616	MUG	101		
	2635	MUG	101		
	2684	MUG	101		
	2685	MUG	43	101	
	2689	MUG	101		
	2731	MUG	101		
	2741	TEA CUP	110		
	2834	MUG	101		
	2880	MUG (Stackable)	101		
	2898	SHORT MUG	101		
	2900	MUG	101		
	2923	MUG	101		
	3279	22cm ROUND VEGETABLE BOWL	42		
	3281	24cm OVAL VEGETABLE BOWL	42		
	3283	CASSEROLE W/COVER 2,420cc	43		
	3356	CASSEROLE W/COVER 4,280cc	43		
	3402	26cm BOWL	93		
	4357	CREAMER JUG 220cc	43		
	4358	SUGAR BOWL W/COVER 300cc	43		
	4359	COFFEE POT W/COVER 1,320cc	43		
	4414	CREAMER JUG 200cc	43		
4416	TEA POT W/COVER 940cc	43			
4464	TEA POT W/COVER 550cc	43			
4562	CREAMER JUG 120cc	111			
5128	32cm DEEP PLATE	43			
5129	30cm PLATE	43			
5130	27cm PLATE	43			
5131	23cm PLATE	43			
5132	16cm PLATE	43			
5134	21cm BOWL	93			
5282	29cm PASTA PLATE	42			
5379	30cm BOWL	93			
5415	27cm WIDE RIM PLATE	43			
5762	17.5cm MEZZA BOWL(DEEP)	42			
5763	17cm MEZZA BOWL	42			
5764	13cm MEZZA BOWL	42			
9212	23cm BUTTER TRAY	42			
9286	NAPKIN RING	80			
9318	SALT SHAKER(3HOLES)	43	105		
9319	PEPPER SHAKER(5HOLES)	43	105		
9788	MUG COVER W/KNOB	101			
9789	MUG COVER W/O KNOB	101			
32064	GRAVY BOAT TRAY	43			
32821	GRAVY BOAT 560cc	43			
59097	GRAVY BOAT W/TRAY	43			
8661		Sharilmoon	94		

Pattern	Item	Description	Page		
8720		Esperar	94		
8725	676	POT WARMER	103		
	2916	FREE CUP 170cc	103		
	9749	26cm OBLONG TRAY	107		
8740 Lotus	1120	27cm PLATE	94		
	1121	23cm PLATE	94		
	1122	21cm PLATE	94		
	1123	17cm PLATE	94		
	1124	20cm COUPE SOUP BOWL	95		
	1125	15cm FRUIT BOWL	95		
	1126	41cm OVAL PLATTER	95		
	1128	COMMON SAUCER	95		
	1131	25cm PLATE	94		
	1132	ESPRESSO SAUCER	95		
	1133	17cm BOWL	95		
	1136	30cm PLATE	94	95	
	1138	19cm PLATE	94		
	1167	38cm OVAL PLATTER	95		
	1170	23cm BUTTER TRAY	95		
	1171	23cm RIM SOUP PLATE	95		
	2540	COFFEE CUP	95		
	2541	TEA CUP	95		
	2548	ESPRESSO CUP	95		
	2549	BOUILLON CUP	95		
	3337	23cm SALAD BOWL	95		
3375	CASSEROLE W/COVER	95			
4470	CREAMER JUG 170cc	95			
4471	SUGAR BOWL W/COVER 290cc	95			
4472	TEA/COFFEE POT W/COVER 960cc	95			
4475	TEA POT W/COVER 600cc	95			
4486	COFFEE POT W/COVER 1,350cc	95			
4723	CREAMER JUG 170cc	95			
5820	27cm PLATE(SHALLOW)	94			
36562	COVER FOR 12cm BOWL	95			
36592	COVER FOR 30cm PLATE	95			
36602	COVER FOR 25cm MUFFIN DISH	95			
8967		Remembrance	96		
8968		Simply Gold	96		
8969 Leaf	1730	TEA/COFFEE SAUCER	97		
	1747	27cm PLATE	96		
	1748	23cm PLATE	96		
	1749	20cm PLATE	96		
	1750	17cm PLATE	96		
	1751	ESPRESSO SAUCER	97		
	1752	19cm COUPE SOUP BOWL	97		
	1753	15cm FRUIT BOWL	97		
	1783	17cm SAUCER	97		
	1784	42cm OVAL PLATTER	97		
	1785	38cm OVAL PLATTER	97		
	1786	32cm OVAL PLATTER	97		
	1887	23cm BUTTER TRAY	97		
	2376	TEA CUP	97		
	2385	ESPRESSO CUP	97		
	2397	BOUILLON CUP	97		
	2596	COFFEE CUP	97		
	2943	CAPPUCCINO CUP	97		
	2944	ESPRESSO CUP	97		
	2954	MUG	97		
3259	23cm ROUND VEGETABLE BOWL	97			
3261	CASSEROLE W/COVER	97			
4333	CREAMER JUG 100cc	97			
4334	SUGAR BOWL W/COVER 140cc	97			
4338	TEA/COFFEE POT W/COVER 1,200cc	97			
4722	SUGAR BOWL 140cc	97			
5533	RICE BOWL	97			
9426	SALT SHAKER(3HOLES)	97			
9427	PEPPER SHAKER(5HOLES)	97			
52217	SALT & PEPPER SHAKER	97			
8970		Briarcliffe (Platinum)	48		
8971		Golden Crown	48		

INDEX

Pattern	Item	Description	Page				
9072 Silky	1525	23cm PLATE	99				
	1526	19cm PLATE	99				
	1527	16cm PLATE	99				
	1528	19cm COUPE SOUP BOWL	99				
	1529	14cm FRUIT BOWL	99				
	1530	COFFEE SAUCER	99				
	1531	37cm OVAL PLATTER	99				
	1532	30cm OVAL PLATTER	99				
	1542	ESPRESSO SAUCER	99				
	1543	COMMON SAUCER	99				
	1544	27cm PLATE	99				
	1658	16cm CEREAL BOWL	99				
	1883	23cm RIM SOUP PLATE	99				
	2283	COFFEE CUP	99				
	2289	ESPRESSO CUP	99				
	2290	TEA CUP LARGE	99				
	2297	BOUILLON CUP	99				
	2306	TEA CUP	99				
	3207	22cm ROUND VEGETABLE BOWL	99				
	3222	CASSEROLE W/COVER 2,200cc	99				
	3223	27cm OVAL VEGETABLE BOWL	99				
	4283	CREAMER JUG 260cc	99				
	4284	SUGAR BOWL W/COVER 450cc	99				
	4344	TEA POT W/COVER 1,450cc	99				
	9265 White	508	21cm CRESCENT DISH	105			
		1099	19cm MEZZA BOWL	92			
		1671	27cm PLATE	92			
		1672	25cm PLATE	92			
		1673	23cm PLATE	92			
		1674	20cm PLATE	92			
		1675	16cm PLATE	92			
		1677	18cm SAUCER	75	93		
		1720	COMMON SAUCER	93			
		1721	ESPRESSO SAUCER	93			
1723		16cm CEREAL BOWL	92				
1746		15cm PORRIDGE BOWL	92				
1876		30cm PLATE	92				
1905		18cm PLATE	92				
1906		14cm PLATE	92				
1963		16cm MEZZA BOWL	92				
1986		29cm FLAT PLATE	81				
2369		COFFEE CUP	93				
2370		TEA CUP	93				
2371		BOUILLON CUP	93				
2372		ESPRESSO CUP	93				
2382		TEA/COFFEE CUP	93				
2435		AMERICAN COFFEE CUP	93				
3610		BRIYANI POT W/COVER 1,000cc	109				
3611		INDIAN CURRY POT W/COVER 900cc	109				
3612		THAI CURRY POT W/COVER 1,100cc	109				
4323		CREAMER JUG 160cc	93				
4324		CREAMER JUG 230cc	93				
4325		SUGAR BOWL W/COVER	93				
4326		COFFEE POT W/COVER 500cc	93				
4327		TEA POT W/COVER 540cc	93				
4328		TEA POT W/COVER 840cc	93				
4336		COFFEE POT W/COVER 1,100cc	93				
4515		PETIT POT W/COVER 330cc	103				
5709		28cm OBLONG TRAY	106				
5710		35cm OBLONG TRAY	106				
5738		36cm OBLONG TRAY	106				
5923		28cm OBLONG TRAY	106				
9453		LADLE	81				
9539		SALT SHAKER(1HOLE)	105				
9540		PEPPER SHAKER(3HOLES)	105				
9781		5 COMPARTMENT DISH	104				
9782		3 COMPARTMENT DISH	104				
9829		20cm CASTER TRAY(3 PORTIONS)	104				
9830		6cm SQUARE BOWL(Stackable)	104				
9839		26cm CASTER TRAY(4 PORTIONS)	104				

Pattern	Item	Description	Page				
9265 White	9842	CURRY/BRIYANI POT STAND	109				
	9843	9.5cm BUTTER DISH W/COVER	105				
	9882	13cm CASTER TRAY(2 PORTIONS)	104				
	9899	SALT SHAKER(3HOLES)	105				
	9900	PEPPER SHAKER(5HOLES)	105				
	9905	TOOTHPICK HOLDER	82				
	98431	9.5cm BUTTER DISH	105				
	98432	COVER FOR BUTTER DISH	105				
	9795 White	675	BUD VASE	105			
		795	SUGAR CONTAINER	103			
		973	8cm DIP DISH	105			
		1024	24cm PASTA PLATE	92			
		1452	16cm SAUCER	102			
		1453	ESPRESSO SAUCER	82	102		
		1644	23cm RIM SOUP PLATE	92			
		2389	COFFEE CUP(Stackable)	102			
		2390	BOUILLON CUP(Stackable)	102			
2392		ESPRESSO CUP(Stackable)	102				
2838		10cm BOWL(Stackable)	111				
2918		COFFEE CUP(Stackable)	102				
3189		SAUCE BOAT(1-P)	111				
3249		DRESSING BOAT	111				
4235		MILK PITCHER 160cc	103				
4238		MILK POT 340cc	103				
4286		CREAMER JUG 190cc	103				
4287		CREAMER JUG 90cc	103				
4361		MARMALADE POT	103				
4652		CREAMER JUG 100cc	22				
5933		10cm SAUCE DISH	80				
9211		EGG CUP	105				
9277		9cm BUTTER DISH	105				
9278		MILK PITCHER 70cc	103				
9380		DIVIDED DISH	80				
9398		18cm OVAL DISH	105				
9429		ASHTRAY	105				
9447		SMALL CUP(1-pc)(Stackable)	105				
9466		SALT SHAKER(3HOLES)	105				
9467		PEPPER SHAKER(5HOLES)	105				
9484		15cm CASTER TRAY	82				
9502		MILK PITCHER 40cc	103				
9526		7cm BUTTER DISH	105				
9544		AMUSEMENT SPOON	110				
9558	SALT SHAKER(3HOLES)	105					
9559	PEPPER SHAKER(5HOLES)	105					
9659	5cm DISH	105					
9785	ASHTRAY	105					
32704	25cm MUFFIN DISH	23	95	109			
32874	20cm MUFFIN DISH	109					
33154	23cm MUFFIN DISH	109					
33362	COVER FOR 23cm MUFFIN DISH	109					
33412	COVER FOR 20cm MUFFIN DISH	109					
33612	COVER FOR 25cm MUFFIN DISH	109					
42482	SMALL CUP COVER	105					
50064	Caress	48					
50131 White	2991	MUG	12	101			
	3702	28cm LARGE BOWL	106				
	3703	18cm DEEP BOWL	12	106			
	3704	12cm DEEP BOWL	12				
	3705	DRESSING POT	106				
	3706	8cm DEEP BOWL	12				
	3707	8cm PLATE	12	101			
	3708	8cm DEEP DISH	12				
	3709	12cm PLATE	12				
	3710	12cm BOWL	12				
	3711	14cm PLATE	12				
	3712	14cm BOWL	12				
	3713	18cm PLATE	12				
	3714	18cm DEEP DISH	12				
	3715	18cm BOWL	12				
3716	21cm PLATE	12					

INDEX

Pattern	Item	Description	Page				
50131 White	5353	27cm SQUARE RIM PLATE	107				
	5599	24cm SQUARE RIM PLATE	107				
	5604	16cm L TRAY	105				
	5605	24cm L TRAY	105				
	5658	27cm SQUARE 4 DIVIDED PLATE	107				
	5659	18cm SQUARE 4 DIVIDED PLATE	107				
	5729	23cm SQUARE 4 DIVIDED PLATE	107				
	5827	27cm PLATE	17				
	5964	15cm SLANT PLATE	21				
	9799	CUBE OBJECT	23				
	9800	SQUARE AMUSE CUP	110				
	9880	GARNISH PLATE	21				
	9881	LEAF BOAT	21				
	9959	QUATER BOWL	12				
	9960	LEAF BOAT	12				
	99361	SMALL MUFFIN DISH	23				
	99362	COVER FOR SMALL MUFFIN DISH	23				
	50180 Esprit	887	40cm PALETTE PLATE	106			
		2646	GRANITE CUP	110			
2687		TEA CUP	61				
2688		MUG	61				
2690		ESPRESSO CUP	61				
2699		10cm RICE BOWL	61				
2703		COFFEE CUP	61				
2708		9cm FREE CUP	61				
2774		CAPPUCCINO CUP	61				
2837		CHAPPEI CUP	61				
2877		SUGAR BOWL W/COVER 270cc	61				
3406		50cm LEAF BOWL	106				
3407		26cm LEAF BOWL	106				
3408		13cm LEAF BOWL	106				
3412		18cm LEAF BOWL	106				
3426		36cm LEAF BOWL	106				
3429		27cm SQUARE PLATE	106				
3430		33cm SQUARE TRAY	62				
3431		12cm SQUARE TRAY	62				
3448		28cm OBLONG TRAY	62				
3449		43cm OBLONG TRAY	62				
3450		28cm SQUARE TRAY	62				
3452		23cm DEEP PLATE	60				
3497		22cm BOWL	61				
3515		19cm BOWL	61				
3554		16cm BOWL	61				
3561		19cm COVERED SOUP BOWL W/HANDLE	62				
3565		13cm BOWL	61				
3598		22cm SQUARE TRAY	62				
4563		SUGAR BOWL W/COVER 340cc	61				
4564		CREAMER JUG 220cc	61				
4565		TEA/COFFEE POT W/COVER 1,270cc	61				
4580		COFFEE POT W/COVER 700cc	61				
4581		CREAMER JUG 160cc	61				
4628		TEA/COFFEE POT W/COVER 800cc	61				
4653		COFFEE POT W/COVER 530cc	61				
4654		TEA POT W/COVER 550cc	61				
5153		34cm SQUARE PLATE, DEEP	106				
5219		27cm DEEP PLATE	60				
5220		30cm SERVICE PLATE	60				
5221		26cm MUFFIN PLATE	60				
5242		27cm PLATE	60				
5243		23cm PLATE	60				
5244		21cm PLATE	60				
5245		18cm PLATE	60				
5304		23cm SOUP BOWL	60				
5305		COMMON SAUCER	61				
5312		30cm PLATE	60				
5313		14cm BOWL	61				
5314		38cm OVAL PLATTER	62				
5315		ESPRESSO SAUCER	61				
5331		COMMON SAUCER	62	111			
5555		44cm OVAL PLATTER	62				

Pattern	Item	Description	Page				
50180 Esprit	5703	16cm PLATE	60				
	5704	16cm SAUCER	61				
	5705	17cm SAUCER	61				
	9557	48cm OBLONG TRAY	106				
	9718	23cm OVAL TRAY	62				
	26561	11cm CUP	23	62			
	27091	BOUILLON CUP	62				
	27092	COVER FOR BOUILLON CUP	62				
	28782	COVER FOR 10cm BOWL	61				
	35332	COVER FOR 25cm MUFFIN DISH	109				
	35342	COVER FOR 23cm MUFFIN DISH	109				
	35352	COVER FOR 20/26cm MUFFIN DISH	60	109			
	35852	COVER FOR 11cm CUP	23	62			
	54302	CHAPPEI SET	61				
	98942	COVER FOR BOUILLON CUP	62				
	50200	Space Moon	48				
	50450 White	3470	24cm SOUP PLATE	107			
		3473	16cm BOWL	111			
		3474	14cm PETAL BOWL	111			
5277		28cm PLATE	107				
5278		24cm PLATE	107				
34721		19cm PETAL BOWL	111				
34722	COVER FOR 19cm PETAL BOWL	111					
50454	Rochelle	48					
50460 White	2657	PETIT CUP	110				
	2931	6cm ROUND BOX (DEEP)	23				
	9651	SHELL DISH	110				
	9652	ROSE DISH	110				
	9653	LEAF DISH	110				
	9654	10cm PETIT TRAY	110				
	9655	SQUARE BOX W/COVER	110				
	9679	10cm PETAL DISH	111				
	9707	BABY SPOON	110				
	9712	11cm TEARDROP BOAT	110				
	9714	11cm OVAL BOAT	110				
	9715	9cm DRESSING BOAT	111				
	9716	10cm TEARDROP BOX W/COVER	111				
	29301	10cm ROUND BOX	23				
	29302	COVER FOR 10cm ROUND BOX	23				
	96561	WOVEN BOX	110				
	96562	COVER FOR WOVEN BOX	110				
	96571	PEACH BOX	110				
	96572	COVER FOR PEACH BOX	110				
	96581	PUMPKIN BOX	110				
96582	COVER FOR PUMPKIN BOX	110					
96751	POUCH BOX	110					
96752	COVER FOR POUCH BOX	110					
96761	RIBBON BOX	110					
96762	COVER FOR RIBBON BOX	110					
98121	6cm ROUND BOX	23					
98122	COVER FOR 6cm ROUND BOX	23					
50481 Square	2633	MUG	101				
	2634	ESPRESSO CUP	89				
	2652	TEA/COFFEE CUP	89				
	2663	BREAKFAST CUP	89				
	2678	FREE CUP	110				
	2680	CAFE AU LAIT BOWL 380cc	111				
	2697	MUG	101				
	2824	13cm SQUARE SOUP BOWL	89				
	3409	15cm SQUARE BOWL	89				
	3410	24cm SQUARE BOWL	89				
	3411	18cm SQUARE BOWL	89				
	3414	13cm SQUARE BOWL	89				
	3480	11cm SQUARE BOWL	89				
	3481	21cm SQUARE BOWL	89				
	3482	33cm OBLONG BOWL	106				
3502	6cm SQUARE BOWL	89					
3503	20cm TIDBIT TRAY	106					
3507	CAFE AU LAIT BOWL 630cc	111					
3510	30cm BUFFET TRAY	106					

INDEX

Pattern	Item	Description	Page			Pattern	Item	Description	Page		
50481 Square	3573	15cm OBLONG TRAY	82			50763 Aria	4695	SUGAR BOWL W/COVER 400cc	67		
	5182	27cm SQUARE PLATE	89				5332	30cm PLATE	66		
	5183	20cm SQUARE PLATE	89				5333	27cm PLATE	66		
	5185	31cm SQUARE PLATTER	89				5334	23cm PLATE	66		
	5186	33cm RECTANGLE PLATTER	89				5335	21cm PLATE	66		
	5194	ESPRESSO SAUCER	89				5336	16cm PLATE	66		
	5230	TEA/COFFEE SAUCER	89				5337	23cm RIM SOUP PLATE	66		
	5262	BREAKFAST SAUCER	89				5338	14cm BOWL	66		
	5263	17cm SQUARE PLATE	89				5340	BOUILLON SAUCER	67		
	5289	14cm SQUARE PLATE	89				5342	38cm PLATTER	67		
	5290	43cm RECTANGLE PLATTER	89				5473	29cm PASTA PLATE	66		
	5318	31cm SQUARE PLATE	89				5532	31cm PLATTER	67		
	5320	24cm SQUARE PLATE	89				5563	COMMON SAUCER	67		
	5321	23cm SQUARE PASTA PLATE	89				5564	ESPRESSO SAUCER	67		
	5401	15cm SQUARE BOWL	89				5587	COFFEE SAUCER	67		
	5614	18cm SAUCER	89				5613	27cm WIDE RIM PLATE	66		
	5615	SQUARE BUTTER DISH	105				5944	12cm BOWL	66		
	9694	23cm RECTANGLE TRAY	89				9733	23cm BUTTER TRAY	67		
	9695	SALT SHAKER(3 HOLES)	105				50764	Aria (White Matte&Shiny)	67		
	9696	PEPPER SHAKER(5 HOLES)	105				50767	Esprit (White Matte&Shiny)	61		
9736	32cm OBLONG TRAY	89			50771	Platinum Line	84				
50576 White	9680	GINKGO REST	105			50796	Gold Band	84			
	9681	ELM REST	105			50822	Platinum Band	84			
	9684	2 STEPS REST	105			50827 Opera	3528	25cm LARGE BOWL	108		
	9685	3 STEPS REST	105				3529	20cm MEDIUM BOWL	108		
	9687	3 SQUARES REST	105				3530	14cm SMALL BOWL	108		
	9701	ESCARGOT DISH	110				3532	46cm BUFFET BOWL	108		
	9702	MOULE DISH	110				3576	23cm SOUP BOWL	108		
	9703	ABALONE DISH	110				4583	COFFEE POT W/COVER 810cc	88		
	9704	OYSTER DISH	110				4585	CREAMER JUG 170cc	88		
	9705	SHELL DISH	110				4589	CREAMER JUG 100cc	88	111	
	9706	LEAF SPOON	110				4601	TEA POT W/COVER 500cc	88		
	9833	10cm 3 SQUARES REST	105				4603	CREAMER JUG 340cc	88		
50584	Laetitia	85			4604		TEA POT W/COVER 1,670cc	88			
50617 Oval	2695	TEA/COFFEE CUP	102				4671	SUGAR BOWL W/COVER 400cc	88		
	2696	MUG	102			5362	30cm PLATE	88			
	3486	30cm TEARDROP BOWL	91			5363	27cm PLATE	88			
	3487	25cm TEARDROP TRAY	91			5364	25cm PASTA PLATE	88			
	3488	18cm TEARDROP BOWL	91			5365	23cm PLATE	88			
	3489	16cm TEARDROP BOWL	91			5366	21cm PLATE	88			
	3490	38cm OVAL 3 DIVIDED PLATE	107			5367	17cm PLATE	88			
	3496	25cm ROUND 3 DIVIDED PLATE	107			5368	COMMON SAUCER	88			
	3563	30cm TEARDROP BOWL	91			5369	BOUILLON SAUCER	88			
	5295	32cm OVAL PLATE	91			5370	ESPRESSO SAUCER	88			
	5296	28cm OVAL PLATE	91			5371	60cm BUFFET PLATTER	108			
	5297	20cm OVAL PLATE	91			5372	60cm BUFFET FISH PLATTER	108			
	5298	28cm TEARDROP DEEP PLATE	91			5373	60cm FISH TRAY	108			
	5299	21cm TEARDROP DEEP PLATE	91			5374	34cm PLATTER	108			
	5300	28cm TEARDROP PLATE	91			5381	46cm BUFFET TRAY	108			
	5301	30cm OVAL PLATE	91			5382	51cm BUFFET TRAY(SINGLE-RIM TYPE)	108			
	5302	17cm OVAL PLATE	91			5383	40cm BUFFET TRAY(SINGLE-RIM TYPE)	108			
5303	20cm OVAL DEEP PLATE	91			5407	23cm SOUP PLATE	88				
50667	Gold Line	61			5498	36cm TRAY(SINGLE-RIM TYPE)	108				
50668	Platinum Line	61			5499	35cm TRAY	108				
50685	Nocturne Platinum	45			5619	45cm DEEP PLATE	108				
50689	Esmeralda	93			5620	35cm DEEP PLATE	108				
50690	Gold Pia	93			9743	23cm BUTTER TRAY	108				
50736	Eloise	48			45841	SUGAR BOWL 300cc	88				
50762	Gold Line	84			45842	COVER FOR SUGAR BOWL	88				
50763 Aria	2710	TEA/COFFEE CUP	64	67	88	45881	7cm PETIT BOWL 100cc	88	110		
	2711	TEA CUP	67	88		45882	COVER FOR 7cm PETIT BOWL	88	110		
	2712	BOUILLON CUP 350cc	51	67	88	50828 White	27381	PLAIN CUP	111		
	2713	ESPRESSO CUP	64	67	88		27382	COVER FOR PLAIN CUP	111		
	2714	MUG	67				27391	RELIEF CUP	111		
	2737	BOUILLON CUP 240cc	67	88			27392	COVER FOR RELIEF CUP	111		
	2807	COFFEE CUP(Stackable)	67			50829	Esprit (White Matte)	61			
	2809	10cm BOWL(Stackable)(RELIEF)	66	111		50832	Grace Garden	48			
	3517	23cm ROUND VEGETABLE BOWL	66			50853	Opera Platinum	88			
	4578	CREAMER JUG 340cc	67			50860	1557	27cm PLATE	27		
4579	TEA POT W/COVER 1,670cc	67			1670		30cm PLATE	27			

INDEX

Pattern	Item	Description	Page
50860	5495	33cm PLATE	27
50861	1557	27cm PLATE	27
	1670	30cm PLATE	27
	5495	33cm PLATE	27
50938		Golden Coin	49
50939 Anatolia Blue	1086	21cm PLATE	44
	1214	16cm PLATE	44
	1217	16cm SAUCER	44
	1218	18cm SAUCER	44
	1220	38cm OVAL PLATTER	44
	1221	32cm OVAL PLATTER	44
	1222	ESPRESSO SAUCER	44
	1269	23cm PLATE	44
	1557	27cm PLATE	44
	1646	23cm RIM SOUP PLATE	44
	1670	30cm PLATE	44
	1857	13cm FRUIT BOWL	44
	2423	TEA/COFFEE CUP	44
	2427	ESPRESSO CUP	44
	2428	BOUILLON CUP	44
	2685	MUG	44
	4357	CREAMER JUG 220cc	44
	4358	SUGAR BOWL W/COVER 300cc	44
	4414	CREAMER JUG 200cc	44
	4416	TEA POT W/COVER 940cc	44
4464	TEA POT W/COVER 550cc	44	
9318	SALT SHAKER (3HOLES)	44	
9319	PEPPER SHAKER (5HOLES)	44	
50945 Hammer	2757	ESPRESSO CUP	102
	5355	28cm PLATE	90
	5356	21cm PLATE	90
	5357	17cm PLATE	90
	5377	32cm PLATE	90
	5469	21cm ACCENT PLATE(ALLOVER RELIEF)	90
50983 Dice	5417	27cm PLATE	90
	5418	23cm ACCENT PLATE	90
	5419	21cm PLATE	90
	5420	23cm RIM SOUP PLATE	90
	5425	16cm PLATE	90
	5467	30cm PLATE	90
	5673	29cm PASTA PLATE	90
	50994 Shagreen Black	1086	21cm PLATE
	1214	16cm PLATE	47
	1220	38cm OVAL PLATTER	47
	1221	32cm OVAL PLATTER	47
	1269	23cm PLATE	47
	1557	27cm PLATE	47
	1646	23cm RIM SOUP PLATE	47
	1670	30cm PLATE	47
	1857	13cm FRUIT BOWL	47
	2710	TEA/COFFEE CUP	47
	2712	BOUILLON CUP 350cc	47
	2713	ESPRESSO CUP	47
	2731	MUG	47
	4583	COFFEE POT W/COVER 810cc	47
	4589	CREAMER JUG 100cc	47
	4601	TEA POT W/COVER 500cc	47
	5368	COMMON SAUCER	47
	5369	BOUILLON SAUCER	47
	5370	ESPRESSO SAUCER	47
	45841	SUGAR BOWL 300cc	47
	45842	COVER FOR SUGAR BOWL	47
51010		Gold Diamond	49
51011		Platinum Diamond	49
51030 Flat Rim	2762	TEA/COFFEE CUP	51
	2793	TEA/COFFE CUP	51
	2794	ESPRESSO CUP	51
	2876	ESPRESSO CUP	51
	2882	12cm BOWL	50
	2887	TEA/COFFE CUP	51

Pattern	Item	Description	Page
51030 Flat Rim	2888	ESPRESSO CUP	51
	2928	CAPPUCCINO CUP	51
	2959	TEA/COFFEE CUP	51
	2964	CAPPUCCINO CUP	51
	2970	ESPRESSO CUP	51
	2985	TEA/COFFEE CUP	51
	3555	14cm BOWL	50
	3556	23cm VEGETABLE BOWL	50
	3633	16cm BOWL	50
	3665	19cm BOWL	50
	4622	TEA POT W/COVER 1,340cc	51
	4623	COFFEE POT W/COVER 1,800cc	51
	4624	SUGAR BOWL W/COVER 340cc	51
	4625	CREAMER JUG 290cc	51
	4655	COFFEE POT W/COVER 600cc	51
	4656	COFFEE POT W/COVER 820cc	51
	4657	TEA POT W/COVER 710cc	51
	4658	TEA POT W/COVER 950cc	51
	4659	SUGAR BOWL W/COVER 250cc	51
	4660	CREAMER JUG 170cc	22 51
	4666	CREAMER JUG 100cc	51
	4667	CREAMER JUG 290cc	22 51
	4713	COFFEE POT W/COVER 600cc	51
	4714	TEA POT W/COVER 710cc	51
	4715	CREAMER JUG 170cc	51
	4716	CREAMER JUG 100cc	51
	4740	TEA POT W/COVER 900c	51
	4741	CREAMER JUG 170cc	51
	4742	SUGAR BOWL W/COVER 250cc	51
	5239	25cm SOUP PLATE	50
	5461	30cm FLAT RIM PLATE	50
	5462	27cm FLAT RIM PLATE	50
	5463	21cm FLAT RIM PLATE	50
	5464	23cm SOUP PLATE	50
	5472	16cm FLAT RIM PLATE	50
	5495	33cm FLAT RIM PLATE	50
	5513	29cm FLAT RIM PLATE	50
	5514	23cm FLAT RIM PLATE	50
	5561	COMMON SAUCER	51
	5562	ESPRESSO SAUCER	51
	5627	BOUILLON SAUCER	51
	5706	16cm SAUCER	51
	5707	ESPRESSO SAUCER	51
	5708	BOUILLON SAUCER	51
	5963	25cm FLAT RIM PLATE	50
6009	15cm SAUCER	51	
9787	23cm BUTTER TRAY	50	
51031 Beat	5503	30cm CAT'S EYE PLATE	91
	5504	26cm DEEP PLATE	91
	5505	30cm PLATE	91
	5536	16cm PLATE	91
	5537	23cm PLATE	91
	5538	29cm DEEP PLATE	91
	5539	33cm OVAL TRAY	91
	5698	37cm OVAL TRAY	91
	5699	23cm TRAY	91
	5700	27cm PLATTER	91
	5701	32cm PLATTER	91
	5702	38cm PLATTER	91
	27711	13cm SOUP BOWL	111
	27712	COVER FOR 13cm SOUP BOWL	111
	27801	10cm PETIT BOWL	110
27802	COVER FOR 10cm PETIT BOWL	110	
51035		Nocturne Gold	45
51050 Cool Coupe	2754	TEA CUP	103
	2759	CAPPUCCINO CUP	75
	2786	CAPPUCCINO CUP	75
	2879	10cm BOWL	111
	3536	28cm SERVING BOWL	74
	3552	17cm ROUND BOWL	75

Pattern	Item	Description	Page			
51050 Cool Coupe	3566	14cm ROUND BOWL	75			
	3571	13cm ROUND BOWL	75			
	3572	25cm ROUND BOWL	75			
	3578	22cm ROUND BOWL	75			
	3586	13cm BOWL	111			
	3587	14cm BOWL	111			
	3588	16cm BOWL	111			
	3589	19cm BOWL	111			
	4627	TEA POT W/COVER 1,060cc	82			
	5361	17cm BOWL	74			
	35381	12cm ROUND BOWL	37	75	95	
	35382	COVER FOR 12cm BOWL	75			
	35641	11cm ROUND BOWL	75			
	35642	COVER FOR 11cm BOWL	75	80		
	35662	COVER FOR 14cm BOWL	75			
	35831	10cm ROUND BOWL	75			
	35832	COVER FOR 10cm BOWL	75			
	36301	11cm SOUP BOWL	80			
	51090 White	2764	TEA CUP	102		
		2766	COFFEE CUP	102		
2768		ESPRESSO CUP	102			
5428		17cm FLAT PLATE	107			
5540		30cm FLAT PLATE	18			
5541		11cm FLAT PLATE	107			
5831		26cm FLAT PLATE	18			
5832		20cm FLAT PLATE	107			
9811		MUG COVER W/KNOB	101			
27651		SOUP CUP	111			
27652		COVER FOR SOUP CUP	111			
27671		FREE CUP	111			
27672		COVER FOR FREE CUP	111			
27691		PETIT CUP	111			
27692		COVER FOR PETIT CUP	111			
27701		17cm SALAD BOWL	109			
27702		COVER FOR 17cm SALAD BOWL	109			
36291		13cm BOWL	111			
36292		COVER FOR 13cm BOWL	111			
51091		5553	32cm DOUBLE SPOON TRAY	107		
	5554	25cm SPOON TRAY	107			
	9786	12cm SPOON	110			
51179	36562	SOUP CUP COVER (LOTUS KNOB)	37			
	36592	COVER FOR 30cm PLATE	37			
51180	2815	MUG	101			
	2816	MUG	101			
51213		Lotus Platinum	94			
51220		Blooming Rosy Lane	94			
51230 Montmartre Noir	1224	19cm PLATE	39			
	1541	10cm RICE BOWL	39			
	2793	TEA/COFFEE CUP	39			
	2794	ESPRESSO CUP	39			
	5239	25cm SOUP PLATE	39			
	5462	27cm PLATE	39			
	5463	21cm PLATE	39			
	5472	16cm PLATE	39			
	5513	29cm PLATE	39			
	5514	23cm PLATE	39			
	5561	COMMON SAUCER	39			
	5562	ESPRESSO SAUCER	39			
5637	23cm SOUP PLATE	39				
51244		Simply Platinum	96			
51270 Terrace Relief	2839	TEA/COFFEE CUP(M)	69			
	2846	CAPPUCCINO CUP	69			
	2847	BOUILLON CUP(M)	69			
	2875	ESPRESSO CUP	69			
	3608	17cm BOWL	68			
	3609	13cm BOWL	68			
	4684	TEA POT W/COVER 660cc	69			
	4685	SUGAR BOWL W/COVER(L)	69			
	4686	CREAMER JUG 180cc	69			
	4696	TEA POT W/COVER 1,180cc	69			

Pattern	Item	Description	Page			
51270 Terrace Relief	4697	COFFEE POT W/COVER 570cc	69			
	4699	CREAMER JUG 310cc	69			
	4700	SUGAR CONTAINER	69			
	5576	25cm PLATE	68			
	5578	21cm PLATE	68			
	5579	17cm PLATE	68			
	5580	24cm RIM SOUP PLATE	68			
	5581	16cm CEREAL BOWL	68			
	5582	15cm FRUIT BOWL	68			
	5584	ESPRESSO SAUCER	69			
	5668	30cm PLATE	68			
	5669	29cm PASTA PLATE	68			
	5670	27cm PLATE	68			
	5671	23cm PLATE	68			
	5672	COMMON SAUCER(M)	69			
	51288		Dover	57		
	51289		Windsor	49		
	51290 White	2820	TEA CUP(L)	110		
		2821	TEA CUP(S)	110		
		2993	MUG	101		
		4739	TEA POT W/COVER 900cc	9	23	
		5609	27cm AMUSE PLATE	17		
		5611	4 DIVIDED DISH	107		
		9801	WARMER FOR SOUP BOWL	82		
		9802	AMUSE CUP(HIGH)	110		
		9803	AMUSE CUP(LOW)	110		
54313		SOUP BOWL W/COVER 360cc	82			
54314		TEA POT W/COVER 1,070cc	82			
99752		DOME COVER	109			
99762	MUG COVER	101				
51298 Cool Coupe	2823	MUG	75	101		
	2830	ESPRESSO CUP	75			
	2831	TEA/COFFEE CUP	7	75		
	2845	BOUILLON CUP	75			
	2955	8cm BOWL	110			
	3657	14cm DEEP BOWL	74			
	4636	SUGAR BOWL W/COVER 430cc	75			
	4637	CREAMER JUG 310cc	75			
	4642	CREAMER JUG 180cc	75			
	4643	SUGAR CONTAINER	75			
	4662	COFFEE POT W/COVER 1,700cc	75			
	4663	TEA POT W/COVER 1,180cc	75			
	4664	TEA POT W/COVER 660cc	75			
	4665	COFFEE POT W/COVER 570cc	75			
	5617	19cm PLATE	74			
	5635	31cm PLATE	74			
	5636	28cm PLATE	74			
	5637	23cm SOUP PLATE	74			
	5638	21cm PLATE	74			
	5639	ESPRESSO SAUCER	75			
5640	17cm DEEP PLATE	74				
5641	16cm SOUP PLATE	74				
5642	12cm DEEP DISH	74				
5649	23cm PLATE	74				
5650	16cm BOWL	74				
5667	16cm PLATE	74				
5677	28cm DEEP PLATE	74				
5943	25cm PLATE	74				
9807	22cm BUTTER TRAY	74				
9808	SPOON	81				
9810	CHOPSTICKS & SPOON REST	80				
9813	11cm SPOON	110				
46362	COVER FOR SUGAR BOWL	75				
46821	SUGAR BOWL 215cc	75				
51299 Strata	5523	30cm SQUARE 6 DIVIDED TRAY	65			
	5601	8cm SQUARE TRAY	19	65		
	5602	16cm SQUARE DIVIDED TRAY	19	65		
	9798	7cm SMALL STAND(PLAIN)	19	65		
51300 Strata	5502	30cm SQUARE DIVIDED TRAY	19	65		
	5524	27cm SQUARE 4 DIVIDED TRAY	19	65		

INDEX

Pattern	Item	Description	Page	
51300 Strata	5525	34cm SQUARE 3 DIVIDED TRAY	19	65
	5527	27cm WIDE RIM PLATE	64	
	5597	16cm PLATE	64	
	5621	30cm PLATE	64	
	5622	27cm PLATE	64	
	5623	21cm PLATE	64	
	5624	23cm RIM SOUP PLATE	64	
	5625	TEA/COFFEE SAUCER	64	
	5660	ESPRESSO SAUCER	64	
	9797	7cm SMALL STAND(RELIEF)	19	65
51302		Platinum Line	84	
51303		Opera Gold	88	
51327	2883	14cm BOWL	111	
51349		Ensemble	84	
51350		Pembroke Platinum	49	
51351		Swirl Ring	49	
51357	5664	27cm PLATE	27	
	5727	30cm PLATE	27	
51365	5599	24cm SQUARE RIM PLATE	25	
51366	5599	24cm SQUARE RIM PLATE	25	
51377		Anatolia Blue, White Background	48	
51395	5628	20cm OBLONG TRAY	107	
	5661	28cm OBLONG TRAY	107	
51396	5664	27cm WIDE RIM PLATE	21	
	5665	24cm WIDE RIM PLATE	21	
	5666	27cm PLATE	107	
	5727	30cm PLATE	107	
51398		Gold Embossment	93	
51399		Platinum Embossment	93	
51408		Lotus Gold	94	
51446		Glowing Platinum	40	
51450		Platinum Line	57	
51473		Miko	85	
51522	1557	27cm PLATE	27	
	1670	30cm PLATE	27	
	1866	26cm FLAT PLATE	31	
	1986	29cm FLAT PLATE	31	
	1042	23cm OVAL RIM PLATTER	45	
	1086	21cm PLATE	45	
51527 Nocturne Platinum-Pro	1214	16cm PLATE	45	
	1217	16cm SAUCER	45	
	1222	ESPRESSO SAUCER	45	
	1269	23cm PLATE	45	
	1557	27cm PLATE	45	
	1670	30cm PLATE	45	
	1760	30cm OVAL RIM PLATTER	45	
	1857	13cm FRUIT BOWL	45	
	2423	TEA/COFFEE CUP	45	
	2427	ESPRESSO CUP	45	
	2685	MUG	45	
	4357	CREAMER JUG 220cc	45	
	4358	SUGAR BOWL W/COVER 300cc	45	
	4414	CREAMER JUG 200cc	45	
	4416	TEA POT W/COVER 940cc	45	
	4464	TEA POT W/COVER 550cc	45	
	5282	29cm PASTA PLATE	45	
	9318	SALT SHAKER (3HOLES)	45	
	9319	PEPPER SHAKER (5HOLES)	45	
	51534	1866	26cm FLAT PLATE	30
51544		Terrace Relief (White Matte&Shiny)	69	
51552 Glowing Platinum-Pro	1217	16cm SAUCER	40	
	1218	18cm SAUCER	41	
	1232	31cm PLATE	40	
	1541	10cm RICE BOWL	41	
	1578	16cm SOUP BOWL	41	
	1757	47cm OVAL RIM PLATTER	41	
	1759	35cm OVAL RIM PLATTER	41	
	1760	30cm OVAL RIM PLATTER	41	
	1761	25cm OVAL RIM PLATTER	41	
	1763	12cm NOODLE SOUP BOWL	41	

Pattern	Item	Description	Page		
51552 Glowing Platinum-Pro	1765	9cm SHARKS FIN BOWL	41		
	1842	36cm ROUND COUPE PLATE DEEP	41		
	1882	10cm SAUCE DISH DEEP	41		
	2830	ESPRESSO CUP	40		
	2831	TEA/COFFEE CUP	40		
	3268	SOUP CUP W/COVER (L)	41		
	4636	SUGAR BOWL W/COVER 430cc	40		
	4637	CREAMER JUG 310cc	40		
	4663	TEA POT W/COVER 1,180cc	40		
	5636	28cm PLATE	40		
	5637	23cm SOUP PLATE	41		
	5638	21cm PLATE	40		
	5639	ESPRESSO SAUCER	40		
	5667	16cm PLATE	40		
	9416	CHAPPEI SAUCER	41		
	9468	CHOPSTICK & SPOON REST	41		
	9549	SPOON (S)	41		
	9807	22cm BUTTER TRAY	41		
	20903	CHAPPEI (M)	41		
	33154	23cm MUFFIN DISH	41		
	33362	COVER FOR 23cm MUFFIN DISH	41		
	95181	CHINESE TEA CUP(M)	41		
	95182	COVER FOR CHAPPEI(M)	41		
	4267R	OIL CONTAINER	41		
	4267S	SOYA CONTAINER	41		
	4267V	VINEGAR CONTAINER	41		
	51555	1670	30cm PLATE	29	
	51556	9549	SPOON (S)	37	
	51571		Claire	57	
	51574 Meteor Silver	2687	TEA CUP	63	
		2690	ESPRESSO CUP	63	
		2703	COFFEE CUP	63	
		3554	16cm BOWL	63	
		3565	13cm BOWL	63	
		5242	27cm PLATE	63	
		5243	23cm PLATE	63	
		5244	21cm PLATE	63	
		5245	18cm PLATE	63	
		5304	23cm SOUP BOWL	63	
5305		COMMON SAUCER	63		
5315		ESPRESSO SAUCER	63		
51584		5462	27cm PLATE	29	
51585		1986	29cm FLAT PLATE	30	
51586		1986	29cm FLAT PLATE	30	
51589	1986	29cm FLAT PLATE	30		
51615	5462	27cm PLATE	27		
51618		Golden Stroke	84		
51632	1670	30cm PLATE	26		
51633	1670	30cm PLATE	26		
51651		Esperar Champagne Gold	94		
51673		Gold Line	57		
51677		Aurora	57		
51678 Bamboo Pearl	2882	12cm BOWL	56		
	2887	TEA/COFFEE CUP	56		
	2888	ESPRESSO CUP	56		
	3555	14cm BOWL	56		
	3633	16cm BOWL	56		
	4655	COFFEE POT W/COVER 600cc	56		
	4656	COFFEE POT W/COVER 820cc	56		
	4657	TEA POT W/COVER 710cc	56		
	4658	TEA POT W/COVER 950cc	56		
	4659	SUGAR BOWL W/COVER 250cc	56		
	4660	CREAMER JUG 170cc	56		
	4666	CREAMER JUG 100cc	56		
	4667	CREAMER JUG 290cc	56		
	5239	25cm SOUP PLATE	56		
	5461	30cm FLAT RIM PLATE	56		
5462	27cm FLAT RIM PLATE	56			
5463	21cm FLAT RIM PLATE	56			
5464	23cm SOUP PLATE	56			

INDEX

Pattern	Item	Description	Page			
51678 Bamboo Pearl	5472	16cm FLAT RIM PLATE	56			
	5514	23cm FLAT RIM PLATE	56			
	5561	COMMON SAUCER	56			
	5562	ESPRESSO SAUCER	56			
	5701	32cm PLATTER	56			
	5702	38cm PLATTER	56			
51683 Mirei Blue	1214	16cm PLATE	46			
	1217	16cm SAUCER	46			
	1218	18cm SAUCER	46			
	1220	38cm OVAL PLATTER	46			
	1221	32cm OVAL PLATTER	46			
	1222	ESPRESSO SAUCER	46			
	1269	23cm PLATE	46			
	1557	27cm PLATE	46			
	1646	23cm RIM SOUP PLATE	46			
	1670	30cm PLATE	46			
51684 Mirei Baby White	1558	19cm PLATE	46			
	1857	13cm FRUIT BOWL	46			
	2423	TEA/COFFEE CUP	46			
	2427	ESPRESSO CUP	46			
	2428	BOUILLON CUP	46			
	4357	CREAMER JUG 220cc	46			
	9318	SALT SHAKER (3HOLES)	46			
	9319	PEPPER SHAKER (5HOLES)	46			
51685	Mirei Noir	48				
51686	Mirei Elegant White	48				
51693	5461	30cm PLATE	27			
51694		Pearl Diamond Mosaic	85			
51702		Mirei Rouge	48			
51717	5461	30cm PLATE	27			
51719	1986	29cm FLAT PLATE	31			
51720	1986	29cm FLAT PLATE	29			
51721	1986	29cm FLAT PLATE	29			
51732	1986	29cm FLAT PLATE	30			
51733		Pink Rose	85			
51759		Tiara Gold	49			
51760		Tiara Platinum	49			
51774		Platinum Coin	49			
51798		Sense Matte & Shiny	71			
51799 Sense	2903	COFFEE CUP(Stackable/PLAIN)	72			
	2911	COFFEE CUP(PLAIN)	72			
	2912	ESPRESSO CUP(PLAIN)	72			
	2913	BOUILLON CUP(PLAIN)	72			
	2914	TEA CUP(PLAIN)	72			
	2915	CAPPUCCINO CUP(PLAIN)	72			
	5815	28cm WIDE RIM DEEP PLATE	20			
	5816	28cm WIDE RIM PLATE	17			
	2901	ESPRESSO CUP	73			
	2902	COFFEE CUP	73			
51800 Sense	2904	TEA CUP	73			
	2907	BOUILLON CUP	73			
	2909	CAPPUCCINO CUP	73			
	2910	9cm SUGAR BOWL	71			
	2927	MUG	73			
	3600	17cm BOWL	70			
	3602	10cm BOWL	71			
	3607	9cm BOWL	71			
	3616	CASSEROLE W/COVER 3,600cc	73			
	3617	23cm BOWL	73			
	4687	TEA POT W/COVER 840cc	71			
	4691	SUGAR BOWL W/COVER 250cc	71			
	4692	CREAMER JUG 180cc	71			
	4708	CREAMER JUG 320cc	71			
	4710	COFFEE POT W/COVER 650cc	71			
	5769	30cm PLATE	71			
	5770	30cm COUPE PLATE	71			
	5772	29cm PASTA PLATE	70			
	5773	27cm PLATE	71			
	5774	27cm COUPE PLATE	71			
	5776	24cm RIM SOUP PLATE	70			

Pattern	Item	Description	Page				
51800 Sense	5777	23cm COUPE PLATE	71				
	5778	21cm COUPE PLATE	71				
	5779	19cm COUPE PLATE	71				
	5780	16cm COUPE PLATE	71				
	5781	10cm SAUCE DISH	71				
	5783	13cm SAUCER	72	73			
	5784	16cm SAUCER	72	73			
	5786	43cm OVAL PLATTER	73				
	5787	38cm OVAL PLATTER	73				
	5788	32cm OVAL PLATTER	73				
	5790	23cm TRAY	73				
	5793	18cm SAUCER	71				
	5812	27cm RIM PLATE	70				
	5813	28cm WIDE RIM DEEP PLATE	20	70			
	5814	28cm WIDE RIM PLATE	70				
	5818	15cm BOWL	70				
	5821	21cm WIDE RIM SOUP PLATE	70				
	5822	25cm RIM PLATE	70				
	5823	23cm RIM PLATE	70				
	5824	21cm RIM PLATE	70				
	5825	17cm RIM PLATE	70				
	5828	28cm OBLONG TRAY	19	73			
	5829	30cm OBLONG RIM TRAY	73				
	5836	28cm SQUARE TRAY	73				
	5850	24cm SQUARE FLAT TRAY	19	73			
	9841	SAUCER	71				
	9846	SALT SHAKER(1HOLE)	73				
	9847	PEPPER SHAKER(3HOLES)	73				
	36132	COVER FOR SOUP CUP	71				
	54590	CHAPPEI SET	71				
	98402	COVER	71				
	51802		Gold Line	84			
	51806		Nocturne Gold-Pro	45			
	51867	1986	29cm FLAT PLATE	30			
	51868	1986	29cm FLAT PLATE	30			
	51870	1986	29cm FLAT PLATE	30			
	51871		Patricia	48			
	51876		Claire Gold	57			
	51897	1986	29cm FLAT PLATE	31			
	51898		Duo Gold	49			
	51899		Duo Platinum	49			
	51906		Aurora Champagne Gold	57			
	51913		Platinum Line	71			
	51928		Charlotte	57			
	51955		Birch	49			
51960		Terrace Relief White(Matte)	69				
51979	5513	29cm PLATE	27				
	5514	23cm PLATE	27				
	51985	5830	27cm PLATE (CRYSTAL)	17			
		5939	30cm OBLONG TRAY	18			
		9844	SALT SHAKER(1HOLE)	18			
		9845	PEPPER SHAKER(3HOLES)	18			
		9848	CLOUD DISH	18			
		9929	ROCK TRAY (M)	18			
	9930	ROCK TRAY (S)	18				
	51989		Glowing Gold	40			
51993	5415	27cm WIDE RIM PLATE	25				
51994	5415	27cm WIDE RIM PLATE	25				
51995	1866	26cm FLAT PLATE	31				
51996	1866	26cm FLAT PLATE	31				
51998		Gold Line	71				
52006		Silver Stroke	84				
52010		Glowing Gold-Pro	40				
52059	1670	30cm PLATE	26				
52060	5859	31cm PLATE (VENUS)	17				
	5860	36cm TRAY (VENUS)	19				
	52061	5852	28cm PLATE (SHOWER)	17			
		6024	25cm PLATE (SHOWER)	17			
		6025	23cm PLATE (SHOWER)	17			
		36612	COVER FOR 25cm MUFFIN DISH	23			

INDEX

Pattern	Item	Description	Page
52062	5853	28cm PLATE (FOREST)	17
52063	5858	28cm PLATE (CASCADE)	17
52068	1670	30cm PLATE	26
52069	1670	30cm PLATE	26
52070		Golden Net	57
52074	1670	30cm PLATE	26
52080	2473	TEA/COFFEE CUP	102
	2942	ESPRESSO CUP	102
	4391	CREAMER JUG 170cc	103
	4392	SUGAR BOWL W/COVER 250cc	103
	4393	TEA/COFFEE POT W/COVER 920cc	103
	4717	TEA POT W/COVER 720cc	103
	4718	TEA POT W/COVER 1,200cc	103
52086		Crystal Platinum	53
52087 Gold Dust	2882	12cm BOWL	53
	2887	TEA/COFFEE CUP	53
	2888	ESPRESSO CUP	53
	3555	14cm BOWL	53
	3633	16cm BOWL	53
	4655	COFFEE POT W/COVER 600cc	53
	4657	TEA POT W/COVER 710cc	53
	4658	TEA POT W/COVER 950cc	53
	4659	SUGAR BOWL W/COVER 250cc	53
	4660	CREAMER JUG 170cc	53
	4667	CREAMER JUG 290cc	53
	5461	30cm FLAT RIM PLATE	53
	5462	27cm FLAT RIM PLATE	53
	5463	21cm FLAT RIM PLATE	53
	5464	23cm SOUP PLATE	53
	5472	16cm FLAT RIM PLATE	53
	5514	23cm FLAT RIM PLATE	53
	5701	32cm PLATTER	53
	5702	38cm PLATTER	53
	5706	16cm SAUCER	53
5707	ESPRESSO SAUCER	53	
52088		Platinum Net	57
52090	3635	16cm BOWL	111
	3636	14cm BOWL	111
	3637	11cm BOWL	80
	5861	28cm PLATE	107
	5862	22cm PLATE	107
52094	5461	30cm PLATE	27
52100 Waku	2952	TEA CUP	87
	3639	10cm RICE BOWL	87
	4719	TEA POT W/COVER 900cc	87
	5864	31cm OCTAGONAL PLATE	86
	5865	29cm OCTAGONAL PLATE	86
	5866	25cm OCTAGONAL PLATE	86
	5867	23cm OCTAGONAL PLATE	86
	5868	21cm OCTAGONAL PLATE	86
	5869	18cm OCTAGONAL PLATE	86
	5870	SAUCER(OCTAGONAL)	87
	5871	10cm SAUCE DISH(OCTAGONAL)	87
	5872	9.5cm SAUCE DISH(OCTAGONAL)	22 87
	5873	26cm TRAY	22 87
	5874	29cm ROUND PLATE	86
	5875	27cm ROUND PLATE(SHALLOW)	86
	5876	27cm ROUND PLATE(DEEP)	86
	5877	25cm DEEP PLATE	86
	5878	23cm ROUND PLATE	86
	5879	22cm SOUP PLATE	86
	5880	21cm ROUND PLATE	86
	5881	19cm ROUND PLATE	86
	5882	16cm ROUND PLATE	86
	5883	SAUCER(ROUND)	87
	5884	8cm SAUCE DISH(ROUND)	22 87
	5885	19cm ROUND STEP PLATE	86
	5886	29cm ROUND PLATE(WITHOUT FRAME)	86
	5901	31cm OCTAGONAL FLAT PLATE(WITHOUT FRAME)	86
	5927	TEA SAUCER(OCTAGONAL)	87

Pattern	Item	Description	Page
	5928	TEA SAUCER(ROUND)	87
	29451	CHAPPEI CUP	36 87
	29452	COVER	87
	36402	COVER FOR SOUP CUP	87
	54635	SOUP CUP W/COVER	87
	54641	SOUP CUP W/COVER(WITHOUT HANDLE)	87
	54653	CHAPPEI SET	87
	54654	CHAPPEI SET	87
52102		Botanica	48
52116		Chester	49
52138	1866	26cm FLAT PLATE	28
	1986	29cm FLAT PLATE	28
52139	1866	26cm FLAT PLATE	28
	1986	29cm FLAT PLATE	28
52142		Jupiter's Ring	93
52143	2956	MUG	101
52148		Shagreen Orange	49
52170		Galaxy Gold	85
52178	5864	31cm OCTAGONAL PLATE	30
	5865	29cm OCTAGONAL PLATE	30
52192	5865	29cm OCTAGONAL PLATE	30
52193 Sui		Sui	30
	5865	29cm OCTAGONAL PLATE	87
52194		Meteor Orange	63
52195		Meteor Purple	63
52196		Meteor Blue	63
52198	5875	27cm ROUND PLATE	30
52199	5936	28cm PLATE (RUSTIC)	17
52200	5937	29cm PLATE (HORIZON)	18
52201	5938	29cm PLATE (SWIRL)	18
52204	1866	26cm FLAT PLATE	28
52207	5816	28cm WIDE RIM PLATE	25
52208	1866	26cm FLAT PLATE	28
	1986	29cm FLAT PLATE	28
52209	1223	27cm PLATE	25
52215 Waltz	2992	CHAPPEI CUP	9
	3670	SOUP BOWL	9 22
	3692	RICE BOWL	9
	4738	CREAMER JUG 170cc	9 22
	5930	28cm PLATE	9
	5940	25cm DEEP PLATE	9
	5948	29cm DEEP PLATE	9
	5949	34cm OVAL BOWL	9 20
	5980	22cm DEEP PLATE	9
	5982	OVAL TRAY	9 22
52243	6019	20cm PLATE	9
	6020	CHAPPEI SAUCER	9
	6032	27cm PLATE	9
	6033	23cm PLATE	9
	6034	16cm PLATE	9
	6035	26cm SOUP PLATE	9
	9978	AMUSE CUP	9
	1986	29cm FLAT PLATE	28
	1866	26cm FLAT PLATE	29
	1986	29cm FLAT PLATE	29
52253	1986	29cm FLAT PLATE	28
52257 Rydges	3676	42cm OBLONG BOWL	7
	3677	25cm OVAL BOWL	7
	3696	15cm BOWL	7
	5976	27cm PLATE	7
	5977	28cm SIGNATURE PLATE	7
	5987	17cm PLATE	7
	6004	27cm DEEP PLATE	7 20
	6005	24cm PLATE	7
	6006	20cm PLATE	7
	6030	TEA/COFFEE SAUCER	7
52266		Anatolia Copper, White Background	48
52267		Aurora Pink	57
52386	1866	26cm FLAT PLATE	29
52387	1866	26cm FLAT PLATE	29

Pattern	Item	Description	Page				
52405		Urban Copper	57				
52422 Kikka	1221	32cm OVAL PLATTER	38				
	5820	27cm PLATE	38				
52423 Kikka	2831	TEA/COFFEE CUP	38				
	5637	23cm SOUP PLATE	38				
52424 Kikka	1128	COMMON SAUCER	38				
	1882	10cm SAUCE DISH DEEP	38				
	1913	11cm RICE BOWL	38				
	2984	MUG	38				
	3571	13cm ROUND BOWL	38				
	5638	21cm PLATE	38				
	9321	SPOON (L)	38				
52435 Canyon	1221	32cm OVAL PLATTER	54				
	2959	TEA/COFFEE CUP	54				
	3555	14cm BOWL	54				
	3556	23cm VEGETABLE BOWL	54				
	5239	25cm SOUP PLATE	54				
	5462	27cm FLAT RIM PLATE	54				
	5463	21cm FLAT RIM PLATE	54				
	5513	29cm FLAT RIM PLATE	54				
	5514	23cm FLAT RIM PLATE	54				
	5561	COMMON SAUCER	54				
	9318	SALT SHAKER(3HOLES)	54				
	9319	PEPPER SHAKER(5HOLES)	54				
	52436 Gold Couture	3639	10cm RICE BOWL	36			
		5864	31cm OCTAGONAL PLATE	36			
5866		25cm OCTAGONAL PLATE	36				
5867		23cm OCTAGONAL PLATE	36				
5869		18cm OCTAGONAL PLATE	36				
5872		9.5cm SAUCE DISH(OCTAGONAL)	36				
5873		26cm TRAY	36				
5884		8cm SAUCE DISH(ROUND)	36				
52437 Gold Couture	1218	18cm SAUCER	36	37			
	4719	TEA POT W/COVER 900cc	36				
	5883	SAUCER(ROUND)	36				
	9468	CHOPSTICKS & SPOON REST	37				
	29452	COVER FOR CHAPPEI	36				
52456	6021	28cm PLATE	21				
	6022	FOOTED PLATE	21				
52457 Caviar White	2762	TEA/COFFEE CUP	52				
	3555	14cm BOWL	52				
	3633	16cm BOWL	52				
	4740	TEA POT W/COVER 900cc	52				
	4741	CREAMER JUG 170cc	52				
	4742	SUGAR BOWL W/COVER 250cc	52				
	5462	27cm FLAT RIM PLATE	52				
	5463	21cm FLAT RIM PLATE	52				
	5472	16cm FLAT RIM PLATE	52				
52466	6021	28cm PLATE	21				
	6022	FOOTED PLATE	21				
52468 Ramage	1231	38cm OVAL COUPE PLATTER	34				
	1866	29cm FLAT PLATE	29				
	1882	10cm SAUCE DISH DEEP	34				
	1913	11cm RICE BOWL	34				
	1946	TEA/COFFEE SAUCER	34				
	2473	TEA/COFFEE CUP	34				
	3279	22cm ROUND VEGETABLE BOWL	34				
	4391	CREAMER JUG 170cc	34				
	4392	SUGAR BOWL W/COVER 250cc	34				
	4718	TEA POT W/COVER 1,200cc	34				
	5617	19cm PLATE	34				
	5636	28cm PLATE	34				
	5637	23cm SOUP PLATE	34				
	5667	16cm PLATE	34				
	6022	FOOTED PLATE	34				
	9549	SPOON (S)	34				
	52471	1670	30cm PLATE	27			
52473	3704	12cm DEEP BOWL	13				

Pattern	Item	Description	Page				
52473 Blue Marble	3706	8cm DEEP BOWL	13				
	3707	8cm PLATE	13				
	3709	12cm PLATE	13				
	3716	21cm PLATE	13				
52480 Noble	329	23cm TRAY	98				
	332	10cm PETIT TRAY	98				
	1394	16cm SAUCER	98				
	1410	19cm PLATE	98				
	1412	23cm PLATE	98				
	1413	17cm PLATE	98				
	1436	27cm PLATE	98				
	1506	23cm RIM SOUP PLATE	98				
	2229	TEA CUP	98				
	2455	COFFEE CUP	98				
	9313	PEPPER SHAKER(5HOLES)	95	98			
	9314	SALT SHAKER(3HOLES)	95	98			
	58045 Black Matte & Shiny	OC3452	23cm DEEP PLATE	20			
		OC5219	27cm DEEP PLATE	20			
OC5220		30cm SERVICE PLATE	17				
OC5524		27cm SQUARE 4 DIVIDED TRAY	65				
OC5526		27cm PLATE	64				
OC5527		27cm WIDE RIM PLATE	64				
58063		Sky Blue	12	15			
58064 Earth Brown	1217	LATTE SAUCER	15				
	1222	ESPRESSO SAUCER	15				
	1946	TEA/COFFEE SAUCER	15				
	2684	MUG	15				
	2695	TEA/COFFEE CUP	15				
	2696	LATTE CUP	15				
	2757	ESPRESSO CUP	15				
	2955	8cm BOWL	15				
	3571	13cm BOWL	15				
	3635	16cm BOWL	15				
	3636	14cm BOWL	15				
	3637	11cm BOWL	15				
	3657	14cm DEEP BOWL	15				
	5617	19cm PLATE	15				
	5636	28cm PLATE	15				
	5637	23cm DEEP PLATE	15				
	5638	21cm PLATE	15				
5649	23cm PLATE	15					
5667	16cm PLATE	15					
58066 Kokutan	3708	8cm DEEP DISH	13				
	3713	18cm PLATE	13				
	3714	18cm DEEP DISH	13				
	3715	18cm BOWL	13				
	3716	21cm PLATE	13				
	5617	19cm PLATE	15				
	5636	28cm PLATE	15				
	5637	23cm SOUP PLATE	15				
	5638	21cm PLATE	15				
	5649	23cm PLATE	15				
	5667	16cm PLATE	15				
5710	35cm OBLONG TRAY	15					
5738	36cm OBLONG TRAY	15					
5864	31cm OCTAGONAL PLATE	15					
5867	23cm OCTAGONAL PLATE	15					
5868	21cm OCTAGONAL PLATE	15					
5923	28cm OBLONG TRAY	15					
58068		Heather Gray	12	15			
58074	1557	27cm PLATE	25				
58075	1557	27cm PLATE	25				
58076	5462	27cm PLATE	25				
58077	5462	27cm PLATE	25				
58078	5462	27cm PLATE	25				
58081 Black Matte & Shiny	2923	MUG	101				
	2924	TEA/COFFEE CUP	102				
	2956	MUG	101				
	5720	COMMON SAUCER	102				
	5853	28cm PLATE (FOREST)	17				

INDEX

Pattern	Item	Description	Page				
58081 Black Matte & Shiny	5937	29cm PLATE (HORIZON)	18				
	5938	29cm PLATE (SWIRL)	18				
58082 White Matte & Shiny	2923	MUG	101				
	2924	TEA/COFFEE CUP	102				
	2956	MUG	101				
	5720	COMMON SAUCER	102				
	5853	28cm PLATE (FOREST)	17				
	5937	29cm PLATE (HORIZON)	18				
	5938	29cm PLATE (SWIRL)	18				
	5976	27cm PLATE	7				
	6004	27cm DEEP PLATE	7	20			
	58083 Gray Matte & Shiny	2923	MUG	101			
2924		TEA/COFFEE CUP	102				
2956		MUG	101				
5720		COMMON SAUCER	102				
58087 Black Matte & Shiny	5852	28cm PLATE (SHOWER)	17				
	5936	28cm PLATE (RUSTIC)	17				
	5940	25cm DEEP PLATE	20				
	5948	29cm DEEP PLATE	20				
58088 White Matte & Shiny	5852	28cm PLATE (SHOWER)	17				
	5936	28cm PLATE (RUSTIC)	17				
	5940	25cm DEEP PLATE	20				
	5948	29cm DEEP PLATE	20				
58089 Gray Matte & Shiny	5940	25cm DEEP PLATE	20				
	5948	29cm DEEP PLATE	20				
58104		Cobalt Blue	12				
58105		Terrace Matte Blue	69				
80740		Pembroke	49				
81405	5461	30cm PLATE	27				
81635		Montmartre Rouge	39				
81739 Grain	2959	TEA/COFFEE CUP	55				
	2970	ESPRESSO CUP	55				
	3555	14cm BOWL	55				
	4657	TEA POT W/COVER 710cc	55				
	4658	TEA POT W/COVER 950cc	55				
	4660	CREAMER JUG 170cc	55				
	5462	27cm FLAT RIM PLATE	55				
	5463	21cm FLAT RIM PLATE	55				
	5472	16cm FLAT RIM PLATE	55				
	5706	16cm SAUCER	55				
	5707	ESPRESSO SAUCER	55				
	92626 Chinese	331	MUSTARD POT	82			
		530	25cm OBLONG COUPE PLATE	81			
1041		16cm FRUIT BOWL	78				
1042		23cm OVAL RIM PLATTER	79				
1063		50cm OVAL COUPE PLATTER	79				
1074		38cm ROUND COUPE PLATE	78				
1102		23cm FLAT PLATE	81				
1144		21cm ROUND COUPE PLATE DEEP	78				
1172		42cm ROUND COUPE PLATE(B)	83				
1173		35cm ROUND COUPE PLATE(B)	83				
1174		31cm ROUND COUPE PLATE(B)	83				
1175		27cm ROUND COUPE PLATE(B)	83				
1176		25cm ROUND COUPE PLATE(B)	83				
1177		23cm ROUND COUPE PLATE(B)	83				
1178		21cm ROUND COUPE PLATE(B)	83				
1179		19cm ROUND COUPE PLATE(B)	83				
1180		16cm ROUND COUPE PLATE(B)	83				
1181		14cm ROUND COUPE PLATE(B)	83				
1182		12cm ROUND COUPE PLATE(B)	83				
1183		10cm ROUND COUPE PLATE(B)	83				
1184		13cm PORRIDGE BOWL(B)	83				
1185		12cm NOODLE SOUP BOWL(B)	83				
1186		11cm RICE BOWL(B)	83				
1187		10cm RICE BOWL(B)	83				
1188		9cm SHARK'S FIN BOWL(B)	83				
1198		14cm FRUIT BOWL(B)	83				
1218		SAUCER	80	87			
1223		27cm ROUND COUPE PLATE	78				
1224		19cm ROUND COUPE PLATE	78				

Pattern	Item	Description	Page			
92626 Chinese	1225	16cm ROUND COUPE PLATE	78			
	1226	19cm COUPE SOUP PLATE	78			
	1227	14cm FRUIT BOWL	78			
	1230	43cm OVAL COUPE PLATTER	79			
	1231	38cm OVAL COUPE PLATTER	74	79		
	1232	31cm ROUND COUPE PLATE	78			
	1288	23cm ROUND COUPE PLATE	78			
	1313	12cm ROUND COUPE PLATE	78			
	1536	42cm ROUND COUPE PLATE	78			
	1537	35cm ROUND COUPE PLATE	78			
	1538	30cm OVAL COUPE PLATTER	79			
	1539	25cm OVAL COUPE PLATTER	79			
	1540	23cm OVAL COUPE PLATTER	79			
	1541	10cm RICE BOWL	80			
	1578	16cm SOUP BOWL	79			
	1597	10cm ROUND COUPE PLATE	78			
	1598	25cm ROUND COUPE PLATE	78			
	1599	14cm ROUND COUPE PLATE	78			
	1643	21cm ROUND COUPE PLATE	78			
	1659	12cm SAUCE DISH DEEP	80			
	1690	7cm SAUCE DISH	80			
	1757	47cm OVAL RIM PLATTER	79			
	1759	35cm OVAL RIM PLATTER	79			
	1760	30cm OVAL RIM PLATTER	79			
	1761	25cm OVAL RIM PLATTER	79			
	1762	13cm PORRIDGE BOWL	80			
	1763	12cm NOODLE SOUP BOWL	80			
	1765	9cm SHARK'S FIN BOWL	80			
	1802	40cm OVAL RIM PLATTER	79			
	1842	36cm ROUND COUPE PLATE DEEP	78			
	1843	32cm ROUND COUPE PLATE DEEP	78			
	1844	27cm ROUND COUPE PLATE DEEP	78			
	1845	25cm ROUND COUPE PLATE DEEP	78			
	1866	26cm FLAT PLATE	81			
	1877	35cm DEEP OVAL PLATTER	79			
	1881	18cm OVAL RIM PLATTER	79			
	1882	10cm SAUCE DISH DEEP	80			
	1913	11cm RICE BOWL	80			
	1926	23cm ROUND COUPE PLATE DEEP	78			
	2318	SAMSHU CUP(L)	80			
	2319	CHINESE TEA CUP	82			
	2391	TEA CUP	82			
2430	JAPANESE TEA CUP	103				
2572	CHINESE TEA CUP(B)	83				
2660	ARABIC COFFEE CUP	82				
2977	SMALL CUP	80				
3212	SOUP TUREEN(L)	81				
3221	19cm NOODLE BOWL	79				
3225	SOUP TUREEN(S)	81				
3255	CASSEROLE W/COVER(10-P)	81				
3256	CASSEROLE W/COVER(4-P)	81				
3268	SOUP CUP W/COVER(L)	80				
3286	SOUP TUREEN(L)	81				
3288	SOUP TUREEN(S)	81				
3293	25cm SOUP BOWL	79				
3294	23cm SOUP BOWL	79				
3295	20cm SOUP BOWL	79				
3303	CASSEROLE W/COVER(6-P)	81				
3328	SOUP CUP W/COVER (S)	80				
3379	21cm NOODLE BOWL(B)	83				
3380	19cm NOODLE BOWL(B)	83				
3387	CASSEROLE W/COVER(12-P)	81				
3508	12cm ALL PURPOSE BOWL	79				
3601	SOUP BOWL W/COVER 570cc	80				
3641	SOUP CUP WITHOUT HANDLE	80	87			
3662	10cm SHALLOW BOWL	80				
4266	SAMSHU POT 400cc	80				
4294	CHINESE TEA POT 1,570cc	82				
4295	CHINESE TEA POT 1,130cc	82				
4313	SAMSHU POT 240cc	80				

INDEX

Pattern	Item	Description	Page		
92626 Chinese	4337	CHINESE TEA POT 1,060cc	82		
	4340	SOYA/VINEGAR POT	82		
	5002	36cm ROUND COUPE PLATE DEEP(B)	83		
	5003	32cm ROUND COUPE PLATE DEEP(B)	83		
	5004	27cm ROUND COUPE PLATE DEEP(B)	83		
	5005	25cm ROUND COUPE PLATE DEEP(B)	83		
	5006	23cm ROUND COUPE PLATE DEEP(B)	83		
	5011	43cm OVAL COUPE PLATTER(B)	83		
	5012	38cm OVAL COUPE PLATTER(B)	83		
	5013	30cm OVAL COUPE PLATTER(B)	83		
	5014	25cm OVAL COUPE PLATTER(B)	83		
	5015	23cm OVAL COUPE PLATTER(B)	83		
	5170	10cm BOWL	80		
	5270	27cm SQUARE PLATE	81		
	5329	SAUCER	80		
	5975	CHAPPEI SAUCER (S)	80		
	9277	9cm ROUND COUPE PLATE	78		
	9321	SPOON(L)	81		
	9322	SPOON HOLDER(L)	81		
	9323	TOOTHPICK HOLDER	82		
	9334	CHOPSTICKS REST	80		
	9338	SAMSHU CUP	80		
	9382	SPOON(S)	81		
	9416	CHAPPEI SAUCER	61	80	
	9428	DIVIDED DISH	80		
	9468	CHOPSTICKS & SPOON REST	80		
	9505	SPOON HOLDER(S)	81		
	9515	25cm CASTER TRAY(3 PORTIONS)	82		
	9548	SPOON(L)	81	83	
	9549	SPOON(S)	81	83	
	9660	10cm DISH	105		
	9780	ROUND DIVIDED DISH(Stackable)	80		
	9832	CHINESE WINE CUP	80		
	9834	CHOPSTICKS & SPOON REST	80		
	9884	SPOON	81		
	9977	18cm CASTER TRAY(2 PORTIONS)	82		
	20903	CHAPPEI(M)	80		
	29761	CHINESE TEA CUP(S)	80		
	29762	COVER FOR CHAPPEI (S)	80		
	32681	SOUP CUP	36	71	87
	32682	COVER FOR SOUP CUP	80		
	51158	CHAPPEI(L)	80		
	51202	CHAPPEI(S)	80		
	54607	TEA POT W/COVER 730cc	103		
	54633	CHAPPEI(L)	80		
	54711	CHAPPEI (S)	80		
93391	CHINESE TEA CUP(L)	71	80	82	
93392	COVER FOR CHAPPEI	9	61	80	
94441	CHINESE TEA CUP(S)	80			
94442	COVER	80			
94444	CHAPPEI SAUCER	80			
95181	CHINESE TEA CUP(M)	80			
95182	COVER	80			
98792	COVER	80			
4267R	OIL CONTAINER	82			

Pattern	Item	Description	Page		
92626 Chinese	4267RE	OIL CONTAINER	82		
	4267S	SOYA CONTAINER	82		
	4267SC	SOYA CONTAINER	82		
	4267SE	SOYA CONTAINER	82		
	4267V	VINEGAR CONTAINER	82		
	4267VC	VINEGAR CONTAINER	82		
	4267VE	VINEGAR CONTAINER	82		
	4461R	OIL CONTAINER	82		
	4461S	SOYA CONTAINER	82		
	4461V	VINEGAR CONTAINER	82		
	4476R	OIL CONTAINER	82		
	4476S	SOYA CONTAINER	82		
	4476V	VINEGAR CONTAINER	82		
	95667	5242	27cm PLATE	29	
95667	5312	30cm PLATE	29		
96000	1866	26cm FLAT PLATE	31		
96072	5462	27cm PLATE	27		
96404 Mirei Blue Mix & Match	4358	SUGAR BOWL W/COVER 300cc	46		
	4359	COFFEE POT W/COVER 1320cc	46		
	4416	TEA POT W/COVER 940cc	46		
96405		Mirei Noir Mix&Match	48		
96422		Mirei Rouge Mix&Match	48		
96543		Ruffle	57		
96658		Victoria	57		
96732		Ruffle Gold	57		
96759	1986	29cm FLAT PLATE	31		
96760		Cottonrose Orange	85		
96761		Cottonrose Blue	85		
96824	1986	29cm FLAT PLATE	31		
96835	1986	29cm FLAT PLATE	31		
96908	1986	29cm FLAT PLATE	31		
96970 Gold Couture	1120	27cm PLATE	37		
	1121	23cm PLATE	37		
	1122	21cm PLATE	37		
	1123	17cm PLATE	37		
	1136	30cm PLATE	37		
97040		Anatolia Copper, Mix & Match	48		
97178 Queen's Garden Red	1231	38cm OVAL COUPE PLATTER	35		
	1866	26cm FLAT PLATE	29		
	1882	10cm SAUCE DISH DEEP	35		
	1913	11cm RICE BOWL	35		
	2762	TEA/COFFEE CUP	35		
	3279	22cm ROUND VEGETABLE BOWL	35		
	4740	TEA POT W/COVER 900cc	35		
	4741	CREAMER JUG 170cc	35		
	4742	SUGAR BOWL W/COVER 250cc	35		
	5617	19cm PLATE	35		
	5636	28cm PLATE	35		
	5637	23cm SOUP PLATE	35		
	5667	16cm PLATE	35		
5706	TEA/COFFEE SAUCER	35			
5710	35cm OBLONG TRAY	35			
9549	SPOON (S)	35			
97179 Queen's Garden Green		Queen's Garden Green	35		
	1866	26cm FLAT PLATE	29		

HANDLING INSTRUCTIONS

Use of electronic devices

- Please do not use on open flame or in ovens under any circumstances.
- Please do not put products with gold or platinum decorations in microwave ovens (except where indicated it is safe to do so). For products without gold or platinum decorations, only household microwave ovens may be used to heat food.
- Use of dishwasher (household use): Please do not wash products with gold or platinum decorations in the dishwasher. Products without gold or platinum decorations may be washed in dishwasher; however, handwashing is recommended to protect luster.
- Use of dishwasher (hotel & restaurant use): Products may be washed in commercial dishwashers with appropriate water temperature and detergent concentration.
- When using microwave or dishwasher, please follow the instructions for the machine.
- Please follow the instructions indicated on the product itself, its attached leaflet or its packaging, if any.

For safe use

- Please avoid the following actions, as they may cause cracking :
 - Impact
 - Sudden heating or cooling
 - heating an empty vessel
 - Boiling or heating in water at over 60°C (140°F)If cracking occurs, please stop using the product and exercise due caution to avoid injury from the damaged parts.
- Please be careful not to burn yourself, as the product gets hot after heated in a microwave oven. Decorated parts especially become hot.
- Please do not tightly seal the product when you cover it with plastic wrap to heat it in a microwave oven.
- Please do not use the product for any other purpose than its intended use.

Maintenance & cleaning

- Please use a pH-neutral cleaning agent and a soft sponge or cloth.
- Tea and other stubborn stains should be removed using a commercially available oxygen bleaching agent in the specified manner.
- Lime scales and metal marks of knives and forks should be removed using a liquid cleanser (which is not rough to the fingertips). However, scratch marks of the knives due to vigorous scrubbing cannot be removed.
- Please remove any stains immediately after use to avoid them from becoming difficult to remove later.
- Please do not use a metal scourer, abrasive nylon scourer or cleanser, as these may lead to scratches on the surface or damage its decoration.
- After washing, the items should be dried thoroughly and stored in a place with low humidity.

Other instructions


- Vases or interior items should be placed in a stable position.
- Please be careful not to scrape the surface too hard with a knife, as this will create scars (knife marks) on the surface that cannot be removed.
- Please do not place parts of the bone china without glaze in contact with vinegar for an extended period of time, as this will damage the body.

Note for special glazes

- Special glazes, such as reactive glazes, color glazes and matte glazes, are applied on some products.
- As the glazes are sprayed one by one, variations in color are to be expected, and each piece is subtly one of a kind. Please enjoy the uniqueness of the individual pieces.
- It will be more difficult to clean off the stain if you leave it for too long. Please try to clean immediately after use.
- For better storage, it is recommended to have a sheet of paper in between plates to prevent scratches caused by rubbing.

Please note

- Specification may change without prior notice.
- Dimensions in this catalogue may differ slightly from dimensions of actual product.
- Color and shape of the actual product may differ from the color and shape pictured in catalogue, due to printing limitations.



L: Long Length H: Height
 S: Short Length D: Diameter
 Mentioned capacity(cc)is full.



■ NARUMI CORPORATION, JAPAN

3 Denjiyama, Narumi-cho, Midori-ku, Nagoya 458-8530, Japan
e-mail export@narumi.co.jp

Phone 81-52-896-2220
Fax 81-52-896-2295

■ NARUMI SINGAPORE PTE LTD

75 Bukit Timah Road, #05-02 Boon Siew Building, Singapore 229833
e-mail narumisingapore@narumi.co.jp

Phone 65-6220-3825
Fax 65-6221-5725

■ NARUMI SHANGHAI CO., LTD

Room 1204, 12F, Zhaofeng Plaza, 1027 Changning Road, Changning, Shanghai,
200050, P.R.China
e-mail info@narumi-china.com

Phone 86-21-5237-5038
Fax 86-21-5237-8686

■ NARUMI SHANGHAI CO., LTD GUANGZHOU OFFICE

Room 2915, Tower B, NO.191 Tiyu West Road, Tianhe District, Guangzhou City,
Guangdong Province, P.R.China
e-mail info@narumi-china.com

Phone 86-20-8362-2443
Fax 86-20-8362-6814

■ NARUMI CORPORATION HONG KONG REPRESENTATIVE OFFICE

Unit B, 21/F Seabright Plaza, 9-23 Shell Street, North Point, Hong Kong
e-mail narumihk@narumi.co.jp

Phone 852-2311-0912
Fax 852-2724-5560

■ NARUMI TABLEWARE USA, INC.

19301 Pacific Gateway Drive, Suite 130, Torrance, CA 90502, USA
e-mail narumiusa@narumi-usa.com

Phone 1-310-856-8560

■ P.T. NARUMI INDONESIA, JAKARTA OFFICE

Menara Standard Chartered, 2nd Podium, Part 3, Jl Prof, Satrio no. 164, Jakarta, 12930
e-mail narumi-indonesia@narumi.co.id

Phone 62-21-8061-5708
Fax 62-21-8061-5709

■ P.T. NARUMI INDONESIA, BALI OFFICE

Jl. Dewi Sri No.100 Blok B, Legian Kuta, Bali, 80361, Indonesia
e-mail narumi-indonesia@narumi.co.id


Phone 62-361-934-7471
Fax 62-361-934-7471



Website



Instagram
[narumi_pro](https://www.instagram.com/narumi_pro)





NARUMI